Reference Guide for the DS7400Xi (Version 3+) Control/Communicator





Keypad Quick Reference Guide

Turning On (arming) your System

Normal Arming - [PIN] + [On]

Perimeter Arming, no entry delay -
[PIN] + [No Entry] [Perimeter Only]

Perimeter Arming, with entry delay -
[PIN] + [Perimeter Only]

Maximum Security Arming -
[PIN] + [No Entry] [On]

Custom Arming - [PIN] + [#] [4]

Set Delayed Arming -
[PIN] + [99] and enter number of hours from current time to the desired arming time.

Extend Automatic Arming during pre-arm time -
[PIN] + [OFF]

Force Arming -
Enter an arming command followed by [Bypass]

Zone Bypass -
[PIN] + [Bypass] followed by the Zone number(s)
[PIN] +[Bypass] [*] to clear ALL Bypasses

Turning Off (disarming) your System

Enter your PIN followed by [Off]

Commands for other System Features

Chime Mode -	[PIN] + [#] [7]
Zone Test -	[PIN] + [#] [8] [1]
Read Event History -	[PIN] + [#] [8] [9]
Battery Test -	[PIN] + [System Reset]
Communicator Test -	[PIN] + [#] [8] [2]
Fire Reset -	[PIN] + [System Reset]
Remote Program Dial-out -	[PIN] + [#] [8] [3]
Remote Program Answer -	[PIN] + [#] [8] [6]
Local Battery/Sounder Test -	[PIN] + [#] [8] [5]
Error Display -	[PIN] + [#] [8] [7]
Error Display Reset -	[PIN] + [System Reset]
To Silence a Fire Trouble -	[PIN] + [Off]
To Clear a Fire Trouble Display -	[PIN] + [System Reset]

Access Control

Enter your Access Control PIN followed by [Off]

Detection Systems PTY Ltd.
Unit 21, 45 Gilby Road
Mount Waverley, Victoria 3149, Australia
61 3 9558 8088 Fax: 61 3 9558 8089

Detection Systems PTY Ltd.
Unit 2, The Riverside Centre
148 James Ruse Drive
Parramatta, NSW 2150, Australia
61 2 891 4944 Fax: 61 2 891 5844

Detection Systems Int'l Inc.
19, Rue du 19 Mars-78130
Les Mureaux, France
Phone/Fax: 33 1 34 74 9576

Detection Systems Ltd.
Unit 13-18, 17/F New Commerce Centre
19 On Sum Street, Shatin, N.T.
Hong Kong
852 2635 2815 Fax: 852 2648 7986

Detection Systems, Inc., 130 Perinton Parkway, Fairport, New York, USA 14450-9199
(716) 223-4060 • (800) 289-0096 • Fax: (716) 223-9180

Copyright © 1995-96

Table of Contents

Keypad Quick Reference Guide **1**

1.0 Specifications **4**

1.1 Enclosure Housing 4
1.2 Temperature 4
1.3 Power 4
1.4 Outputs 4
1.5 Zones 4
1.6 Keypads 4
1.7 Communicator 4
1.8 Partitions 4
1.9 Users 4
1.10 Lightning Protection 4
1.11 Burglar/Fire Zone Inputs 4
1.12 Fire Signal Initiating Circuit (2-wire mode) 4
1.13 Multiplex Bus Wiring Requirements 4
1.14 Option Bus Wiring Requirements 4
1.15 Max. Load Currents 4
1.16 Backup Battery Calculation 5
1.17 Standby Current Load 5
1.18 Options 5

2.0 Enclosure Installation **7**

2.1 Install the Enclosure 7
2.2 Install the Control/Communicator 7

3.0 Control Terminal Wiring **8**

4.0 Hardware Layout Example **9**

5.0 System Worksheet **10**

6.0 System Overview **14**

6.1 DS7400Xi Description 14
6.1.1 A/C Failure Report Delay 14
6.1.2 Entry/Exit Delay Cancel Zone Functions 14
6.1.3 General “Arm-Only” Authority by Partition 14
6.1.4 Input/Output Cross Matrixing 14
6.1.5 Multiplex Bus Outputs 14
6.1.6 Octal Relay Modules (DS7488) 14
6.1.7 Output Functions 14
6.2 Zone 14
6.3 Zone Function 14

7.0 Glossary **14**

7.1 General Control Programming 14
7.2 Zone Function Programming 15
7.3 Zone Programming 16
7.4 Output Programming 16
7.5 Partition Control Programming 17
7.6 Keypad Assignment Programming 17
7.7 Emergency Key Programming 17
7.8 Custom Arming Programming 17
7.9 Force Arming 17
7.10 Ground Fault Detect Programming 17
7.11 Commercial Fire Mode Programming 17
7.12 Open/Close Report Control Programming 18
7.13 Report Programming 18
7.14 Phone Number General Control Programming 19
7.15 Phone Answering Programming 19
7.16 FCC Compliance Notice 19
7.17 FCC Phone Connection Notice To Users 19
7.18 Canadian Dept. of Communications 20
7.19 For Installations in New Zealand 20

8.0 Operating Guide **21**

8.1 Personal Identification Numbers 21
8.1.1 General Information 21
8.1.2 Removing a PIN 21
8.1.3 Authority Levels 21
8.2 Arming/Disarming Commands 22
8.3 Changing the Date 22
8.4 Changing the Tempoary PIN Expiration Date 22
8.5 Changing the Time 23
8.6 Delayed Arming 23
8.7 Automatic Arming 24
8.8 Turning OFF the System under Duress 25
8.9 Emergency Procedures 25
8.9.1 Identifying Alarm Sounds 25
8.9.2 Silencing Alarms 25
8.9.3 A Cautionary Note 25
8.9.4 Use Common Sense 25
8.9.5 Caution When Entering A Building 25
8.9.6 Fire Alarms 25
8.10 Fire Reset/Fire Trouble 25
8.10.1 Fire Reset 25
8.10.2 Fire Trouble 25
8.11 Emergency Keypad Alarms 26
8.12 Fire Safety 26
8.12.1 If Installed in Family Residences 26
8.12.2 Having and Practicing an Escape Plan 26
8.12.3 Installation Considerations 27
8.13 Testing 27
8.13.1 Zone Test 27
8.13.2 Battery/Sounder Test 27
8.13.3 Communicator Test 28
8.13.4 Event History Readback 28
8.13.5 Remote Program Dial-out and Answer 28
8.13.6 Error Displays 29

9.0 The Master Keypad **30**

9.1 Master Keypad Displays 30
9.2 Arming from the Master Keypad 30
9.3 Disarming from the Master Keypad 31
9.4 Single Partition Mode 31

10.0 How to Program the Control Panel **31**

10.1 Entering the Programmer’s Mode 31
10.2 Reading back a Program Address 31
10.3 Entering a value in a Program Address 31
10.4 HEX values 32
10.5 Defaults 32
10.6 Setting the Control to the Factory Default 32
10.7 Exiting the Programmer’s Mode 32

11.0 Understanding the Programming Charts **32**

12.0 Programming **34**

12.1 General Control Programmong: Program Address (0000) 34

 Copyright © 1995-96 Detection Systems, Inc.

12.2 Zone Function Programming: Program Addresses (0001-0015) 35
12.3 Zone Programming: Program Addresses (0018-0145) 36
12.4 Zone Partition Assignment: Program Addresses (1248-1311) 36
12.5 Zone Bypass Programming: Program Addresses (0016-0017) 37
12.6 Output Programming: Program Addresses (0146-0148) 38
12.7 Output Partition Assignment: Program Addresses (0149-0150) 38
12.8 Partition Control Programming: Program Address (0165) 39
12.9 Quick Arm Control Programming: Program Address (0169) 39
12.10 Keypad Assignment Programming: Program Addresses (0173-0180) 40
12.11 Keypad Partition Assignment: Program Addresses (0208-0215) 40
12.12 Emergency Key Programming: Program Addresses (0181-0182) 41
12.13 Custom Arming Programming: Program Addresses (0183-0184) 41
12.14 Force Arming and Ground Fault Detect Programming: Program Address (0185) 42
12.15 Commercial Fire Mode Programming: Program Address (0186) 43
12.16 Open/Close Report Control Programming: Program Address (0187) 44
12.17 Open/Close & Zone Report Control Programming: Program Address (0189) 44
12.18 Report Control Programming: Program Address (0190) 44
12.19 Timer Programming: Program Addresses (0191-0196) 45
12.20 A/C Fail Report Delay Programming: Program Address (0197) 45
21.21 General Code “Arm Only” Programming: Program Address (0198-0201) 46
12.22 Arming Warning Programming: Program Addresses (0202-0205) 46
12.23 DS7412 RS232 Interface Control Programming: Program Address (0206) 47
12.24 DS7412 RS232 Interface Configuration Programming: Program Address (0207) 47
12.25 Report Programming: Program Addresses (0256-0304 and 0320-0340) 48
12.26 Phone/ARDIS Routing Control: Program Addresses (0494-0495) 49
12.27 Account Code Programming: Program Addresses (0496-0526) 50
12.28 Phone Number General Control Programming: Program Address (0528) 51
12.29 Phone Number Format Programming: Program Addresses (0529-0530) 51
12.29.1 Compatable Receivers 52
12.30 Phone Answering Programming: Program Address (0531) 52
12.31 Programmers and Master Code Programming: Programming Addresses (0532-0534) 53
12.32 Octal Relay Module Output Programming: Program Addresses (1456-1471) 53
12.32.1 Octal Relay Module Output Partition Assignment: Program Addresses (3725-3732) 54
12.33 Output Function Programming: Program Addresses (1472-1516) 55
12.33.1 Output Function Partition Assignment: Program Addresses (3733-3740) 56
12.34 Dual Phone Line/Bell Supervision Module Output Programming: Program Address (1520) 56
12.35 Call-Out Timer Programming: Program Addresses (1521-1524) 57
12.36 Test Report and Remote Programmer Call-Out Programming: Program Address (1525) 57
12.37 Alpha Description Programming: Program Addresses (1526-3701) 58
12.37.1 Alpha Description Programming: A Worksheet 59
12.38 Phone Number Programming: Program Addresses (4028, 4038, 4048) 63

13.0 Installation Guide for U.L. Listed Systems 64

13.1 DS7400Xi U. L. Listings: 64
13.1.1 U.L System Configurations 64
13.2 INSTALLATION CONSIDERATIONS 64
13.3 PROGRAMMING THE DS7400Xi 65
13.3.1 Household Fire Alarm using Digital Alarm Communicator Transmitter with local bell 65
13.3.2 Grade A Household Burglary Alarm using Digital Alarm Communicator Transmitter with local bell 65
13.4 General System Requirements 66
13.4.1 Local Burglary Alarm 66
13.4.2 Police Station Connection 66
13.4.3 Central Station Burglary Alarm 67
13.5 Commercial Fire Alarm 67
13.6 Wiring and Programming information for installations using the Ademco AB-12 Bell/Housing 68

14.0 Report Programming 69

14.1 4/2 Format 69
14.2 BFSK Format 70
14.3 Pager Format 71

15.0 Report Programming - Values Sent 73

15.1 SIA Format 73
15.2 Contact I.D Format 75

16.0 Multiplex Zone Addressing Guide 77

17.0 Troubleshooting Guide 78

17.1 Keypad Problems 78
17.2 Reporting Problems 79
17.3 Zone Problems 79
17.4 General System Problems 80

18.0 Program Addresses 84

Index 87

 Copyright © 1995-96 Detection Systems, Inc.

1.0 Specifications

1.1 Enclosure Housing

1. The standard enclosure is manufactured from 20 Ga., cold-rolled steel, and measures 12.5" Wide, by 14.5" High, by 3" Deep (31.8 cm Wide, by 36.8 cm High, by 7.6 cm Deep). A keyed lock is included, and this enclosure has provision for an optional tamper switch (required for commercial burglary applications) for monitoring the door.

1.2 Temperature

- Storage and Operating Temperature: +32° to +120°F (0° to +49°C)

1.3 Power

NOTE: The total current output capacity for all auxiliary devices, including keypads and smoke detectors = 1.5 A standby, 2.5 A alarm. The following ratings are maximum values. The total combined output cannot exceed the max. load current.

- Input power: 18 VAC, 50 VA, 50 Hz./60 Hz.
- Auxiliary regulated power: 12 VDC, 1.0 A max.
- U. L. Listed Auxiliary power: 12 VDC, 1.0 A max.
- U. L. Listed Alarm Power Output: 12 VDC, 1.75 A max.
- Auxiliary power voltage range: 12 V special application
- Optional Standby battery (P334): 12 V, 7.0 AH - 35 AH max.
- Control panel current draw: 175 mA, Standby
  250 mA, Alarm

1.4 Outputs

- Alarm Output: 12 VDC, 1.75 A output. Can be programmed for steady or pulsed output.
- Programmable Output 1* Solid state current sink (1.0 A max.). Shorts to ground when activated. Connect device to Aux. power positive. Can be used for alarm, arming state, or access control.** This output is generally programmable.
- Programmable Output 2* Solid state voltage source (500 mA max.). Can be used for alarm, arming state, or access control.** This output is generally programmable. For use with such compatible devices as the Listed DS250 with a 4-wire base.

* = Current draw should be subtracted from either maximum auxiliary or maximum alarm current draw.

** = Not investigated to the requirements of UL294.

1.5 Zones

- 8 on-board zones. Up to 128 total zones with expansion modules.
- Zone Response Time: 300 ms.

1.6 Keypads

- Maximum # of keypads: 15 Keypads
- Maximum wire length each: 1000 feet (305 m)
- Maximum wire length total: 6000 feet (1830 m) in system
- Wire type: 4 conductor, unshielded, #22 AWG (0.8 mm) "Telephone quad" or #18 AWG (1.0 mm) quad wiring can be home-run or daisy- chained.

NOTE: No more than 2 keypads (#22 AWG) or 3 keypads (#18 AWG) are recommended on any 1000 foot (305 m) run.

NOTE: Shared cable is not recommended for keypad, multiplex, options bus, telephone, or siren wiring.

1.7 Communicator

Will report to two phone numbers with full single, double and back-up reporting. Communicates in SIA (110 or 300 baud), 3/1, 3/1 Ext., 3/1 with Parity, 3/1 Ext. with Parity, 4/1, 4/2, BFSK, Contact ID, and Pager formats.
FCC Registration Number is ESVUSA-75333-AL-E
The ringer equivalence is 0.1B
Commercial Fire CSFM Listing Number is 7165-1062:111
Residential Fire CSFM Listing Number is 7167-1062:111

1.8 Partitions

The system has the capacity for 8 independant partitions.

1.9 Users

The DS7400Xi system allows up to 90 individual users. Each user will have his own PIN number (the 4 digit code entered at the keypads) and his own authority level (to determine which functions he may perform).

1.10 Lightning Protection

MOVs and spark gaps provide protection from lightning surges and static discharges.

1.11 Burglar/Fire Zone Inputs

- Number of circuits: 8 Circuits on-board
- End-of-line resistor: 2.2 K Ω (P/N 25944, provided)
- Loop resistance tolerance: 60 ohms

1.12 Fire Signal Initiating Circuit (2-wire mode)

Fire circuit will work with 2 or 4-wire detectors and has optional alarm verification.

- Number of circuits: 8 Circuits on-board
- Type of circuit: Class B, latching
- End-of-line resistor: 2.2 K Ω (P/N 25944, provided)
- Supervisory current: 5.5 mA
- Maximum short circuit current: 22 mA
- Maximum line resistance: 60 ohms
- Circuit voltage range: 8.5 to 14.1 VDC
- Total detector standby current: 2.5 mA

1.13 Multiplex Bus Wiring Requirements

- #22 AWG (0.8 mm). Up to 2000 feet (610 m) per system.
- #18 AWG (1.0 mm). Up to 5000 feet (1525 m) per system.

1.14 Option Bus Wiring Requirements

- Maximum wire length 1000 feet (305 m) per home-run.

1.15 Max. Load Currents

Max. Load Currents	Standby	Alarm
U. L. Installations	1.5 A	2.5 A
Non-U. L. Applications	2.0 A	2.5 A
Max. Current By Output: Not to exceed the max. load currents listed above per column.		
Aux. Power & Keypad (Combined)	1.0 A	1.0 A
Option Power	1.0 A	1.0 A
Bell Output	X	1.75 A
Programmable Output 2	500 mA	500 mA
Loop Power +	500 mA	500 mA

Copyright © 1995-96 Detection Systems, Inc.

1.16 Backup Battery Calculation

- The following table is used to calculate the standby battery capacity required by NFPA when using the DS7400Xi:

Device	Quantity	Standby Current Per Device	Total Standby Current (Quantity x Standby Current Per Device)	Alarm Current Per Device	Total Alarm Current (Quantity x Alarm Current Per Device)
DS7447 Keypad		100 mA		100 mA	
DS7445 Keypad		75 mA		75 mA	
DS7430 - Multiplex Expansion		65 mA		65 mA	
DS7432 - 8 Input Remote		10 mA		10 mA	
DS7433 - 8 Input Direct		50 mA		65 mA	
DS7488 - Octal Relay*		10 mA + 40 mA*		10 mA + 40 mA*	
DS7416 - ARDIS Module		127 mA		127 mA	
DS7457 - Single Zone Multiplex Input		350 µA		350 µA	
DS7460 - Dual Zone		1 mA		1 mA	
DS7465 - Input/Output		1 mA		1 mA	
DS7450 & DS7452 - Contact Points		350 µA		350 µA	
DS7420i - Dual Line/Bell Supervision		20 mA		140 mA	
DS7480 - Bell Supervision		20 mA		20 mA	
DS7481 - Single Line Monitor		20 mA		20 mA	
Smoke Detectors					
Bells, Horns, etc.					
Other sensors					
Other					
		Grand Total		Grand Total	

* = When calculating Standby and Alarm Current for the Octal-Relay Module, use 10 mA plus 40 mA for each activated relay.

1.17 Standby Current Load

- Battery AH - (20% Storage + 0.375 AH's Alarm)
- The following table is the derated battery divided by hours minus the control standby (175 mA):

Rechargeable Battery Size	Max. Standby for 4 hours	Max. Standby for 8 hours	Max. Standby for 24 hours	Max. Standby for 48 hours	Max. Standby for 60 hours	Max. Standby for 72 hours	Max. Standby for 80 hours
7 AH	1.0 A	470 mA	X	X	X	X	X
8 AH	1.2 A	580 mA	X	X	X	X	X
14 AH	1.5 A	1.1 A	270 mA	X	X	X	X
15 AH	1.5 A	1.2 A	300 mA	X	X	X	X
17.2 AH	1.5 A	1.5 A	380 mA	100 mA	X	X	X
21 AH	1.5 A	1.5 A	500 mA	160 mA	100 mA	X	X
28 AH	1.5 A	1.5 A	740 mA	280 mA	190 mA	130 mA	100 mA
30 AH	1.5 A	1.5 A	800 mA	310 mA	210 mA	150 mA	120 mA
35 AH	1.5 A	1.5 A	970 mA	400 mA	280 mA	200 mA	170 mA

1.18 Options

- **DS7412:** RS232 Serial Interface module. The DS7412 module allows the panel to send event information, in an ASCII format, directly to a serial printer or computer. In addition, the interface allows the direct connection of a computer to the panel for programming via the WDSRP programming software.
  - Current Draw= 25 mA, 35 mA with LEDs on.

- **DS7420i:** Dual Phone Line/Bell Supervision Module (1 per system).
  The DS7420i allows the control to be used in NFPA 72 installations. It provides two supervised 12.0 VDC signaling outputs, one Class A (Style D) input zone, and dual phone line transmission and supervision.
  - Current Draw = 20 mA, Standby. 140 mA, Alarm.

- **DS7430:** Multiplex Expansion Module (1 per system).
  The DS7430 provides a two-wire multiplex bus for the connection of additional remote zones. It also supplies up to 250 mA for 4-wire multiplex devices such as the DS7432.
  - Current Draw = 65 mA, Standby. 65 mA, Alarm.

- **DS7432:** 8 Input Remote Module (up to 15 per system. Requires a DS7430 Multiplex Expansion Module).
  The DS7432 provides a means of monitoring conventional Normally Open or Normally Closed contacts. It reports their status to the control panel as multiplex addresses. It occupies eight multiplex zones on the system and can monitor up to eight separate loops. It will support 4-wire smoke detectors.
  - Current Draw = 10 mA, Standby. 10 mA, Alarm.

Copyright © 1995-96 Detection Systems, Inc.

- **DS7433:** 8 Input Direct Module (1 per system. Can not be used with the DS7430 Multiplex Expansion Module). The DS7433 provides a means of expanding the system to include eight additional hard-wired zones. Each zone can support up to twenty 2-wire smoke detectors (can also support 4-wire smoke detectors).
  • Current Draw = 65 mA, Standby. 80 mA, Alarm. Add 15 mA for each additional zone in alarm.

- **DS7445:** Control Station.
  The DS7445 is an LED keypad which has LEDs representing the first 8 zones of the system. It displays information on various control panel functions. A built in sounder is used as an interior warning device and to annunciate keystroke entries.
  • Current Draw = 75 mA, Standby. 75 mA, Alarm.

- **DS7447:** Control Station.
  The DS7447 is an Alpha-Numeric LCD keypad. It displays information on various control panel functions. A built-in sounder is used as an interior warn ing device and to annunciate keystroke entries.
  • Current Draw = 100 mA, Standby. 100 mA, Alarm.
  • Keypad Access Output: The DS7447 Alpha Key pad will provide a ten (10) second access relay ouput if equipped with the optional K938 Relay. The relay will energize at the keypad if the user has a master, unlimited, general, or access PIN. The output will change only if the user has access to the partition assigned to the keypad. See the DS7447 Keypad Installation Instructions (P/N 22235) for wiring information.

- **DS7450:** Flush Mount Single Multiplex Contact Point (requires a DS7430 Multiplex Expansion Module).
  The DS7450 is intended as a replacement for conventional dry contacts, and to report an actual multiplex address to the control panel.
  • Current Draw = 350 µA, Standby. 350 µA, Alarm.
  • Occupies 1 zone.

- **DS7452:** Surface Mount Single Multiplex Contact Point (requires a DS7430 Multiplex Expansion Module).
  The DS7452 is intended as a replacement for con ventional dry contacts, and to report an actual multi plex address to the control panel.
  • Current Draw = 350 µA, Standby. 350 µA, Alarm.
  • Occupies 1 zone.

- **DS7457:** Single Zone Multiplex Input Module (requires a DS7430 Multiplex Expansion Module).
  The DS7457 provides a means of monitoring conventionally Normally Open or Normally Closed contacts. It reports their status to the control panel as multiplex addresses. It occupies one multiplex zone on the system and can monitor one loop. It also includes a tamper loop.
  • Current Draw = 350 µA, Standby. 350 µA, Alarm.

- **DS7460:** Dual Zone Module (up to 60 per system. Requires a DS7430 Multiplex Expansion Module).
  The DS7460 provides a means of monitoring conventional Normally Open or Normally Closed contacts. It reports their status to the control panel as multiplex addresses. It occupies two multiplex zones on the system and can monitor up to two separate loops.
  • Current Draw = 1 mA, Standby. 1 mA, Alarm.

- **DS7465:** Input/Output Module (up to 20 per system. Requires a DS7430 Multiplex Expansion Module).
  The DS7465 provides a Form “C” relay that may be programmed to activate on system events, and an input loop to monitor conventional Normally Open or Normally Closed contacts. It reports their status to the control panel as multiplex addresses.
  • Current Draw = 1 mA, Standby.1 mA, with relay energized.
  • Occupies 2 zones.

- **DS7480:** Bell Supervision Module (1 per system).
  The DS7480 provides a means of monitoring bells. It provides a supervised (polarity reversing) output relay to activate the bell. It also provides a Form “C” Bell Fault Output to be connected to the control panel.
  • Current Draw = 7 mA @ 12 VDC, Standby. 50 mA @ 12 VDC, Alarm.

- **DS7481:** Single Phone Line Monitor (1 per system).
  The DS7481 provides a means of monitoring a single phone line for fault conditions. When a fault is detected, the DS7481 automatically closes its Normally Open relay contacts to provide a means of signaling the fault.
  • Current Draw = 20 mA, Standby. 20 mA, Alarm.

- **DS7488:** Octal Relay Module (2 per system).
  The DS7488 provides 8 Form “C” relay outputs for addition to the system. The outputs are fully programmable and can be activated by system events. Each output operates individually of the other 7 outputs for complete flexibility.
  • Current Draw = 10 mA + 40 mA for each relay when energized.

The control/communicator is also available in three package formats. The packages include the following:

- **DS7400XiF:** DS7400Xi in large red enclosure (manufactured from 18 Ga., cold-rolled steel, and measures 15.0" Wide, by 20.75" High, by 4.25" Deep (38.1 cm Wide, by 52.7 cm High, by 10.8 cm Deep)).

- **DS7400XiFCP:** DS7400XFi package
  DS7420i
  DS7447
  AE-TR16

- **DS7400XiCC:** DS7400Xi in an Attack Enclosure.

When installing a U. L. Listed system,
refer to the Installation Guide for U. L. Listed Systems.
See Section 14.0.

 Copyright © 1995-96 Detection Systems, Inc.

2.0 Enclosure Installation

The DS7400Xi control/communicator and the enclosure are shipped together. The control, however, still needs to be installed into the enclosure. Hardware for mounting the enclosure to a wall, and the control to the enclosure is located in its own hardware pack.

2.1 Install the Enclosure

- Use the enclosure as a template and mark the top mounting holes on the mounting surface.
- Pre-start the mounting screws for these two holes. Slide the enclosure onto these mounting screws so that the screws move up into the thinner section of the holes. Tighten the screws.
- Screw in the remaining two screws in either set of bottom mounting holes.
- Knock out the desired wire entrances on the enclosure.

2.2 Install the Control/Communicator

CAUTION: The control is static sensitive. Make sure you touch earth ground before handling the control. This will discharge any static electricity in your body. Example: Run the ground wire to the enclosure before handling the control. Then keep holding the ground wire while installing the control.

- Insert the three support posts into the control retainer holes as shown in the diagram.
- Slide the top of the control into the retainer tabs (the slots under the top frame).
- Once in the retainer tabs, the control will rest on the three support posts.
- Secure the bottom of the enclosure by screwing the bottom three holes through the support posts and through to the control retainer holes.

CAUTION: Once the control is installed, be sure to connect its ground wire to the top hinge of the enclosure (the unpainted tab).



Support Post Assembly



Control/Communicator



Enclosure

Copyright © 1995-96 Detection Systems, Inc.

3.0 Control Terminal Wiring

WARNING: Before servicing, remove all power including the transformer, battery and phone line. A complete functional test is required after any programming.

CAUTION: Incorrect connections may result in damage to the unit.

System is Power Limited except for battery terminals. All wiring entering this enclosure must be power limited.

A/C Power Indication LED

1	⏚	**EARTH GROUND:** Must be connected to a good earth ground such as a cold water pipe and also connected to the cabinet cover, using the supplied wire jumper.
2	⏚	
3	A C	**A/C INPUT:** Use U. L. listed, 18 VAC 50 VA, class 2 transformer. Model TR-1850 requires 50/60 Hz. unswitched dedicated outlet - do not share.
4		
5	–	**ALARM OUTPUT:** Provides 12 VDC, special application, up to 1.75 A for powering bells, siren drivers, etc. Function programmed in address 0146.
6	A	
7	–	**AUXILIARY POWER:** Provides 12 VDC, special application, up to 1.0 A for powering detectors.
8	+	

TYPICAL BURGLAR AND FIRE WIRING



Typical burglar alarm loop wiring

Typical 2-wire smoke detector wiring

(for a list of compatible 2-wire smoke detectors, see Technical Service Note P/N 27685)

Typical 4-wire smoke detector wiring. For example: Detection Systems' DS250 in an MB4W base.

R B G Y	OPTION	**OPTION BUS:** Used for options such as the ARDIS communications module, the DS7420i Dual Phone Line module, etc. Also for keypads #11 - #15. For Commercial Fire Mode: Option Bus wiring should be in conduit if run ouside the enclosure.

PROGRAMMABLE OUTPUTS:
PO1 shorts to aux. power negative when activated, PO1 can sink up to 1.0 A. PO1 function programmed in address 0147.

PO2 supplies 12 V and up to 500 mA when activated. PO2 function programmed in address 0148.

ZONES 1-8: Zones 1-8 are intended for connection of Normally Open or Normally Closed alarm contacts. They may also be used for compatible 2-wire smoke detectors. These zones require a 2.21KΩ resistor (P/N 25899) at the end of the loop. Power is momentarily removed from L+ after a [PIN] + [System Reset] or during a fire verification.
Zone 1-8 assignments are programmed in address 0018-0025.

KEYPAD BUS*: Up to 15 keypads** may be used. Can be "home-run" or "daisy-chained."				**PHONE LINE:**			
				T	TH	RH	R
R	B	G	Y	G	B	S	R
9	10	11	12	13	14	15	16

PO1	PO2	1–	L+	2–	3–	L+	4–	5–	L+	6–	7–	L+	8–
17	18	19	20	21	22	23	24	25	26	27	28	29	30



* = Maximum wire length each: 1000 ft. (305 m).
Maximum wire length total in system: 6000 ft. (1830 m) when using #22 AWG (0.8 mm) or #18 AWG (1.0 mm) cable.

** = Keypads #1 - #10 connect to the Keypad Bus and keypads #11 - #15 connect to the Option Bus.

Note: Shared cable is not recommended for keypad, multiplex, options bus, telephone, or siren wiring.

Copyright © 1995-96 Detection Systems, Inc.

4.0 Hardware Layout Example


ARDIS Interface Module
Keypads #11 - #15 must be connected to the Options Bus. Keypads #1 - #10 must be connected to the Keypad Bus.
DS7430
DS7400Xi
DS7432 8 - Input Remote Modules
47KΩ
Dry contact inputs
DS7420i Dual Phone Line/Bell Supervision Module
DS7488 Octal Relay Board
Battery
Battery
DS7450/52 Series Contacts, DS7460 Input Modules and DS7465 Input/Output Modules
DS7447 and DS7445 Keypads

Note: Ensure at least 1/4" separation between battery wires and all other cabling.

- Up to 15 keypads may be used. Keypads #1 - #10 connect to the Keypad Bus and keypads #11 - #15 connect to the Option Bus. One keypad must be designated as keypad #1 and connected to the Keypad Bus. See the DS7447 and DS7445 Installation Instructions for further details.
- A DS7420i (Dual Phone Line/Bell Supervision Module) may be connected to the control panel, and placed within the enclosure. Connect to the Options Bus of the control panel. See the DS7420i Installation Instructions for further details.
- A DS7488 (Octal Relay Module) may be connected to the control panel, and placed within the enclosure. Connect to the Options Bus of the control panel. This provides an additional 8 Form "C" relay outputs for the control panel. See the DS7488 Installation Instructions for further details.
- A DS7430 (Multiplex Expansion Module) may be connected to the control panel via the expansion port. This will allow for the connection of additional zones via the Options Bus. See the DS7430 Installation Instructions for further details.
- Up to 15 DS7432s (8 Input Remote Modules) may be connected to the DS7430. Connect to the Power and Bus terminals of the DS7430. This allows for a means of addressing up to 120 input loops of conventional contacts to the control panel. See the DS7432 Installation Instructions for further details.
- A Communications Module may be connected to the control panel via the Options Bus. This allows for connection to the ARDIS radio network.
- Up to 128 zones are available for the connection of Single, Multiple, Input/Output, and Multiplex devices.

Copyright © 1995-96 Detection Systems, Inc.

5.0 System Worksheet

Account Number _____ Information

Name _____ Contact Person _____

Address _____ Voice Phone Number _____

_____ Panel Phone Number _____

City, State, Zip _____ Panel Answers Phone ☐ Armed ☐ Disarmed

Equipment Location and Notes

AC Voltage _____ VAC Battery Voltage _____ VDC AUX Current _____ A

Battery Standby _____ AH Bell Current _____ A

Control Panel _____

Transformer _____

Telephone Jack _____

Telephone On Same Line as Panel _____

Earth Ground Connection _____

Alarm Sounder (s) _____

Misc. Notes

_____

_____

_____

_____

_____

_____

_____

_____

Keypad Location and Notes

	Example Location	Belongs to Partition	Master/ Standard
Keypad # 1	Kitchen	2	Master

	Location	Belongs to Partition	Master/ Standard		Location	Belongs to Partition	Master/ Standard
Keypad # 1				Keypad # 9			
Keypad # 2				Keypad # 10			
Keypad # 3				Keypad # 11			
Keypad # 4				Keypad # 12			
Keypad # 5				Keypad # 13			
Keypad # 6				Keypad # 14			
Keypad # 7				Keypad # 15			
Keypad # 8							

Copyright © 1995-96 Detection Systems, Inc.

Personal Identification Number Information

Example

PIN Information

User #	Pin #	Auth. Level	Parti-tions	Name
002	1001	6	1, 2, 4	James L.

PIN Information

User #	Pin #	Auth. Level	Parti-tions	Name
001				
002				
003				
004				
005				
006				
007				
008				
009				
010				
011				
012				
013				
014				
015				
016				
017				
018				
019				
020				
021				
022				
023				
024				
025				
026				
027				
028				
029				
030				

PIN Information

User #	Pin #	Auth. Level	Parti-tions	Name
031				
032				
033				
034				
035				
036				
037				
038				
039				
040				
041				
042				
043				
044				
045				
046				
047				
048				
049				
050				
051				
052				
053				
054				
055				
056				
057				
058				
059				
060				

PIN Information

User #	Pin #	Auth. Level	Parti-tions	Name
061				
062				
063				
064				
065				
066				
067				
068				
069				
070				
071				
072				
073				
074				
075				
076				
077				
078				
079				
080				
081				
082				
083				
084				
085				
086				
087				
088				
089				
090				

Copyright © 1995-96 Detection Systems, Inc.

5.0 System Worksheet (continued)

Zone Location and Notes

	Example Type *	Zone/Output Function #	Partition & Location
Zone # 1	SZ	Zn Funct. 1	2, Kitchen

* = SZ: Single Zone Input
MZ: Multiple Zone Input
IO: DS7465
(see section 12.3)

	Type *	Zone/Output Function #	Partition & Location
Zone # 1			
Zone # 2			
Zone # 3			
Zone # 4			
Zone # 5			
Zone # 6			
Zone # 7			
Zone # 8			
Zone # 9			
Zone # 10			
Zone # 11			
Zone # 12			
Zone # 13			
Zone # 14			
Zone # 15			
Zone # 16			
Zone # 17			
Zone # 18			
Zone # 19			
Zone # 20			
Zone # 21			
Zone # 22			
Zone # 23			
Zone # 24			
Zone # 25			
Zone # 26			
Zone # 27			
Zone # 28			
Zone # 29			
Zone # 30			
Zone # 40			

	Type *	Zone/Output Function #	Partition & Location
Zone # 31			
Zone # 32			
Zone # 33			
Zone # 34			
Zone # 35			
Zone # 36			
Zone # 37			
Zone # 38			
Zone # 39			
Zone # 40			
Zone # 40			
Zone # 41			
Zone # 42			
Zone # 43			
Zone # 44			
Zone # 45			
Zone # 46			
Zone # 47			
Zone # 48			
Zone # 49			
Zone # 50			
Zone # 51			
Zone # 52			
Zone # 53			
Zone # 54			
Zone # 55			
Zone # 56			
Zone # 57			
Zone # 58			
Zone # 59			
Zone # 60			

Copyright © 1995-96 Detection Systems, Inc.

Zone Location and Notes (continued)

	Type *	Zone/Output Function #	Partition & Location
Zone # 61			
Zone # 62			
Zone # 63			
Zone # 64			
Zone # 65			
Zone # 66			
Zone # 67			
Zone # 68			
Zone # 69			
Zone # 70			
Zone # 71			
Zone # 72			
Zone # 73			
Zone # 74			
Zone # 75			
Zone # 76			
Zone # 77			
Zone # 78			
Zone # 79			
Zone # 80			
Zone # 81			
Zone # 82			
Zone # 83			
Zone # 84			
Zone # 85			
Zone # 86			
Zone # 87			
Zone # 88			
Zone # 89			
Zone # 90			
Zone # 91			
Zone # 92			
Zone # 93			
Zone # 94			

	Type *	Zone/Output Function #	Partition & Location
Zone # 95			
Zone # 96			
Zone # 97			
Zone # 98			
Zone # 99			
Zone # 100			
Zone # 101			
Zone # 102			
Zone # 103			
Zone # 104			
Zone # 105			
Zone # 106			
Zone # 107			
Zone # 108			
Zone # 109			
Zone # 110			
Zone # 111			
Zone # 112			
Zone # 113			
Zone # 114			
Zone # 115			
Zone # 116			
Zone # 117			
Zone # 118			
Zone # 119			
Zone # 120			
Zone # 121			
Zone # 122			
Zone # 123			
Zone # 124			
Zone # 125			
Zone # 126			
Zone # 127			
Zone # 128			

Copyright © 1995-96 Detection Systems, Inc.

6.0 System Overview

6.1 DS7400Xi Description

The DS7400Xi Control/Communicator is a fully integrated hardwire/multiplex security/fire alarm system.

- It can support up to 128 input zones, 90 individual users, and multiple output options.
- It can be partitioned into as many as eight separate systems, thus allowing individual control and reports for each partition.
- Up to 15 keypads may be used to provide user interface with the system, as well as programming access for the installer.

6.1.1 A/C Failure Report Delay

The A/C power loss report can be programmed to delay for up to 254 minutes (see address 0197). (The same delay would also apply to the A/C restoral report.)

- If another report is sent during this delay period, the A/C fail report will be sent along with this report.
- If the A/C power restores during this delay period, the A/C loss report will not be sent.
- Programming address 0197 as FF causes the report to be sent at a random interval of at least 15 minutes, but no more than 2 hours after the A/C failure occurs.

6.1.2 Entry/Exit Delay Cancel Zone Functions

Entry/Exit Delay Cancel 1 and Entry/Exit Delay Cancel 2 Zone Functions cause the exit delay to expire as soon as the premises is vacated.

- If a zone is programmed as an Entry/Exit Delay Cancel zone, and it is activated during the exit delay, the exit delay will expire as soon as the zone has been restored.
- Entry/Exit Delay Cancel 1 follows entry delay 1.
- Entry/Exit Delay Cancel 2 follows entry delay 2.
- They are programmed at addresses 0001-0015.

6.1.3 General "Arm-Only" Authority by Partition

A general (level 2) authority can be programmed to have arm-only authority by partition. This is done at addresses 0198 and 0199.

- Arm-only access by partition allows someone with a General Authority to arm and/or bypass zones in a partition he can not disarm.
- This level can still be used to arm, disarm, and bypass zones in the other partitions that it has access to.

6.1.4 Input/Output Cross Matrixing

Input/Output Cross Matrixing allows Output Functions to follow the status of specific input zones (zones 1 through 99 only).

- Outputs can be programmed to follow any combination of one or two zones, open or closed, with the system armed or disarmed.
- If programmed to latch, the output will latch until a valid PIN is entered at the keypad.

6.1.5 Multiplex Bus Outputs

The DS7400Xi supports up to 20 DS7465 Input/Output Modules.

- These modules are connected to the multiplex bus and provide one input loop and one Form "C" output relay.
- The input loop operates the same as all other multiplex inputs.
- The output loop can be programmed to follow Output Functions.
- Multiplex Bus outputs can be bypassed using the bypass function. If an output zone is bypassed while it is ON, it will turn OFF. The bypass will not be removed when the system is armed and then disarmed; it must be cancelled by entering the bypass command again or by cancelling all bypasses.

Note: DS7465 Module outputs will not pulse, even if programmed to do so.

6.1.6 Octal Relay Modules (DS7488)

The DS7400Xi can support two Octal Relay Modules.

- Each relay can be programmed to follow system-wide events or Output Functions as described above.

6.1.7 Output Functions

Output Functions can be programmed to follow system events or to follow one or two specific zones in a "cross-matrix" fashion (see Input/Output Cross-Matrixing).

- These Output Functions can be programmed to control Octal Relay outputs or Multiplex Bus outputs.
- Output Functions are programmed at addresses 1472 through 1516.

6.2 Zone

A Zone is an input to the DS7400Xi Control/Communicator.

- There are 8 hardwired zones on the main circuit board.
- Additional zones may be added by using the DS7433 (8 zone expansion module), the DS7430 (multiplex loop module), and/or other modules.

6.3 Zone Function

A Zone Function is the description of how a particular zone will behave (e.g. steady alarm output, bypassing allowed, alarm on short, trouble on open, perimeter instant).

- Zone functions may be custom made, but 8 default zone functions already exist.
- There are many possible zone functions, but only up to 15 different zone functions are allowed per control.
- Each zone must be programmed as a specific zone function. Any number and combination of zones may be programmed as particular zone functions.

7.0 Glossary

7.1 General Control Programming

- **Normal Arming** - [PIN] + [On]: If programmed, arms the entire system while allowing entry delays for entry/exit zones.

- **Perimeter Instant Arming** - [PIN] + [No Entry] [Perimeter Only]: If programmed, arms only the perimeter of the system and does not allow entry delays for entry/exit zones.

- **Perimeter Arming** - [PIN] + [Perimeter Only]: If programmed, arms only the perimeter of the system while allowing entry delays for entry/exit zones.

- **Custom Arming** - [PIN] + [#] [4]: If programmed, allows custom arming of the system and bypasses the zone functions specified in data address 0183.

- **Maximum Security Arming** - [PIN] + [No Entry] [On]: If programmed, arms the entire system and does not allow an entry delay for entry/exit zones.

- **Closing Ring-Back**: If programmed, the keypad sounders and Bell will activate for 2 seconds after the system is armed and the closing report is successfully sent. This requires Closing Ring-Back and Closing Report to be programmed.
  - If a closing report is not programmed, the control will test for a dial tone when the system is armed. If the test passes, the sys-

 Copyright © 1995-96 Detection Systems, Inc.

tem will arm normally. If the test fails, the system will arm, but will indicate a trouble condition.
- The DS7447 keypad will display “Communication Err” after [#] [8] [7] is entered.
- This can also be used to perform a bell test on arming.

- **Siren on Comm. Fail for Silent Zone:** If programmed, a silent zone will sound the alarm outputs if the zone is in an alarm condition and the system fails to communicate with the central station.

- **Restore when Sounders Silence**: If programmed, a zone sends a restoral report and is ready to activate again only after the burglary bell cut-off time expires or the bells are silenced.
  - The zone can alarm multiple times per armed period.

- **Restore when Zone Restores**: If programmed, a zone sends a restoral report and is ready to activate again as soon as it physically restores.
  - This zone can alarm multiple times per armed period.

- **Restore when System Disarms**: If programmed, a zone sends a restoral report when the system is disarmed.
  - It can only alarm once per armed period.

- **Allow Swinger Shunts:** If programmed, a zone can only alarm or trouble up to three times per armed period. After the third alarm or trouble, the zone will be bypassed and a trouble report will be sent.

7.2 Zone Function Programming

- **Invisible Alarms**: This is a zone programmed not to have an alarm output or an alarm display at any keypad when activated. An alarm signal will be sent, but the DS7447 keypad display will read “Not Ready” while this zone is violated.
  - Invisible Alarm zones are recommended for holdup alarms.

- **Silent Alarms**: This is a zone programmed to activate the visual display at the keypad, but not audible signals.
  - If this zone is also an entry zone, an entry tone will sound when this zone is activated.

- **Bypassing Allowed**: This is a zone programmed to allow bypassing (shunting). This is done using the bypass command or the force-arming sequence.

- **Alarm on Short**: This is a zone programmed to activate an alarm when its loop is shorted.

- **Alarm on Open**: This is a zone programmed to activate an alarm when its loop is opened.

- **Trouble on Open**: This is a zone programmed to activate a trouble when its loop is opened and the system is disarmed.
  - If the system is armed, this zone will activate an alarm if shorted or opened.
  - For 24-hour zones, regardless of the arming state of the panel, this always remains as a Trouble on Open.

- **Trouble on Short**: This is a zone programmed to activate a trouble when its loop is shorted and the system is disarmed.
  - If the system is armed, this zone will activate an alarm if shorted or opened.
  - For 24-hour zones, regardless of the arming state of the panel, this always remains as a Trouble on Short.

- **Perimeter Instant**: This is a zone programmed to activate an alarm even during the entry/exit delay period.

- **24-Hour**: This is a zone programmed to activate when its loop is faulted, even if the system is disarmed.

- **Entry/Exit Delay #1:** This is a zone programmed to be ignored during the entry/exit delay period.
  - If it is violated while the system is armed, it will activate a delay for the amount of time programmed for entry delay time #1 (address 0191). The keypad pre-alert sounders will activate and the system may be disarmed during this delay period.
  - If the system is not disarmed during the entry period, this zone will activate an alarm.

- **Entry/Exit Delay #2:** This is a zone programmed to behave identical to the Entry/Exit Delay #1 zone function except that it uses entry delay time #2 (address 0192).

Note: If both entry delays have been activated, the control will use the shorter entry delay.

- **Interior Entry/Exit Follower**: This is a zone programmed to be ignored during an entry/exit delay and then become an interior instant zone.
  - If this zone is violated while the system is armed and no entry/exit zones have been violated, it will activate an alarm.
  - If this zone is violated after an entry/exit delay zone is violated, it will follow that entry/exit delay time.
  - This zone is bypassed by Perimeter Instant or Perimeter arming.

- **Interior Home/Away:** This is a zone programmed to become an interior instant zone if the system is armed and an entry/exit delay zone is violated during the exit delay time.
  - If the system is armed and an entry/exit delay zone is not violated, this zone will be bypassed.
  - This zone is bypassed by Perimeter Instant or Perimeter arming.

- **Interior Instant**: This is a zone programmed to activate an alarm even during the entry/exit delay periods.
  - It is bypassed by Perimeter Instant or Perimeter arming.

- **Day Monitor**: This is a zone programmed to be a perimeter instant zone when the system is armed.
  - When the system is disarmed, any violation of this zone will activate the keypad sounders which will sound continuously until a disarm command sequence is entered.
  - The alarm outputs for this zone will not activate and there will be no report for this zone when the system is disarmed.

- **Keyswitch Input**: This is a zone programmed to allow the system to be armed or disarmed using a Normally Open momentary keyswitch.
  - Outputs for keyswitch LEDs and sounders are available using the programmable outputs or the Octal relay outputs.
  - An output is needed for each LED and sounder.
  - A keyswitch will only control the partition that these zones are assigned to unless programmed as a master, then they will control all at once. See Program Address 0001, Data Digit 1.
  - Keyswitches and keypads may be used in the same partition, if desired.

- **Fire Zone**: This is a zone programmed to activate if the system is armed or disarmed.

 Copyright © 1995-96 Detection Systems, Inc.

- It can be silenced (not reset) by entering a valid [PIN] + [Off].
- The display will indicate a Fire Alarm for this zone on all keypads in every partition.
- A fire reset command must be entered after silencing the alarm to re-enable this zone.
- If this zone is programmed for trouble and the loop opens, the DS7447 keypad will display "Fire Trouble" for this zone and the keypad sounders will beep once every ten seconds.
- If the system is a combination fire and burglar alarm, the fire alarm has priority over the burglar alarm.

• **Fire Zone with Verification**: This zone is identical to a Fire Zone except that after the first alarm, it will perform a fire reset and then wait up to two minutes for a second alarm.
- If a second alarm occurs within this two minute period, the system will indicate a fire alarm.
- If there is no second alarm within this two minute period, the control panel will reset back to its normal condition.

Note: Use of this control's alarm verification feature is not permitted for applications in the state of California.

• **Water Flow Zone**: This is a zone programmed to operate like a Fire Zone, but is specifically intended for water flow switches.
- An optional retard timer can be programmed to compensate for changes in water pressure. If the timer is used, the water flow zone must be activated for the complete time period; an alarm will be initiated at the end of the timer period.
- The maximum combined water flow delay of the control panel and the device must not exceed two minutes.

Note: Any zone can be a water flow zone, but only zones 1 through 4 may be programmed as delayed water flow zones.

• **Supervisory Zone**: This is a zone programmed to accommodate shut-off valves.
- It will indicate a supervisory condition at the keypads when activated.

7.3 Zone Programming

• **Single Zone Input**: This is an individual zone such as the on-board zones and multiplex contact zones.

• **Multiple Zone Input**: This is a zone connected to one of the 8-Input Modules or to a Dual Zone Module.
- The inputs are programmed separately (see the separate Programming Addresses Worksheet, P/N 29802).
- When using the Dual Zone Module, loop A is always programmed as an odd numbered program address (ending in 1, 3, 5, 7, or 9). Loop B is the even numbered program address that follows loop A.

• **DS7465**: This is the input zone or the output relay on a DS7465. The odd numbered zone is programmed for the input zone function and the even numbered zone is programmed for the output function.

7.4 Output Programming

• **Latch on Any Zone Alarm**: This is an output programmed to activate upon any zone alarm (including invisible zones) and will latch until the system has been disarmed.
- If this output responds to a fire zone, it will remain latched until the fire reset command is performed.

• **ON during Entry Pre-Alert**: This is an output programmed to activate when an entry/exit zone is violated while the system is armed.
- It will remain activated until the system is disarmed, or until the entry delay time has expired.

• **ON for 10 seconds** after [PIN] + [System Reset] is entered: This is an output programmed to activate for 10 seconds after the fire reset command is entered at the keypad or if a Fire Zone with Verification activates.
- This output is intended to be used to power 4-wire smoke detectors or any other device that requires a power interruption to reset an alarm condition.

Note: When Programmable Output 2 is programmed this way, it will normally supply auxiliary power and will turn OFF for 10 seconds when the fire reset command is entered.

• **ON when System is Armed**: This is an output programmed to activate when the system is armed.
- It will remain activated until the system is disarmed.

• **Ground Start**: This is an output programmed to activate for 3 seconds when the phone line is seized. It is intended for use with ground start phone systems that require a momentary short to ground to obtain a dial tone.
- Connect a separate 12 VDC, DPDT relay.
- Connect both relay contact commons to ground, and connect the Normally Open of each contact to terminal positions 13 and 16 (one to terminal 13, the other to 16) of the DS7400Xi.
- This output follows all partitions regardless of how data digit 2 of the output programming address is programmed.
- Not intended for U. L. Listed systems. Not for use with phone line monitors.

• **System Status (ready to arm)**: This is an output programmed to follow the Status LED of the keypad.
- It will activate when the system is ready to arm with no zones violated.

• **Zone Alarm**: This is an output programmed to activate when a zone is in an alarm condition.
- It will remain activated until the system is disarmed or the bell cut-off time expires.
- This output is intended to activate alarm bells and sirens.
- This will not activate from Silent or Invisible Zones.

• **Zone Alarm Delayed by 20 sec.**: This is an output programmed to wait 20 seconds after a zone enters an alarm condition to activate.
- It will remain activated until the system is disarmed or the bell cut-off time expires.
- This output is intended to activate alarm bells and sirens, but provides a delay to allow the user to silence the system before it activates.

• **Keypad Sounder Output**: This is an output programmed to follow the keypad sounder.
- It activates during the entry pre-alert and during any day monitor alarm. It does not follow momentary keypad beeps such as keystrokes, chimes, etc.

• **Access Output**: This is an output programmed to activate for 10 seconds when an access control PIN is entered at the keypad.
- Not U. L. Listed for Access Control (UL294).

 Copyright © 1995-96 Detection Systems, Inc.

- **Panic/Duress Output**: All outputs, including the three on-board outputs, the Octal Relays, and the Output Functions, support a Panic/Duress function. To assign an output as a Panic/Duress Output, program the first data digit as "*1". Program data digit two for the appropriate partition(s). This output will follow Duress activations, Keypad Emergency Keys B and C, and Invisible and Silent Zone alarms. It will reset after acknowledged by a user or after the burglary bell time-out expires.

7.5 Partition Control Programming

- **Partition Control Programming**: Up to eight partitions may be used. They are assigned (program address 0165) in order.
  - For example: When using only one partition, it is partition one. When using three partitions, they are partitions one, two, and three.
  - Partitioning allows the system to act as up to 8 different systems.
  - Zones, keypads, outputs, and other items may be assigned to particular partitions.
  - Access to partitions may be through each partition's keypad or through a Master keypad (see the operating section for more details).

- **Common Area**: Partition 1 can be programmed as a common area, that is, common to other partitions. This allows it to be used in an installation with one common entry area such as a foyer or vestibule.
  - When Partition 1 is programmed as a common area, it will only arm when all the partitions it is common to are armed.
  - The common area will disarm when any of the partitions it is common to are disarmed - only if the user has access to the common area.
  - When using a common area, a Master keypad should be used and assigned to the common area (see keypad assignment programming).

7.6 Keypad Assignment Programming

- **Keypad Assignment**: The keypad type and the partition it is assigned to must be programmed.
  - Each program address (0173-0180) programs the keypad type for two keypads. For example: data digit 1 of address 0173 is for keypad 1, data digit 2 of address 0173 is for keypad 2.
  - Each program address (0208-0215) programs the partition assignment for two keypads. For example: data digit 1 of address 0208 is for the partition assignment of keypad 1, data digit 2 of address 0208 is for the partition assignment of keypad 2.
  - Users must have access to the partition the keypad is assigned to in order to use the keypad.

- **Master Keypad Programming** : A Master keypad can be used to access all the partitions.
  - It will display the arm/disarm status of all the partitions and can be used to individually control each partition (see the operating section for an explanation of the keypad displays).
  - A Master keypad can be assigned to any of the partitions.
  - Any number of the 15 allowable keypads can be a Master keypad.
  - When using the common area, it is suggested that a Master keypad be used and that it is assigned to the common area.

7.7 Emergency Key Programming

Note: Do not label these keys if they are unprogrammed. Only the A key may be programmed and labeled as the Fire key.

Note: These keys are not intended to substitute for Listed manual pull boxes.

- **Fire Key**: The emergency key (key A) at the bottom left of the keypad entry area is the Fire Key. If programmed, the key will activate a fire alarm when pressed for 2 seconds.
  - It may be programmed for a steady or pulsed alarm.

Note: The Fire Key will generate the fire alarm sounders in the partition that activated the Fire Key. Any other partitions in use will only have their keypad sounders activated. All keypad displays will be the same.

- **Special Emergency Key**: The emergency key (key B) at the bottom center of the keypad entry area is the Emergency Key.
  - If programmed, the key will activate a supplementary or an auxiliary type alarm when pressed for 2 seconds.
  - It may be programmed for a silent, steady, or pulsed alarm.

- **Panic Key**: The emergency key (key C) at the bottom right of the keypad entry area is the Panic Key.
  - If programmed, the key will activate a panic alarm when pressed for 2 seconds; nothing will display at the keypad to indicate an alarm.
  - It may be programmed for a silent, steady, or pulsed alarm.

Note: The Special Emergency Key and the Panic Key will generate the alarm sounders only in the partition of the keypad that activated that Key.

7.8 Custom Arming Programming

- **Custom Arming - [PIN] + [#] [4]**: If programmed, the [PIN] + [#] + [4] command sequence may be used to custom arm the system by arming only certain zone functions.
  - For example: All interior zones plus some perimeter zones may be bypassed while leaving some of the perimeter armed.

7.9 Force Arming

- **Force Arming**: If programmed, allows violated zones to be force armed. When force arming, the user must enter the usual arming command followed by the [Bypass] key. This automatically bypasses zones that are violated and programmed as bypassable.
  - Fire zones, supervisory zones, keyswitch zones, and non-bypassable zones can not be force armed.
  - Not available in U. L. Listed systems.
  - See Program Address 0185.

7.10 Ground Fault Detect Programming

- **Ground Fault**: If programmed, this function will allow the system to detect ground faults. This function is required for fire panels and will be forced on when the panel is in the commercial fire mode.
  - See Program Address 0185.

7.11 Commercial Fire Mode Programming

Note: In a system that includes both fire alarm and burglar alarm devices, the system must produce distinct sounds for fire and burglar alarm conditions either by using different indicating appliances or by using distinct cadences for the same appliance.

 Copyright © 1995-96 Detection Systems, Inc.

- **Commercial Fire Mode**: When in Commercial Fire Mode, the control panel will perform some functions (e.g. communications) differently to conform with commercial fire regulations.
  - See Commercial Fire Mode Programming, program address 0186.

- **Water Flow Zone Delay**: This is the amount of time a water flow zone must be violated before the control panel will initiate an alarm.
  - The delay is necessary to accommodate normal changes in water pressure.
  - If the water flow initiating device incorporates its own time delay, do not program the control panel unit to exceed 120 seconds combined time delay.

- **Pulsing Fire Zone**: This is a zone programmed to output a pulse for a fire alarm in the normal manner (one second ON, one second OFF).

- **California March Time**: This is a zone programmed to output a pulse for a fire alarm in the California Time cadence (ten 1/2 second pulses, followed by one second of quiet time).

- **Temporal**: This is a zone programmed to output a pulse for a fire alarm in the Temporal cadence (three 1/2 second pulses, followed by one second of quiet time).

- **Single Keypad Use**: The keypad should be used on the keypad bus and be mounted to the front of the control enclosure OR if within the same room as the control equipment with the wire run in conduit (or equivalently protected against mechanical injury) within 20 ft. (6.1 m) of the control equipment.
  - This keypad should be assigned as address 1.

- **Multiple Keypad Use**: <u>One keypad only</u> must be used on the option bus, at any address from 11 - 14, and must meet the following requirements:
  - The keypad must be mounted to the front of the control enclosure OR mounted within the same room as the control equipment and the wire is run in conduit (or equivalently protected against mechanical injury) within 20 ft. (6.1 m) of the control equipment.
  - All other keypads should be connected to the keypad bus and may be placed as needed (within the noted wiring limitations in the installation manual).
  - One keypad must be assigned as address 1.

7.12 Open/Close Report Control Programming

- **Open and Close Reports**: If programmed, these reports are sent when the system is armed or disarmed. They may be sent independently for the opening and closing of each partition, or the first partition to open and the last partition to close may send the reports.

- **Send Trouble at Close for Bypassed Zones**: If programmed, a trouble report will be sent for each zone bypassed when the system is armed.

- **Alternate between both Phone Numbers**: If programmed, open and close reports will be sent to phone number one first. If phone number one does not pick-up, the control panel will alternate to phone number two. If phone number two does not pick-up, the control panel will alternate back to phone number one. It will alternate between both phone numbers until successful.

7.13 Report Programming

- **Reports**: For pulse formats, reports are programmed by entering data in the reporting and extended digits. The report will send the data programmed for each event. For SIA and Contact ID, the report formats are fixed and may be activated by placing a 1 in the reporting digit.
  - To disable a report, enter a 0 in the reporting digit.
  - To send the Man No. along with Open and Close reports, program an "F" (enter [*] [5] at the keypad) in the extended digit.

- **Keypad Fire Alarm**: This report is sent when a fire alarm has been activated by the “A” emergency key.

- **Keypad Fire Restoral**: This report is sent when a keypad fire alarm has been restored using the [System Reset] command.

- **Zone Function Alarm**: An alarm report is sent when a zone alarm occurs. Alarm reports are enabled by zone function. Program this report for any zone functions you wish to send an alarm report about. For local zones (no reports), do not program an alarm report. The zone number will automatically be sent for this report in SIA or Contact ID format.

- **Keypad Emergency Alarm**: This report is sent when an emergency alarm has been activated using the “B” emergency key.

- **Keypad Panic**: This report is sent when an emergency alarm has been activated using the “C” emergency key.

- **Zone Function Restoral**: This report is sent when the zone alarm and trouble conditions are cleared. The zone number will automatically be sent for this report in SIA or Contact ID format.

- **Zone Function Trouble**: This report is sent when a zone trouble condition occurs. This can be an open circuit, if the zone is programmed for “trouble on open”, a multiplex tamper switch being activated, or a multiplex zone not communicating with the control panel. The zone number will automatically be sent for this report in SIA or Contact ID format.

- **Open**: This report is sent when the system has been disarmed. In SIA or Contact ID formats, the user number for the person who disarmed the system will be sent with this report. To send the user number along with an Open report in other formats, program the extended digit of the report as *5. In Contact ID format, the partition number will also be sent along with this report. The Open report will only be sent if a Close report was sent previously.

- **Close**: This report is sent when the system has been armed. In SIA or Contact ID formats, the user number for the person who armed the system will be sent with this report. To send the user number along with a Close report in other formats, program the extended digit of the report as *5. In Contact ID format, the partition number will also be sent along with this report.

- **Duress**: This report is sent when the system is disarmed using a duress code. The user number will not be sent along with this report.

- **Partial Close**: This report is sent when the system is armed partially, or force armed.

- **First Open After Alarm**: This report is sent when the system is disarmed after an alarm has occurred. It will also be sent if the system is already disarmed and a user number is entered to si-

 Copyright © 1995-96 Detection Systems, Inc.

lence a 24-hour or fire zone.

- **Low Battery**: This report is sent when a low battery condition occurs.
- **Battery Restoral**: This report is sent when a low battery condition restores.
- **AC Fail**: This report is sent when an AC failure condition occurs. This report may be delayed in address 0197.
- **AC Restoral**: This report is sent when an AC failure condition restores.
- **Communicator Test/System Normal**: This report is sent at the 24-hour check-in time if there is not a control trouble, an active fire alarm that has not been acknowledged, a fire trouble, or a supervisory condition. Note: To send a Communicator Test even if one of these conditions exists, program the Communicator Test/ System Off Normal.
- **Remote Program Successful**: This report is sent after a Remote Program session, if the session was terminated properly.
- **Remote Program Unsuccessful**: This report is sent after a Remote Program session, if some error has occurred or the session did not terminate properly.
- **Local Program Successful**: This report is sent when local programmer's mode is exited and there is no error associated with the programming.
- **Local Program Unsuccessful**: This report is sent when local programmer's mode is exited and there has been some error associated with the programming.
- **System Trouble**: This report is sent when a control trouble condition occurs.
- **System Trouble Restoral**: This report is sent when all system trouble conditions restore.
- **Communicator Test/System Off Normal**: This report is sent at the 24-hour check-in time if there is a control trouble, an active fire alarm that has not been acknowledged, a fire trouble, or a supervisory condition.
- **Exit Error**: This report is sent if an exit error occurs. An exit error occurs when an entry/exit zone is still violated at the end of the exit delay. If this happens, the entry delay will begin. If the system is not disarmed before the entry delay expires, an alarm report for the effected zone will be sent and the Exit Error report will be sent. If this report is not programmed, the control will not sound the exit error warning.
- **Recent Closing**: This report is sent, along with any alarm reports, when there is an alarm within the first five minutes after the system has been armed.
- **System Test**: This report is sent when a system test has been started (#81 key sequence). Zone reports are not sent during a system test.
- **System Test Restoral**: This report is sent when the system test has been completed or has timed-out.

7.14 Phone Number General Control Programming

- **Enable Remote Programmer Callback**: If programmed, when the remote programmer tries to initiate a session with the panel, the panel will hang up and call the remote programmer phone number.
  - This ensures the correct remote programmer is initiating the call.
- **Dial Pulse on all Phone Numbers**: If programmed, the panel will dial phone number 1, 2, and the remote programmer phone number 3 using the pulse format.
- **Dial Tone on all Phone Numbers**: If programmed, the panel will dial phone number 1, 2, and the remote programmer phone number 3 using the tone format.

7.15 Phone Answering Programming

- **Answering Machine Bypass**: This feature allows the panel to answer incoming calls when answering machines are used. If the line rings, stops ringing, then rings again within one minute, the panel will seize the phone line on the first ring.
- **Phone Answering Programming**: The panel can be programmed to answer the phone after a selected number of rings for remote programming access. It can also be programmed to answer the phone after a different number of rings when in armed or disarmed states.
  - This can be used to call the panel location and determine its arming state.

7.16 FCC Compliance Notice

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

7.17 FCC Phone Connection Notice To Users

This control complies with Part 68 of the FCC rules.

On the inside of the enclosure is a label that contains, among other information, the FCC Registration Number and the Ringer Equivalence Number (REN) for this equipment. You must, upon request,

 Copyright © 1995-96 Detection Systems, Inc.

provide this information to your local telephone company.
The REN is useful to determine the quantity of devices that may be connected to your telephone line and still have all of those devices ring when your telephone number is called. In most, but not all areas, the sum of the REN's of all devices connected to one line should not exceed five (5.0). To be certain of the number of devices that you may connect to your line, you may want to contact your local telephone company to determine the max. REN for your local calling area.

This equipment may not be used on coin service provided by the telephone company. This control should not be connected to party lines.

Should this equipment cause harm to the telephone network, the telephone company may discontinue your service temporarily. If possible, they will notify you in advance. But if advanced notice isn't practical, you will be notified as soon as possible. You will be informed of your right to file a complaint with the FCC. The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the proper functioning of your equipment. If they do, you will be notified in advance to give you an opportunity to maintain uninterrupted telephone service.

If you experience trouble with this equipment, please contact the manufacturer for information on obtaining service or repairs.

The telephone company may ask that you disconnect this equipment from the network until the problem has been corrected or until you are sure that the equipment is not malfunctioning. The repairs to this equipment must be made by the manufacturer and not the user.

To guard against accidental disconnection, there is ample room to mount the Telco jack to the inside of the Control cabinet.

The operation of this Control may also be affected if events such as accidents or acts of God cause an interruption in telephone service.

7.18 Canadian Dept. of Communications

General Installation Requirements: Notice: The Canadian Department of Communications label identifies certified equipment. This certification means that the equipment meets certain telecommunications network, protective, operational, and safety requirements. The Department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.
Users should ensure, for their own protection, that the electrical ground connections of the power utility, telephone lines, and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

Terminal Requirements: The Load Number (LN) assigned to each terminal device denotes the percentage of the total load to be connected to a telephone loop which is used by the device, to prevent overloading. The termination on a loop may consist of any combination of devices subject only to the requirement that the total of the Load Numbers of all the devices does not exceed 100. The Load Number of the DS7400Xi is 2.

RFI Requirements: This Class A digital apparatus meets all requirements of the Canadian Interference- Causing Equipment Regulations. [Cet appareil numerique de la classe A respecte toutes les exigences du Reglement sur le material broilleur du Canada.]

7.19 For Installations in New Zealand

Two-wire Connection:
The operation of this equipment on the same line as telephones or other equipment with audible warning devices or automatic ring detectors will give rise to bell tinkle or noise and may cause false tripping of the ring detector. Should such problems occur, the user is not to contact Telecom Faults Service.

 Copyright © 1995-96 Detection Systems, Inc.

8.0 Operating Guide

8.1 Personal Identification Numbers

8.1.1 General Information

When programming Personal Identification Numbers, it is helpful to know the following terms:

- **PIN:** Personal Identification Number. This is the 4 digit code users must enter at the keypad to gain access to the system. A PIN may be assigned to each User Number 001 through 090.

- **User Number:** This is the number that identifies each person using the system. There are 90 possible User Numbers available for use (001 through 090)

.

- **Authority Level:** This number determines which functions each user will be able to perform.

Your system has the capability to assign up to 90 PINs, each four digits long. Each User Number can have only one PIN assigned to it. Attempting to assign the same PIN to multiple User Numbers will result in the three-beep error tone, and the entry will not be made.

User Number 001 is designated as a Master code. It can be used to add, delete, or change other PINs. It will always have access to all partitions regardless of how it is programmed.

User Number 001 is shipped from the factory with the PIN of 1 2 3 4. This PIN should be changed to one of your personal preference and must be programmed as a Master code.

PINs should never be programmed with common sequences such as 1 2 3 4, 1 1 1 1, or 2 4 6 8 because they are easily violated.

8.1.2 Removing a PIN

To disable (remove) a PIN, enter:
- A Master code, followed by [#] [0].
- [0]
- User number of the PIN to be cancelled, followed by [#]

User Number 001 can not be disabled in this manner.

8.1.3 Authority Levels

0 = **Master:** Can enter all commands, add or change PINs in all partitions, change time and date, bypass, arm, disarm, perform system tests, system reset, and view history. Any or all PINs can behave as a Master code.

1 = **Unlimited:** Can enter all commands, bypass, arm, disarm, system reset, and perform system tests. Can not change PINs.

2 = **General:** Can bypass, arm, and disarm. Can not change PINs, system reset, or enter Command 7 or any of the Command 8 functions. Bypass and disarm are programmable by partition.

3 = **Arm Only:** Can arm the system with [On] arming only. Can not perform any other functions including disarming.

4 = **Temporary:** Valid only for a specified time (PIN will disappear upon expiration date). Can arm and disarm the system, but can not perform any other functions. If this function is performed from a Master Keypad, you must be in Single Partition Mode.

5 = **Duress:** When the system is disarmed using the duress PIN, a silent report is sent to the central station. The Duress PIN is intended to be used when the user is forced to disarm the system.

6 = **Access:** When a PIN with an Access code is entered, any output programmed for Access Output (e.g. door strikes) will pulse on for 10 seconds (works when the system is armed or disarmed).

This chart will guide you through the steps necessary to change a PIN.

It is recommended that this procedure be performed at a DS7447 keypad. No visual cues will be given from a DS7445 keypad.

Steps to Change a PIN	Command Sequence	If Accepted, the Display Reads
# 1. Enter the Master Code Programming Mode.	[Master Code] + [#] [0]	"0 User Change" (display will scroll to this)
# 2. Enter a 0.	[0]	"Enter User No." (001..0XX)
# 3. Enter the User Number.	[0] [0] [1] through [0] [9] [0]	"Enter Authority Level" Level (0-6)
# 4. Enter the Authority Level.	[0] through [6]	"Enter Area(s) or # for all"
# 5. Enter the Area(s) (partition(s)) this user has access to.	[1], [2], [3], [4], [5], [6], [7], and/or [8] then [#]	"Enter Next Area, End with #" or "Enter PIN"
# 6. Enter the PIN.	Any 4 digits. Do not press [#].	"Enter PIN Again. End with #" A long beep will sound to signify acceptance of the new PIN.
# 7. Enter the PIN again followed by the [#] key.	PIN (same 4 digits as above), then [#].	

Copyright © 1995-96 Detection Systems, Inc.

8.2 Arming/Disarming Commands

For commands to Arm, Disarm, Bypass or set chime mode, see the front cover of this Reference Guide or consult the DS7400Xi Ver. 3+ Users Guide.

8.3 Changing the Date

This chart explains the procedure for changing the date at the keypad.

It is recommended that this procedure be performed at a DS7447 keypad. No visual cues will be given from a DS7445 keypad.

Steps to Change the Date	Command Sequence	If Accepted, the Display Reads
# 1. Enter the Master Code Programming Mode.	[Master Code] + [#] [0]	"2 Change Date" (display will scroll to this)
# 2. Enter a 2.	[2]	"Enter Month" (01...12)
# 3. Enter the Month.	[0] [1] through [1] [2] January December	"Enter Day." (01...31)
# 4. Enter the Day.	[0] [1] through [3] [1]	"Enter Year." (XX) End with #
# 5. Enter the Year.	The last two digits of the year, followed by the [#] key.	"Month, Day, Year" A long beep signifies acceptance.

Note: Entering the command sequence [Master Code] [#] [0] [2] [#] will cause the DS7447 keypad to read back the date.

The control panel will exit you from the master code programming mode after about 15 seconds without a keystroke.

8.4 Changing the Tempoary PIN Expiration Date

This chart explains the procedure for changing the expiration date (for temporary PINs) at the keypad.

It is recommended that this procedure be performed at a DS7447 keypad. No visual cues will be given from a DS7445 keypad.

Steps to Change the Exp. Date for Temp. PINs	Command Sequence	If Accepted, the Display Reads
# 1. Enter the Master Code Programming Mode.	[Master Code] + [#] [0]	"3 Change Date of Code Expiration"* (display will scroll to this)
# 2. Enter a 3.	[3]	"Enter Month" (01...12)
# 3. Enter the expiration Month.	[0] [1] through [1] [2] January December	"Enter Day." (01...31)
# 4. Enter the expiration Day. *The temporary PIN will expire at Midnight on the day selected.*	[0] [1] through [3] [1]	"Enter Year." (XX) End with #
# 5. Enter the expiration Year.	The last two digits of the year, followed by the [#] key.	"Month, Day, Year" A long beep signifies acceptance.

* = This will only display when in Single Partition Mode.

Note:Entering the command sequence [Master Code] [#] [0] [3] [#] will cause the DS7447 keypad to read back the temporary code expiration date.

The control panel will exit you from the master code programming mode after about 15 seconds without a keystroke.

 Copyright © 1995-96 Detection Systems, Inc.

8.5 Changing the Time

This chart explains the procedure for changing the time at the keypad.

It is recommended that this procedure be performed at a DS7447 keypad. No visual cues will be given from a DS7445 keypad.

Steps to Change the Time	Command Sequence	If Accepted, the Display Reads
# 1. Enter the Master Code Programming Mode.	[Master Code] + [#] [0]	"6 Change Time"* (display will scroll to this)
# 2. Enter a 6.	[6]	“Enter Day" (1...7)
# 3. Enter the day.	[1] through [7] Sunday Saturday	"Enter Time." (0100...1259)
# 4. Enter the Time. (Hour and minute)	[0] [1] [0] [0] through [1] [2] [5] [9]	"Enter AM/PM.” (4/6) End with #
# 5. Enter AM or PM.	[4] [#] or [6] [#] (4=AM, 6=PM)	“Day - Time” A long beep signifies acceptance.

* = This will only display when in Single Partition Mode.

Note: Entering the command sequence [Master Code] [#] [0] [6] [#] will cause the DS7447 keypad to read back the time.

The control panel will exit you from the master code programming mode after about 15 seconds without a keystroke.

8.6 Delayed Arming

This section explains how to cause the system to arm after a specified number of hours.

Delayed arming is simply causing the system to arm after a specified number of hours.

To program the system for delayed arming, perform the following steps:

Delayed Automatic Arming	Notes
Enter a PIN	
Enter [9] [9] to enter the Delayed Arming programming	
The keypad will display the following: Arm in nn Hours # to accept	Enter the number of hours from now that you would like the system to arm. For example: If if is 3:30 now, and you would like the system to arm at 9:30, enter 06.

Additional Notes:

Delayed arming can be used even if there are no automatic arming times programmed.

If delayed arming is used in Master Keypad mode, it will affect all partitions you have access to. If delayed arming is used in single partition mode, or from a single partition keypad, it will affect only the partition you are working in.

Delayed arming will override automatic arming.

Delayed arming will also provide a 15 minute pre-arm period like the one provided with automatic arming.

 Copyright © 1995-96 Detection Systems, Inc.

8.7 Automatic Arming

Each partition can be programmed to automatically arm once per day.

To inform occupants that the system is about to arm, a pre-arming period will begin 15 minutes before the system arms automatically. The keypad sounders, and any outputs programmed to follow the keypad sounders, will pulse five times every minute. During the last five minutes before arming, these sounders will be on steady. Once per minute the keypad will read, “Arm in nn min./PIN + OFF - extend.”

If automatic arming is used in Master Keypad mode, it will affect all partitions you have access to. If used in single partition mode, or from a single partition keypad, it will affect only the partition you are working in.

To extend the Automatic Arming of the system during the automatic arming pre-arming period 15 minutes, enter a valid user code plus OFF [PIN] + [OFF]. For a longer delay, perform the following steps:

Delayed Automatic Arming	Notes
Enter a PIN	
Enter [9] [9] to enter the Delayed Arming programming	
The keypad will display the following: Arm in nn Hours # to accept	Enter the number of hours from now that you would like the system to arm. For example: If if is 3:30 now, and you would like the system to arm at 9:30, enter 06.

* = To extend the Automatic Arming at any time, use the Delayed Arming feature (see section 8.6).

To program the Automatic Arming Time, perform the following steps:

Setting the Automatic Arming Time	Notes
Enter a Master PIN + [#] + [0]	Setting the Automatic Arming Time can only be performed in the Master Programming Mode.
Enter a [1] to enter the Automatic Arm Setup programming	
Enter the partition number. Press [#] to exit.	If programming is done from a Master Keypad that is not in single partition mode, the user will be prompted to enter the partition they wish to program. The user will only be allowed to program the partitions to which they are assigned. If programming from a standard keypad, or from a Master Keypad in single partition mode, this step will be skipped.
Enter a time for each day. Enter in [0] [1] [0] [0] [#] format.	The display will start with Sunday. It will read, “Sunday - nn : nn” Enter the time in 24 hour format then press the [#] key. If you make a mistake, press the [*] key twice to move back to your last entry. Samples of times: 12 noon = 1200# / 12 midnight = 2400# 12:01am = 0001# / 12:01pm = 1201# 1:00am = 0100# / 1:00pm = 1300# Disabled = 0000#

 Copyright © 1995-96 Detection Systems, Inc.

8.8 Turning OFF the System under Duress

This chart explains the proper procedure for disarming under Duress.

Ask your installer if the Duress feature has been activated.

A Duress code is used when someone demands, by threatening your life or well-being, that the system be turned off. When used, the code will both turn off the system and report a silent Duress alarm if connected to a monitoring service.

Extreme care should be used when entering your PIN to turn off the system, so a Duress code is not inadvertently entered.

Type of Disarming	Command Sequence	What will Happen
Disarming System under Duress	Duress Code + [Off]	System will appear to disarm normally. A Duress code will be sent to the central station.

8.9 Emergency Procedures

8.9.1 Identifying Alarm Sounds

Your alarm system may be programmed for a steady alarm sound or a pulsed alarm sound. It is important to learn the difference between a fire alarm sound and an intrusion alarm sound before you are confronted with an actual emergency.

8.9.2 Silencing Alarms

All alarms can be silenced with any PIN that has disarm privileges. Entering your PIN+ [Off] will silence the alarm and turn off (disarm) the control.

8.9.3 A Cautionary Note

How you respond to an alarm will depend, mostly, on the type and time of the alarm. You should seek the advice of your installing company as they install your system, not later (e.g. after an alarm) to develop a response plan.

8.9.4 Use Common Sense

Above all else, common sense should prevail. If there is any threat or hint of danger to yourself or others on the premises, such as in the event of a fire alarm, everyone should be instructed to leave the premises immediately. Do not enter the premises unless accompanied by the appropriate Emergency Services' personnel, or after they have given the OK to enter.

8.9.5 Caution When Entering A Building

If the bells and sirens are on and/or the red Armed Light is flashing with the DS7447 display reading "Zone Alarm" or the DS7445 having its zone LEDs flashing, then the keypad is signaling that an alarm has occurred. The keypad will also issue a pulsed tone during the entry delay instead of the usual steady tone.

If the alarm has not been previously investigated, do not enter the building unless accompanied by the appropriate Emergency Services' personnel.

8.9.6 Fire Alarms

Fire Alarms are silenced using the same procedure as intrusion alarms: a PIN (with disarm privileges) + the [Off] key.

The Fire Alarm system is not reset until alarms at smoke detectors are cleared by using the [System Reset] command. The Fire Alarm system will not be functional until this procedure has been followed. See the "Fire Reset" section, 8.10.1.

8.10 Fire Reset/Fire Trouble

8.10.1 Fire Reset

During a fire alarm, exit the premises immediately. When you have determined there is no fire, you must silence the bells/sirens before you can initiate the [System Reset]
command: PIN + [System Reset].
Before the [System Reset] command is used, determine which smoke detector has alarmed so the monitoring company may verify its operation.
A PIN followed by the [System Reset] key will reset any smoke detectors after a fire alarm has occurred.
Note: To use the System Reset command sequence, your PIN must have disarm privileges.
The System Reset command will perform a fire reset, will perform a battery test, and will clear all system troubles.
Note: If the System Reset command has not been performed after 24 hours of the Fire Alarm, the keypad will sound and it will display "Fire Alarm Not Reset." If the sounders have been silenced and the system has been reset properly, this warning will not occur.

8.10.2 Fire Trouble

A Fire Trouble message with a zone number signifies a problem with the fire system, such as a break in the wiring that monitors smoke detectors. A Fire Trouble message with no zone number indicates a ground fault if the unit is in the commercial fire mode.

A Fire Trouble will be indicated by a short beep from the keypad sounders every 10 seconds. The DS7447 will display "Fire Trouble" followed by the zones in a trouble condition. The DS7445 will turn the Fire and Trouble Lights on steady and will light the corresponding zone LEDs.

Notify your installing company immediately if the Fire Trouble message is displayed.

The Fire Trouble beep can be silenced with any PIN followed by the [Off] key. After problems have been remedied, a PIN followed by the [Off] key should again be entered to clear the "Fire Trouble" display.

Copyright © 1995-96 Detection Systems, Inc.

8.11 Emergency Keypad Alarms



The Emergency Alarm Keys [A], [B], and [C] may generate Fire, Special Emergency, and Panic Alarms if programmed by the installer. Ask your installing company to explain the function of these keys.

When using the Emergency Keys, they must be pressed for two seconds to generate an alarm.

Note: If the Emergency Alarm Keys are to be used, they should be labeled to signify their functions.
The A key should be labeled as the Fire key. This is the only key that may be designated as the Fire key.
The B key should be labeled as the Special Emergency key.
The C key should be labeled as the Panic key.

Use the Disarming Command Sequence to cancel or silence these alarms.

8.12 Fire Safety

WARNING: No fire detection device or system should be considered 100% foolproof.

This fire alarm system can provide early warning of a developing fire. Such a system, however, does not ensure protection against property damage or loss of life resulting from a fire. Any fire alarm system may fail to warn for any number of reasons (e.g. smoke not reaching a detector that is behind a closed door).
When considering detectors for residential applications, refer to NFPA Standard 72, "The National Fire Alarm Code." This standard is available at a nominal cost from: The National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

8.12.1 If Installed in Family Residences

Adherence to the NFPA Standard 72 can lead to reasonable fire safety when the following items are practiced:

- Minimize hazards: Avoid the three traditional fire killers: smoking in bed, leaving children home alone, and cleaning with flammable liquids.

- Providing a fire warning system: Most fire deaths occur in the home, the majority, during sleeping hours. The minimum level of protection requires smoke detectors to be installed outside of each separate sleeping area and on each additional story of the dwelling.

For added early warning protection, it is recommended that detectors be installed in all separated areas including the basement, bedrooms, dining room, utility room, furnace room, and hallways.

8.12.2 Having and Practicing an Escape Plan

A fire warning may be wasted unless the family has planned in advance for a rapid and safe exit from the building.

- Draw a floor plan of the entire house showing two exits from each bedroom and two from the house. Since stairwells and hallways may be blocked during a fire, the plan should provide exits from bedroom windows.

Make copies of the plan and practice it with all family members.

- Pre-arrange a meeting place outside and away from the residence. Once out of the building, all occupants should immediately go to the pre-selected location to be accounted for.

- Provide a barricade between family members and fire, smoke, and toxic gases (e.g. close all bedroom doors before retiring).

- Children should be instructed on opening their bedroom windows and exiting safely from the building. If exiting is not possible, they should be taught to stay at the open window and shout for help until it arrives.

- In the event of a fire alarm after retiring, wake the children by shouting to them from behind your closed door. Tell them to keep their bedroom doors closed.

- If the top of your bedroom door is uncomfortably hot, do not open it. There is most likely fire, intolerable heat, or smoke on the other side. Shout to all family members to keep their bedroom doors closed and to exit the building via alternate routes.

- If the top of the door is not uncomfortably hot, brace the bottom of the door with your foot, and the top with one hand, then open the door about one inch. Be prepared to slam the door shut if there is any pressure against the door or if any hot air rushes in.

- If there is no evidence of excessive heat or pressure, leave the room and close the door behind you. Shout appropriate instructions to all family members and immediately leave the building via the pre-planned routes. If heavy smoke is present, drop to your hands and knees, or crawl to remain below the smoke level.

 Copyright © 1995-96 Detection Systems, Inc.

8.12.3 Installation Considerations

Proper location of detection devices is one of the most critical factors in a fire alarm system.

The following are some general considerations:



A smoke detector should be located on each story including basements, but excluding crawl spaces and unfinished attics.



Locate smoke detectors between sleeping areas and family living areas.

- Smoke detectors should not be installed in "dead air" spaces or close to ventilating or air conditioning outlets because smoke may be circulated away from the detector. Locations near air inlets should be favored.
- Avoid areas subject to normal smoke concentrations such as kitchens, garages, or near fireplaces.
- Do not install smoke detectors where normal area temperatures are above 100 degrees F (38 degrees C) or below 32 degrees F (0 degrees C).
- Areas of high humidity and dust concentrations should be avoided.
- The edge of ceiling mounted detectors should be no closer than 4 inches (10 cm) from any wall.
- Place the top edge of wall mounted detectors between 4 and 12 inches (10 to 30 cm) from the ceiling.

8.13 Testing

8.13.1 Zone Test

The Zone Test is used to confirm that detectors will report alarms. Zone Test works on all zones, except 24-hour zones and fire zones. While the keypad is in Zone Test, no reports will be sent and no control panel alarms will activate an alarm, except 24-hour zone alarms and fire alarms. These will override the Zone Test function.

Type of Test	Command Sequence	What will Happen	What to Do
Zone Test	PIN + [#] [8] [1]	DS7447: **"Test Zone"** will display followed by the zone number of any zones that have not been tested. DS7445: The Zone LEDs will flash for any zones that have not been tested. DS7447: **"Now Testing"** will be displayed followed by the zone number of the zone that is currently being violated (being tested). It returns to **"Test Zone"** after the violation. DS7445: The Zone LED will turn on steady for the zone that is currently being violated (tested).	Test each detector one at a time as instructed by the installing company. To exit the Zone Test mode, enter your PIN + the [#] key.

Note: This test can not be performed from a Master Keypad.

8.13.2 Battery/Sounder Test

If a power failure occurs, your control panel has a built-in battery that will continue to power the control panel for several hours. The control panel automatically recharges the battery when power is restored. In addition to an automatic battery test performed every 4 hours, the battery may also be tested manually. This test also uses the battery to manually activate all the system sounders for 2 seconds (# 8 5 only). If the battery voltage is low, a battery fault will occur (see Error Display).

Type of Test	Command Sequence	What will Happen	What to Do
Local Battery/ Sounder Test *	PIN + [#] [8] [5]	• All keypad Lights will turn on. • The keypad sounder and all alarm sounding devices will operate for 2 seconds.	If test fails, the control will indicate a Control Problem. See Error displays, section 9.20. If power in your building has been off recently, wait 2 hours for the battery to recharge and then try again.
Battery Test	PIN + [System Reset]	• The control will perform a Battery Test. • The control will report a Low Battery or a Low Battery Restoral if necessary.	

*** = Note**: If this test is performed from a Master Keypad, it must be in Single Partition Mode.

Copyright © 1995-96 Detection Systems, Inc.

8.13.3 Communicator Test

This test is available only if your system transmits alarms and system information to a monitoring service, and has been programmed by the security installing company to permit communicator tests. A long beep will initially sound to acknowledge the start of the test. If the test is successful, the sounder will again issue one long beep. If the test fails, the keypad sounder will turn ON continuously. To silence the sounder, enter you PIN followed by the [#] key or press the [*] key.

Type of Test	Command Sequence	What will Happen	What to Do
Communicator Test Requires addresses 0329, 0504, 0529, and 1521 to be programmed.	PIN + [#] [8] [2]	• A long beep will sound. • A "Test" report is sent to the monitoring service.	If test fails, the keypad sounder will sound continuously. To silence the sounder, press the [System Reset] key. **Note:** This test may take several minutes to complete as the control will try 10 attempts (not programmable) before it fails this test.

8.13.4 Event History Readback

The History Buffer stores the last 400 events in memory, the last 100 in non-volitile memory (will be kept even if total power loss). The DS7447 can display all of these events. The DS7445 will only display those zones that have alarmed since the last Event History Read-back.

Type of Test	Command Sequence	What will Happen	What to Do
Event History Readback *	PIN + [#] [8] [9]	DS7447: The last event to take place will be displayed. DS7445: The zone LEDs will flash for any zones that have alarmed since the last Event History Readback done on a DS7445 keypad in that partition. For System Fault displays, see section 9.20.	DS7447: Scroll through the events by using the [9], [6], and [#] keys. See below. To exit from the Event History Mode, press the [*] key.

*** = Note**: If this is performed from a Master Keypad, it must be in Single Partition Mode.

DS7447 Only: Scrolling through the History Events.
To begin scrolling back through the events, press the [#] key. The [#] key will scroll you back through the history line by line. The [9] key will scroll you back in reverse chronological order by event. The [6] key will scroll you back up through the events (toward the most recent) by event.
Each event consists of two or three lines or display screens. The first line/screen will be the event title and user. The second line/screen will be the date of the event or the change being made. If there is a third line/screen, it will be the date of the change.
To exit the Event History Mode, press the [*] key or wait 20 seconds and the keypad will exit automatically.
When performing this from a Master Keypad, each partition will display its own history.

8.13.5 Remote Program Dial-out and Answer

Type of Function	Command Sequence	What will Happen
Remote Program Dial-out*	PIN + [#] [8] [3]	The panel will call the remote programmer.
Remote Program Answer	PIN + [#] [8] [6]	The panel will answer a call from the remote programmer.

* = Phone numbers 1 and 3 must be programmed and an Account Code must be programmed.

 Copyright © 1995-96 Detection Systems, Inc.

8.13.6 Error Displays

This chart explains the procedure for reading Error displays when the green Power Light is flashing on the keypad.

Control panel problems are indicated by a flashing green Power Light. The DS7447 display will also read **"Control Trouble, Enter #87."** The DS7445 will only flash the green Power Light.

The Error displays may only be read when the control is disarmed. Contact your installing company if the problems persist.

1. DS7447 - "**AC Power Failure"** / DS7445 - LED 1 turns on steady**:** There is a power failure and the panel is operating on backup battery.
2. DS7447 - "**Battery Trouble"** / DS7445 - LED 2 turns on steady**:** If the system has just been through a power failure, wait at least two hours for the battery to recharge, then enter a PIN + [System Reset] to perform a battery test.
3. DS7447 - "**Communicator Err"** / DS7445 - LED 3 turns on steady**:** The communicator failed to communicate with the central station.
4. DS7447 - "**System Fault"** / DS7445 - LED 4 turns on steady**:** Internal error in the control circuitry or optional circuitry. These faults are designated as follows:
5. DS7447 - "**Keypad Fault"** / DS7445 - LED 5 turns on steady**:** One of the keypads is not responding to the control panel.
6. DS7447 - "**Multiplex Bus"** / DS7445 - LED 7 turns on steady**:** The multiplex bus is defective or has been shorted.
7. DS7447 - "**Aux Power Fault"** / DS7445 - LED 8 turns on steady**:** The auxiliary power has been shorted.
8. DS7447 - "**Zone Trouble":** One of the zones is not responding to the control panel. This may also be displayed during power-up (if so, ignore).

#87 will display	#89 will display
RAM Fault	System fault 01
ROM Fault	System fault 02
EEPROM Fault	System fault 03
Ground Fault	System fault 04
2Ph/Bell Fault = loss of communication to DS7420i	System fault 10
Line 1 Fault = DS7420i phone line 1 fault	System fault 11
Line 2 Fault = DS7420i phone line 2 fault	System fault 12
Bell Fault = DS7420i bell circuit fault	System fault 13
Aux. Relay Fault = DS7420i aux. relay fault	System fault 14
Oct. Relay Fault = loss of communication to DS7488	System fault 20
Reserved for older panels	System fault 50
AR IB Queue Full = modem buffer full	System fault 51
AR Host Down = network data switch down	System fault 52
AR Unreg. Modem = modem not registered	System fault 53
AR Power Fail = power source below defined threshold	System fault 54
AR Network Lost = loss of network	System fault 55
AR Modem HW Err = modem hardware error	System fault 56
AR Modem SW Err = modem software error	System fault 57
AR Opt. Bus Err = loss of communication to ARDIS module	System fault 58
AR Corrupt MSG = message error	System fault 59

Note: System Faults may be read from any keypad because they are system-wide.

All other Error Displays are limited to the partition the Standard keypad is in. If you are on a Master keypad, you may read Error Displays one partition at a time.

Action Desired	Command Sequence
Read Error display when green Power light is flashing.	PIN + [#] [8] [7]
Clear Error Display* **Caution:** Clear the error display only on the advice of your installing company or if you are certain the problem has been remedied.	PIN + [System Reset]

* = **Battery Trouble** display will only clear by the [System Reset] command or another automatic battery test even after the problem has been remedied. **Comm Error** display willonly clear by the [System Reset] command or the next successful automatic system off normal report even after the problem has been remedied. All the other error displays will self clear from the keypads once the problem has been remedied.

 Copyright © 1995-96 Detection Systems, Inc.

9.0 The Master Keypad

Your system may include a Master keypad.

A Master keypad is a DS7447 keypad programmed to give a user access to all the partitions he has access to, not just the partition the Master keypad is in. This is different from a Standard keypad, in that Standard keypads only give access to the single partition they are in. Commands entered at the Master keypad will affect all the partitions the user has access to. If this is not desirable, the Master keypad can be used to control partitions individually; this is called Single Partition Mode. Single Partition Mode allows a user to control the partitions he has access to on an individual (one by one) basis (see section 11.4 for more information on Single Partition Mode).

9.1 Master Keypad Displays

Master keypad displays will differ slightly from Standard keypads.

The Master keypad display will scroll the Status of each partition, followed by the partition number.
For example, if all partitions are armed, the Master keypad will scroll through the following displays:

Armed area 1	**Armed area 2**	**Armed area 3**	**Armed area 4**	**Armed area 5**	**Armed area 6**	**Armed area 7**	**Armed area 8**

If only partitions 1, 2, 3, 4, 6, and 8 are armed, the Master keypad will scroll through the following displays:

Armed area 1	**Armed area 2**	**Armed area 3**	**Armed area 4**	**Ready to Arm area 5**	**Armed area 6**	**Ready to Arm area 7**	**Armed area 8**

Displays for partitions that are Not Ready will display in the same manner.

Light	Off	Flashing	On
Armed (red)	All partitions are disarmed.	One or more partitions are armed, or an alarm has occurred.	All partitions are armed, and no alarms have occurred.
Status (green)	Not ready to arm (if the Armed Light is on, all partitions are armed).	One or more zones are bypassed.	All partitions are ready to arm.
Power (green)	The control panel has lost all power; no AC or battery.	Control panel problems exist. See *Error Displays.*	Normal Operation. The control panel is running on AC power with no problems.
Fire (red)	There are no fire alarms.	A fire zone is in alarm.	A fire trouble condition exists.

9.2 Arming from the Master Keypad

Arming from the Master Keypad	
Arming all the Partitions you have access to.	Enter your PIN followed by one of the arming sequences. This will arm all of your partitions, even if some are already armed.
Arming only some of your Partitions	You must enter Single Partition Mode to arm the necessary partitions one at a time. 1. Enter your PIN, followed by the [#] key twice: [1] [2] [3] [4] [#] [#]. 2. The first partition you have access to will be displayed: "**Ready to Arm. Cafeteria**." 3. Complete the arming command sequence you wish for this partition: [On]. 4. Move to the next partition you have access to by pressing the [#] key twice: [#] [#]. 5. The next partition you have access to will be displayed: "**Ready to Arm. Office**." 6. Complete the arming command sequence you wish for this partition. 7. After you have completed all the arming command sequences for the partitions you have access to, exit Single Partition Mode by pressing the [*] key for 2 seconds.

 Copyright © 1995-96 Detection Systems, Inc.

9.3 Disarming from the Master Keypad

Disarming from the Master Keypad	
Disarming all the Partitions you have access to.	Enter your PIN followed by the [Off] key. This will disarm all of your partitions, even if some are already disarmed.
Disarming only some of your Partitions	You must enter Single Partition Mode to disarm the necessary partitions one at a time. 1. Enter your PIN, followed by the [#] key twice: [1] [2] [3] [4] [#] [#]. 2. The first partition you have access to will be displayed: "**Armed. Cafeteria**." 3. Complete the disarming command sequence for this partition: [Off]. 4. Move to the next partition you have access to by pressing the [#] key twice: [#] [#]. 5. The next partition you have access to will be displayed: "**Armed. Office**." 6. Complete the disarming command sequence for this partition. 7. After you have disarmed all the partitions you have access to, exit Single Partition Mode by pressing the [*] key for 2 seconds.

9.4 Single Partition Mode

Single Partition Mode is used to control partitions on a "one at a time/one by one" basis from the Master keypad.

To enter the Single Partition Mode, enter your PIN, then press the [#] key twice. This will call up the first partition you have access to. Enter the command sequence you wish for this partition. You do not need to use your PIN again. To move on to the next partition you have access to, press the [#] key twice.

To exit the Single Partition Mode, hold the [*] key down for 2 seconds. The system will automatically drop out of Single Partition Mode after 40 seconds without a keypad entry.

10.0 How to Program the Control Panel

10.1 Entering the Programmer's Mode

To enter the Programmer's Mode, enter the Programmer's Code followed by [#] [0]. Shorting the program pads (see section 2.0 for location) on the control panel will also activate Programmer's Mode.

The default Programmer's Code is [9] [8] [7] [6].

10.2 Reading back a Program Address

Once you are in the programmer's mode, to read back the value of a Program Address, enter that Program Address followed by [#]. Each data digit is displayed one data digit at a time. To view the second data digit, enter the # button again.

The display will look like this:



10.3 Entering a value in a Program Address

To enter a value in the Program Address, enter the Program Address, then enter the value for each Data Digit, then enter [#] to save it and move on to the next Program Address. Entering data digit 1 will increment you to the next data digit.

The display will show the Program Address and will display the value of each Data Digit after you enter it. The data will be programmed (saved) when you press the [#] key. The control panel will automatically increment to the next program address.

- If you wish to program that next address, enter the necessary information.

 Copyright © 1995-96 Detection Systems, Inc.

- If you wish to read back the value of that address, press the [#] key.
- If you wish to program a different address, press the [*] key two times and enter the program address you wish to program.

If you make a mistake at any time, press the [*] key two times (before pressing the [#] key). This will clear the display, allowing you to enter the program address you wish to work with.

10.4 HEX values

Some Data Digit values will be higher than 9. These values must be programmed by pressing the [*] key followed by some other number. These values will display as HEX characters (A - F) when entered. Example: entering *0 at the keypad will display an A.

The HEX character values are as follows:
*0 = A *1 = B *2 = C *3 = D *4 = E *5 = F

10.5 Defaults

The DS7400Xi is shipped from the factory as a working, pre-programmed control. Many of the programming addresses may already be set to the values you need. The default values are shown in Reverse Print.
If the value you would like is in Reverse Print, you don't need to re-program this address.

In the example below, a "0" is the default value:

	0	1	2	3	4	5	6
Feature 1	●			●	●		●
Feature 2		●		●		●	●
Feature 3			●		●	●	●

If the default value is not shown in reverse print, it will be shown in a separate table.

10.6 Setting the Control to the Factory Default

CAUTION: Only enter [0] [1] [#] in Program Address 4058 when you are completely sure you want to erase all installer programming. Entering [0] [1] [#] in Program Address 4058 will immediately reset the control to the factory default. Any programming already done by the installer will be erased. This action cannot be reversed.

To set the control's programming values back to the default, enter the programming mode, then enter [4][0][5][8][0] [1] [#].

10.7 Exiting the Programmer's Mode

To exit the Programmer's Mode, press the [*] key for a minimum of 2 seconds. If no keypad entries are made for 4 minutes, the control will automatically exit you from the Programmer's Mode.

11.0 Understanding the Programming Charts

The Programming Reference Guide makes use of three types of charts. Each is described below.


Enter the Data Digit as a:
Select Options
0 1 2 3 4 5 6 7
Feature 1
Feature 2
Feature 3
Feature 4
Enter one of these numbers for the appropriate data digit
The dots represent which options/features are included with each selection
Example:
To select Feature 2 only, enter the data digit as a 1.
To select Feature 2 and Feature 4, enter the data digit as a 5.
Identifies the options/features available for this address

If the chart looks like this, a combination of features is available to be programmed for that particular address.

 Copyright © 1995-96 Detection Systems, Inc.

If the chart looks like this, only a single feature is available to be programmed for that particular address.


Represents the option/feature available for this address.
Example:
To select Disabled, enter the data digit as a 0.
To select Entry/Exit Delay #2, enter the data digit as a 4.
Select Option
DD
Disabled 0
Perimeter Instant 1
24-Hour 2
Entry/Exit Delay #1 3
Entry/Exit Delay #2 4
Enter one of these numbers for the appropriate data digit

Some pages may also include a Default chart that looks like this:

Zone Function	Address	Default
1	0001	23
2	0002	24
3	0003	21

Copyright © 1995-96 Detection Systems, Inc.

12.0 Programming

12.1 General Control Programmong: Program Address (0000)

Example:
To program the system-wide General Operating parameters as: allowing Normal and Custom Arming, Operating at 60 Hz., and to Restore when a Zone Restores.

Data Digit 1 = [2], Data Digit 2 = [1].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [0] [0] [0]
Enter Data Digit 1: [2]
Enter Data Digit 2: [1]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

General Control programming defines the system-wide general operating parameters.

See Glossary (section 7.1) for further details.

Data Digit **1** **2**

Select Options	Enter the Data Digit as a: 0	1	2	3	4	5	6	7	8	9	*0	*1	*2	*3	*4	*5
Allow Normal and Custom Arming**	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Allow Perimeter Instant Arming**	●	●			●	●			●	●			●	●		
Allow Perimeter Arming**	●	●			●	●			●	●			●	●		
Allow Maximum Security Arming**	●	●			●	●			●	●			●	●		
Closing Ring-Back					●	●	●	●					●	●	●	●
Siren on Comm. Fail for Silent Zone									●	●	●	●	●	●	●	●
50 Hz. operation∆		●		●		●		●		●		●		●		●
60 Hz. operation	●		●		●		●		●		●		●		●	

∆ = For installations in North America, select 60 Hz. operation.

*0 - *5 are Hex values. They will display as A - F at the keypads.

Select Options	Enter DD as a: 0	1	2	3	4	5
Restore zone when Sounders Silence	●			●		
Restore zone when Zone Restores		●			●	
Restore zone when System is Disarmed			●			●
Allow Swinger Shunts				●	●	●

**** =**

- Normal Arming = PIN + [On]: If programmed, Normal Arming arms the entire system while allowing entry delays for entry/exit zones.
- Perimeter Instant Arming = [PIN] + [No Entry] [Perimeter Only]: If programmed, Perimeter Instant Arming arms only the perimeter of the system and does not allow entry delays for entry/exit zones.
- Perimeter Arming = [PIN] + [Perimeter Only]: If programmed, Perimeter Arming arms only the perimeter of the system while allowing entry delays for entry/exit zones.
- Custom Arming = [PIN] + [#] [4]: If programmed, Custom Arming allows custom arming of the system and bypasses the zone functions specified in data address 0183.
- Maximum Security Arming = [PIN] + [No Entry] [On]: If programmed, Maximum Security Arming arms the entire system and does not allow entry delays for entry/exit zones.

Copyright © 1995-96 Detection Systems, Inc.

12.2 Zone Function Programming: Program Addresses (0001-0015)

A Zone Function is the description of how a zone will behave. Up to 15 different Zone Functions may be programmed. Each zone must be assigned a zone function. Multiple zones can be programmed to follow the same zone function.

See section 6.3 and 7.2 for further details.

Example:
To program Zone Function 1 as: Steady Alarm Output, Alarm on Short, Trouble on Open, Interior Instant.

Data Digit 1 = [6], Data Digit 2 = [7].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [0] [0] [1]
Enter Data Digit 1: [6]
Enter Data Digit 2: [7]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

** = Only when disarmed. When armed, this becomes an Alarm on Open or Short for non 24-hour zones.
Note: Multiplex contacts (DS7450 and DS7452) should not be programmed for Trouble on Open.

Data Digit

	1	2

Select Options	Enter the Data Digit as a: 0	1	2	3	4	5	6	7	*2	*3	*4	*5
Invisible Alarm	●				●				●			
Silent Alarm		●				●				●		
Steady Alarm Output			●				●				●	
Pulsing Alarm Output				●				●				●
Alarm on Short	●	●	●	●	●	●	●	●				
Alarm on Open	●	●	●	●					●	●	●	●
Trouble on Open**					●	●	●	●				
Trouble on Short									●	●	●	●

*2 - *5 are Hex values. They will display as C - F at the keypads.

Select Option	DD
Disabled	0
Perimeter Instant	1
24-Hour	2
Entry/Exit Delay #1	3
Entry/Exit Delay #2	4
Interior Entry/Exit Follower	5
Interior Home/Away	6
Interior Instant	7
Day Monitor	8
Keyswitch (See note below)	9
Fire Zone with verification	*0
Fire Zone w/out verification	*1
Waterflow	*2
Supervisory	*3
Entry/Exit Delay Cancel 1	*4
Entry/Exit Delay Cancel 2	*5

Value (fill in)	Zone Funct.	Address	Default (Will be forced to different values when in Commercial Fire Mode. See section 12.15.3)
	1	0001	2 = Steady alarm output, alarm on short and open. 3 = Entry/exit delay 1.
	2	0002	2 = Steady alarm output, alarm on short and open. 4 = Entry/exit delay 2.
	3	0003	2 = Steady alarm output, alarm on short and open. 1 = Perimeter Instant.
	4	0004	2 = Steady alarm output, alarm on short and open. 5 = Interior entry/exit follower.
	5	0005	2 = Steady alarm output, alarm on short and open. 6 = Interior home/away.
	6	0006	2 = Steady alarm output, alarm on short and open. 7 = Interior Instant.
	7	0007	2 = Steady alarm output, alarm on short and open. 2 = 24-hour.
	8	0008	7 = Pulsing alarm output, alarm on short, trouble on open. *0 = Fire zone with verification.
	9	0009	0 = _____ 0 = Disabled _____
	10	0010	0 = _____ 0 = Disabled _____
	11	0011	0 = _____ 0 = Disabled _____
	12	0012	0 = _____ 0 = Disabled _____
	13	0013	0 = _____ 0 = Disabled _____
	14	0014	0 = _____ 0 = Disabled _____
	15	0015	0 = _____ 0 = Disabled _____

	9

Note: If digit 2 = 9 (keyswitch), use this chart for digit 1.

Select Option	DD
Single Partition-No Force Arm	0
Single Partition-Can Force Arm	1
All Partions-No Force Arm	2
All Partitions-Can Force Arm	3

Copyright © 1995-96 Detection Systems, Inc.

12.3 Zone Programming: Program Addresses (0018-0145)

Example:
To program a Zone (Zone 1) as: a Single Zone Input (PIR) and follows Zone Function 1.

Data Digit 1 = [0], Data Digit 2 = [1].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [0] [1] [8]
Enter Data Digit 1: [0]
Enter Data Digit 2: [1]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

In Zone Programming, each zone is defined according to:
- Input (single or multiple zone input, or a DS7465)
- Zone Function or Output function (1-15).

The DS7465's relay is the only device that will follow the output functions; its input loop will follow a zone function. All single and multiple zone inputs will follow a zone function.

See section 6.2 and 7.3 for further details.

Data Digit 1 2

Select Option	DD
Single Zone Input (zones 1-8 on the control, multiplex contacts, sensors, or a DS7457)	0
Multiple Zone Input (any zone that is on a DS7432, DS7433, or DS7460)	1
DS7465 Connections (the input zone or the output relay on a DS7465)	2

Zone Number	Address	Default
1	0018	01
2	0019	02
3	0020	03
4	0021	04
5	0022	05
6	0023	06
7	0024	07
8	0025	08
9-128	0026-0145	00

Hint: Address = Zone Number + 17

Select Option	DD
Disabled	0
Follow Zone (or Output) Function 1	1
Follow Zone (or Output) Function 2	2
Follow Zone (or Output) Function 3	3
Follow Zone (or Output) Function 4	4
Follow Zone (or Output) Function 5	5
Follow Zone (or Output) Function 6	6
Follow Zone (or Output) Function 7	7
Follow Zone (or Output) Function 8	8
Follow Zone (or Output) Function 9	9
Follow Zone (or Output) Function 10	*0
Follow Zone (or Output) Function 11	*1
Follow Zone (or Output) Function 12	*2
Follow Zone (or Output) Function 13	*3
Follow Zone (or Output) Function 14	*4
Follow Zone (or Output) Function 15	*5

To program Output Functions, see section 12.33.
*0 - *5 are Hex values.
They will display as A - F at the keypads.

12.4 Zone Partition Assignment: Program Addresses (1248-1311)

In Zone Partition Assignment, each zone is assigned to a partition. By default, all zones are assigned to partition 1.

The partition assignment for odd numbered zones is programmed in the first data digit of these addresses. The partition assignment for even numbered zones is programmed in the second data digit of these addresses.

For example, to assign zone 1 to partition 1 and zone 2 to partition 2, program address 1248 as 01.

Partition Assignment Address	
For Zones 1 and 2	1248
For Zones 3 and 4	1249
For Zones 5 and 6	1250
For Zones 7 and 8	1251
Zones 9 through 128	1252-1311

Data Digit 1 2

Select Option	DD
Belongs to Partition 1	0
Belongs to Partition 2	1
Belongs to Partition 3	2
Belongs to Partition 4	3
Belongs to Partition 5	4
Belongs to Partition 6	5
Belongs to Partition 7	6
Belongs to Partition 8	7

Select Option	DD
Belongs to Partition 1	0
Belongs to Partition 2	1
Belongs to Partition 3	2
Belongs to Partition 4	3
Belongs to Partition 5	4
Belongs to Partition 6	5
Belongs to Partition 7	6
Belongs to Partition 8	7

Copyright © 1995-96 Detection Systems, Inc.

12.5 Zone Bypass Programming: Program Addresses (0016-0017)

Example:
To program zone functions 1 - 7 so they can not be bypassed and zone function 8 so it can be bypassed.

Data Digit 1 = [*] [5], Data Digit 2 = [7].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [0] [1] [6]
Enter Data Digit 1: [*] [5]
Enter Data Digit 2: [7]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

Zone Bypass programming determines which zone functions can be bypassed. Zone functions that can not be bypassed can not be force armed either. Fire zones can never be manually bypassed, but can be force armed. The Default of [0] or [8] means those zones can be bypassed.

PA 0016
Data Digit
1 **2**

Select Options	Enter the Data Digit as a: 0	1	2	3	4	5	6	7	8	9	*0	*1	*2	*3	*4	*5
Zone Function 1 Can Be Bypassed	●		●		●		●		●		●		●		●	
Zone Function 2 Can Be Bypassed	●	●			●	●			●	●			●	●		
Zone Function 3 Can Be Bypassed	●	●	●	●					●	●	●	●				
Zone Function 4 Can Be Bypassed	●	●	●	●	●	●	●	●								

*0 - *5 are Hex values. They will display as A - F at the keypads.

Select Options	Enter the Data Digit as a: 0	1	2	3	4	5	6	7	**8**	9	*0	*1	*2	*3	*4	*5
Zone Function 5 Can Be Bypassed	●		●		●		●		●		●		●		●	
Zone Function 6 Can Be Bypassed	●	●			●	●			●	●			●	●		
Zone Function 7 Can Be Bypassed	●	●	●	●					●	●	●	●				
Zone Function 8 Can Be Bypassed	●	●	●	●	●	●	●	●								

*0 - *5 are Hex values. They will display as A - F at the keypads.

PA 0017
Data Digit
1 **2**

Select Options	Enter the Data Digit as a: 0	1	2	3	4	5	6	7	8	9	*0	*1	*2	*3	*4	*5
Zone Function 9 Can Be Bypassed	●		●		●		●		●		●		●		●	
Zone Function 10 Can Be Bypassed	●	●			●	●			●	●			●	●		
Zone Function 11 Can Be Bypassed	●	●	●	●					●	●	●	●				
Zone Function 12 Can Be Bypassed	●	●	●	●	●	●	●	●								

*0 - *5 are Hex values. They will display as A - F at the keypads.

Select Options	Enter the Data Digit as a: 0	1	2	3	4	5	6	7	8	9	*0	*1	*2	*3	*4	*5
Zone Function 13 Can Be Bypassed	●		●		●		●		●		●		●		●	
Zone Function 14 Can Be Bypassed	●	●			●	●			●	●			●	●		
Zone Function 15 Can Be Bypassed	●	●	●	●					●	●	●	●				

*0 - *5 are Hex values. They will display as A - F at the keypads.

Copyright © 1995-96 Detection Systems, Inc.

12.6 Output Programming: Program Addresses (0146-0148)

Example:
To program the Programmable Output 1 as: following a Burglar Zone Alarm that is in Partition 1.

PA 0147: Data Digit 1 = [6], Data Digit 2 = [1].
PA 0149: Data Digit 1 = [8], Data Digit 2 = [0].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [1] [4] [7]
Enter Data Digit 1: [6]Enter Data Digit 2: [1]Enter the pound key: [#]
Enter the Program Address: [0] [1] [4] [9]
Enter Data Digit 1: [8]Enter Data Digit 2: [0]Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

Output programming defines the event, partition, and type of alarm (burg or fire) that will trigger each of the three physical outputs on the control panel.

See section 3.0 for the location of the physical outputs on the control panel.

See Glossary (section 7.4) for further details.

Programmable Output 1 will be ON for 10 seconds after pressing [System Reset].

Programmable Output 2 will be OFF for 10 seconds after pressing [System Reset].

Data Digit 1 2

Select Option	DD
Latch on ANY Zone Alarm**	0
ON during Entry Pre-Alert	1
ON for 10 sec. after pressing [System Reset]	2
ON when system is Armed	3
Ground Start	4
System Status (ready to arm)	5
Zone Alarm	6
Zone Alarm delayed by 20 sec.	7
Keypad Sounder Output	8
Access Output (10 sec. pulse)	9
Panic Duress Output***	*1

Options	DD
Disabled	0
Burglar Alarm	1
Fire Alarm	2
Burg and Fire Alarm	**3**

** = This includes invisible zones. See glossary for further details.
*** = See section 7.4 for description of this option.

Output	Address	Default
Alarm	0146	6 3
Programmable Output 1	0147	3 3
Programmable Output 2	0148	2 3

12.7 Output Partition Assignment: Program Addresses (0149-0150)

In Output Partition Assignment, each On-board output is assigned to a partition. By default, outputs are assigned to all partitions.

PA 0149 Data Digit 1 2

PA 0150 Data Digit 1 2

PA 0150 Data Digit 2 = **0**

Must Be 0

Output	Address	Default
Alarm	0149-DD1	8
Programmable Output 1	0149-DD2	8
Programmable Output 2	0150-DD1	8

Select Option	DD
Belongs to Partition 1	0
Belongs to Partition 2	1
Belongs to Partition 3	2
Belongs to Partition 4	3
Belongs to Partition 5	4
Belongs to Partition 6	5
Belongs to Partition 7	6
Belongs to Partition 8	7
Follows all Partitions	**8**

Copyright © 1995-96 Detection Systems, Inc.

12.8 Partition Control Programming: Program Address (0165)

Example:
To program the Partition Control as: the System will use 3 Partitions, and Partition 1 is common to Partitions 2 and 3.

Data Digit 1 = [2], Data Digit 2 = [1].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [1] [6] [5]
Enter Data Digit 1: [2]
Enter Data Digit 2: [1]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

Partition Control programming defines the number of partitions in use and the common area (common area can only be partition 1).

See Glossary (section 7.5) for further details.

Data Digit

1	2

Select Option	DD
Use 1 Partition	0
Use 2 Partitions	1
Use 3 Partitions	2
Use 4 Partitions	3
Use 5 Partitions	4
Use 6 Partitions	5
Use 7 Partitions	6
Use 8 Partitions	7

Select Option	DD
No Common Area	0
Partition 1 Common to Partition 2 and 3	1
Partition 1 Common to Partition 2 - 4	2
Partition 1 Common to Partition 2 - 5	3
Partition 1 Common to Partition 2 - 6	4
Partition 1 Common to Partition 2 - 7	5
Partition 1 Common to Partition 2 - 8	6

12.9 Quick Arm Control Programming: Program Address (0169)

Example:
To program so that Partitions 1 and 2 can be quick armed, while Partitions 3 through 8 can not be quick armed.

Data Digit 1 = [3], Data Digit 2 = [0].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [1] [6] [9]
Enter Data Digit 1: [3]
Enter Data Digit 2: [0]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

Quick Arm Control programming defines which partitions can be quick armed (armed without requiring a PIN to be entered).

Data Digit

1	2

	Enter the Data Digit as a:															
Select Options	**0**	1	2	3	4	5	6	7	8	9	*0	*1	*2	*3	*4	*5
Partition 1 Quick Arm Enabled		●		●		●		●		●		●		●		●
Partition 2 Quick Arm Enabled			●	●			●	●			●	●			●	●
Partition 3 Quick Arm Enabled					●	●	●	●					●	●	●	●
Partition 4 Quick Arm Enabled									●	●	●	●	●	●	●	●

	Enter the Data Digit as a:															
Select Options	**0**	1	2	3	4	5	6	7	8	9	*0	*1	*2	*3	*4	*5
Partition 5 Quick Arm Enabled		●		●		●		●		●		●		●		●
Partition 6 Quick Arm Enabled			●	●			●	●			●	●			●	●
Partition 7 Quick Arm Enabled					●	●	●	●					●	●	●	●
Partition 8 Quick Arm Enabled									●	●	●	●	●	●	●	●

Copyright © 1995-96 Detection Systems, Inc.

12.10 Keypad Assignment Programming: Program Addresses (0173-0180)

Example:
To program Keypad 1 as an Alpha Keypad that is assigned to Partition 1.

PA 0173: Data Digit 1 = [1], Data Digit 2 = [0].
PA 0208: Data Digit 1 = [2], Data Digit 2 = [0].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [1] [7] [3] (Data Digit 1)
Enter Data Digit 1: [1]Enter Data Digit 2: [0]Enter the pound key: [#]
Enter the Program Address: [0] [2] [0] [8]
Enter Data Digit 1: [0]Enter Data Digit 2: [0]Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

Keypad Assignment Programming is where you assign the keypad type and the partition it belongs to.

See Glossary (section 7.6) for further details.

Note: Each keypad must have its own Bus address. This must also be selected on the keypad via its address pins. See In Guide P/N 25902. One keypad must be selected as keypad 1.

Defaults: The default, if using only one keypad, is an Alpha keypad belonging to partition one.

Program Address 0173
Data Digit 1 | Data Digit 2
Keypad 1* (default = 1) | Keypad 2 (default = 0)

Program Address 0174
Data Digit 1 | Data Digit 2
Keypad 3 (default = 0) | Keypad 4 (default = 0)

Program Address 0175
Data Digit 1 | Data Digit 2
Keypad 5 (default = 0) | Keypad 6 (default = 0)

Program Address 0176
Data Digit 1 | Data Digit 2
Keypad 7 (default = 0) | Keypad 8 (default = 0)

Program Address 0177
Data Digit 1 | Data Digit 2
Keypad 9 (default = 0) | Keypad 10 (default = 0)

Program Address 0178
Data Digit 1 | Data Digit 2
Keypad 11** (default = 0) | Keypad 12** (default = 0)

Program Address 0179
Data Digit 1 | Data Digit 2
Keypad 13** (default = 0) | Keypad 14** (default = 0)

Program Address 0180
Data Digit 1 | Data Digit 2
Keypad 15** (default = 0) | Must Be 0 (**0**)

* = When in Commercial Fire Mode, certain keypads must have specific assignments (see section 8.10).
** = Keypads 11-15 are connected to the Option Bus. If the DS7412 is connected to the Option Bus (at keypad address 13 or 14), keypad 13 or 14 is unavailable. Similarly, if the DS7420i is connected to the Option Bus at keypad address 15, keypad 15 is unavailable; and if the DS7488 is connected to the Option Bus at keypad address 11-15, the corresponding keypad(s) is(are) unavailable.



***** = If only using one partition, do not program keypads as Master Keypads.** Only program for a Master Keypad if you need to view multiple partitions from a single keypad.

Select Options	0	1	2	3
Disabled	●			
Alpha (LCD) Keypad		●		●
LED Keypad			●	
Master Keypad***				●

12.11 Keypad Partition Assignment: Program Addresses (0208-0215)

Program Address 0208
Data Digit 1 | Data Digit 2
Keypad 1 | Keypad 2

Program Address 0209
Data Digit 1 | Data Digit 2
Keypad 3 | Keypad 4

Program Address 0210
Data Digit 1 | Data Digit 2
Keypad 5 | Keypad 6

Program Address 0211
Data Digit 1 | Data Digit 2
Keypad 7 | Keypad 8

Program Address 0212
Data Digit 1 | Data Digit 2
Keypad 9 | Keypad 10

Program Address 0213
Data Digit 1 | Data Digit 2
Keypad 11 | Keypad 12

Program Address 0214
Data Digit 1 | Data Digit 2
Keypad 13 | Keypad 14

Program Address 0215
Data Digit 1 | Data Digit 2
Keypad 15 | Must Be 0 (**0**)

Select Option	DD
Belongs to Partition 1	**0**
Belongs to Partition 2	1
Belongs to Partition 3	2
Belongs to Partition 4	3
Belongs to Partition 5	4
Belongs to Partition 6	5
Belongs to Partition 7	6
Belongs to Partition 8	7

Copyright © 1995-96 Detection Systems, Inc.

12.12 Emergency Key Programming: Program Addresses (0181-0182)

Example:
To program the Fire Key and the Special Emergency Key as both having a Steady Alarm.

Data Digit 1 = [2], Data Digit 2 = [2].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [1] [8] [1]
Enter Data Digit 1: [2]
Enter Data Digit 2: [2]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

Emergency Key and Panic Key programming disables or activates these keys (the A, B, and C keys) located on the keypads.
It also determines a silent, pulsed, or steady alarm.

See Glossary (section 7.7) for further details.

PA 0181

Data Digit **1** **2**

Fire Key

A

Select Option	DD
Fire Key Disabled	**0**
Fire Key = Disabled	1
Fire Key = Steady Alarm	2
Fire Key = Pulsed Alarm	3

May be forced to a different value when in Commercial Fire Mode. See section 12.15.3.

Emergency Key

B

Select Option	DD
Special Emergency Key Disabled	**0**
Special Emergency Key = Silent Alarm	1
Special Emergency Key = Steady Alarm	2
Special Emergency Key = Pulsed Alarm	3

PA 0182

Data Digit **1** **2**

Panic Key

C

Select Option	DD
Panic Key Disabled	**0**
Panic Key = Silent Alarm	1
Panic Key = Steady Alarm	2
Panic Key = Pulsed Alarm	3

Data Digit 2 must be 0 **0**



May be forced to a different value when in Commercial Fire Mode. See section 12.15.3.

12.13 Custom Arming Programming: Program Addresses (0183-0184)

Example:
To program the [4] to Bypass Zone Function 1 only.

Data Digit 1 = [1], Data Digit 2 = [0].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [1] [8] [3]
Enter Data Digit 1: [1]
Enter Data Digit 2: [0]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

PA 0183

Data Digit **1** **2**

Select Options	Enter the Data Digit as a: **0**	1	2	3	4	5	6	7	8	9	*0	*1	*2	*3	*4	*5
Bypass Zone Function 1		●		●		●		●		●		●		●		●
Bypass Zone Function 2			●	●			●	●			●	●			●	●
Bypass Zone Function 3					●	●	●	●					●	●	●	●
Bypass Zone Function 4									●	●	●	●	●	●	●	●

*0 - *5 are Hex values. They will display as A - F at the keypads.

Select Options	Enter the Data Digit as a: **0**	1	2	3	4	5	6	7	8	9	*0	*1	*2	*3	*4	*5
Bypass Zone Function 5		●		●		●		●		●		●		●		●
Bypass Zone Function 6			●	●			●	●			●	●			●	●
Bypass Zone Function 7					●	●	●	●					●	●	●	●
Bypass Zone Function 8									●	●	●	●	●	●	●	●

*0 - *5 are Hex values. They will display as A - F at the keypads.

Copyright © 1995-96 Detection Systems, Inc.

12.13 Custom Arming Programming: Program Addresses (0183-0184) (Continued)

PA 0184
Data Digit
1 **2**

Select Options	Enter the Data Digit as a: 0	1	2	3	4	5	6	7	8	9	*0	*1	*2	*3	*4	*5
Bypass Zone Function 9		●		●		●		●		●		●		●		●
Bypass Zone Function 10			●	●			●	●			●	●			●	●
Bypass Zone Function 11					●	●	●	●					●	●	●	●
Bypass Zone Function 12									●	●	●	●	●	●	●	●

*0 - *5 are Hex values. They will display as A - F at the keypads.

Select Options	Enter the Data Digit as a: 0	1	2	3	4	5	6	7
Bypass Zone Function 13		●		●		●		●
Bypass Zone Function 14			●	●			●	●
Bypass Zone Function 15					●	●	●	●

12.14 Force Arming and Ground Fault Detect Programming: Program Address (0185)

Example:
To be able to Force Arm up to 5 Zones and have Ground Fault Off.

Data Digit 1 = [5], Data Digit 2 = [0].

Enter the Programmer's Mode:
[9] [8] [7] [6] [#] [0]

Enter the Program Address: [0] [1] [8] [5]
Enter Data Digit 1: [5]
Enter Data Digit 2: [0]
Enter the pound key: [#]

Program the next Address, Program a different Address, or Exit the Programmer's Mode.

Force Arming programming defines how many zones may be Force Armed using an Arming sequence followed by the [Bypass] key. With this entry, all violated zones (up the programmed limit) will automatically be Force Armed (bypassed). Ground Fault Detect programming determines whether or not the control will detect a ground fault condition.

See Glossary (section 7.9) for further details.

Select Option	DD
Do not allow Force Arming	0
Allow up to 1 zone to be Force Armed	**1**
Allow up to 2 zones to be Force Armed	2
Allow up to 3 zones to be Force Armed	3
Allow up to 4 zones to be Force Armed	4
Allow up to 5 zones to be Force Armed	5
Allow up to 6 zones to be Force Armed	6
Allow up to 7 zones to be Force Armed	7
Allow up to 8 zones to be Force Armed	8
Allow up to 9 zones to be Force Armed	9

Data Digit
1 **2**

Select Option	DD
Ground Fault Detect Off	0
Ground Fault Detect On	**1**

Copyright © 1995-96 Detection Systems, Inc.

12.15 Commercial Fire Mode Programming: Program Address (0186)

Example:
To program the Commercial Fire Mode parameters as: Central Station Commercial Fire Mode enabled, with a 10 second delay on Waterflow Zones, having the Bell and Aux. activate on Fire Alarms, and using California March Time.

Data Digit 1 = [8], Data Digit 2 = [1].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [1] [8] [6]
Enter Data Digit 1: [8]
Enter Data Digit 2: [1]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

This section describes how to define the parameters for the Commercial Fire Mode.

See Glossary (section 7.10) for further details.

Data Digit **1** **2**

Select Options	Enter the Data Digit as a: 0	1	2	3	4	5	6	7	8	9	*0	*1	*2
Commercial Fire Mode disabled	●												
Local Comm. Fire Mode enabled		●	●	●	●	●	●						
Central Station Comm. Fire Mode enabled								●	●	●	●	●	●
10 sec. delay on waterflow zone			●						●				
20 sec. delay on waterflow zone				●						●			
30 sec. delay on waterflow zone					●						●		
40 sec. delay on waterflow zone						●						●	
50 sec. delay on waterflow zone							●						●

*0 - *2 are Hex values. They will display as A - C at the keypads.

Zones 1-4 may only have waterflow delays.

Select Options	Enter the DD as a: 0	1	2	3	4	5
Bell and Aux. activate on Fire	●	●	●	●	●	●
Bell and Aux. activate on Burg				●	●	●
Pulsing Fire Alarms are 1 sec. On / 1 sec. Off	●			●		
Pulsing Fire Alarms use California March Time		●			●	
Pulsing Fire Alarms use Temporal Cadence			●			●

When programming Fire zones, it is recommended that they be zone functions 12 and 13 (see sections 12.2 and 12.15.3).

12.15.1 When Central Station Commercial Fire Mode is chosen, address 1520 (DS7420i: Dual Phone Line/Bell Supervision Module Output Programming),will be forced to a value of 5.

12.15.2 When Local Commercial Fire Mode is chosen,address 1520 (DS7420i: Dual Phone Line/Bell Supervision Module Output Programming),will be forced to a value of 3, 4, or 5. (Turns the Bell Monitor feature ON and the Alarm Output on Line Fault feature OFF)

12.15.3 Regardless of which Commercial Fire Mode is chosen, the following parameters will be forced when exiting local programmer's mode:

- Zone Function 12, address 0012, will be a 7 *0.
- Zone Function 13, address 0013, will be a 7 *1.
- Zone Function 14, address 0014, will be a 7 *2.
- Zone Function 15, address 0015, will be a 7 *3.
- Zone Bypass address 0017 will not allow zone functions 12 - 15 to be bypassed.
- Emergency Key, address 0181, data digit 1, will become a 3 if programmed previously as a 2. Data digit 2 will become a 2 if programmed previously as a 3.
- Panic Key, address 0182, data digit 1, will become a 2 if programmed previously as a 3.
- Fire Bell Cutoff: If less than 5, set to 5, otherwise untouched.

12.15.4 In Central Station Commercial Fire Mode, the following communication parameters will be forced:

Report Codes: If 0, the following defaults will be set, otherwise they will be unchanged.

Address	Default	Address	Default	Address	Default	Address	Default	Address	Default
0256	*0 1	0272	*0 6	0325	6 9	0326	7 9	0331	6 *5
0257	7 1	0286	7 3	0301	6 3	0327	6 *0	0334	3 9
0269	*0 3	0287	7 4	0302	6 4	0328	7 *0	0335	3 *0
0270	*0 4	0288	7 5	0303	6 5	0329	8 3	0336	3 9
0271	*0 5	0289	7 6	0304	6 6	0330	7 *5		

- Phone Control: If 0, set to 6 1, 4/2 @ 18/23, 10pps, otherwise untouched.
- Test Report: Set to 8, call out every day.

Copyright © 1995-96 Detection Systems, Inc.

12.16 Open/Close Report Control Programming: Program Address (0187)

Example:
To program to send Open/Close Reports from Partition 1 and to send Trouble Reports on Closings for all Bypassed Zones.

Data Digit 1 = [1], Data Digit 2 = [1].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [1] [8] [7]
Enter Data Digit 1: [1]
Enter Data Digit 2: [1]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

See Glossary (section 7.12) for further details.

Select Options	Enter the Data Digit as a: 0	1	2	3	4	5	6	7	**8**	9
Do not report opens or closes	●									
Report opens and closes in Partition 1		●	●	●	●	●	●	●	●	
Report opens and closes in Partition 2			●	●	●	●	●	●	●	
Report opens and closes in Partition 3				●	●	●	●	●	●	
Report opens and closes in Partition 4					●	●	●	●	●	
Report opens and closes in Partition 5						●	●	●	●	
Report opens and closes in Partition 6							●	●	●	
Report opens and closes in Partition 7								●	●	
Report opens and closes in Partition 8									●	
Report first Partition to open and last Partition to close**										●

Data Digit **1** **2**

Do Not Send Trouble at Close for Bypassed Zones	**0**
Send Trouble at Close for Bypassed Zones	1

** = When using this option, all partitions should have the same account code.

12.17 Open/Close & Zone Report Control Programming: Program Address (0189)

This section allows you to decide which phone number will send open and close reports, zone alarm, zone restoral, and zone trouble reports.

Example:
To program to send Open and Close Reports to Phone Number 1 and Zone Alarm, Zone Restoral, and Zone Trouble Reports to Phone Number 2.

Data Digit 1 = [1], Data Digit 2 = [2].

Enter the Programmer's Mode:
[9] [8] [7] [6] [#] [0]

Enter the Program Address: [0] [1] [8] [9]
Enter Data Digit 1: [1]
Enter Data Digit 2: [2]
Enter the pound key: [#]

Program the next Address, Program a different Address, or Exit the Programmer's Mode.

Select Option	DD
Alternate between both Phone Numbers	**0**
Report to Phone Number 1	1
Report to Phone Number 2	2
Report to Phone Number 1 and 2	3

Data Digit **1** **2**

Data Digit 1 is for Open and Close Reports.

Data Digit 2 is for Zone Alarm, Zone Restoral, and Zone Trouble Reports.

Select Option	DD
Alternate between both Phone Numbers	**0**
Report to Phone Number 1	1
Report to Phone Number 2	2
Report to Phone Number 1 and 2	3

12.18 Report Control Programming: Program Address (0190)

This section allows you to decide which phone number will send reports other than open/close reports and zone reports.

Example:
To program all other Reports to Phone Number 2.

Data Digit 1 = [2], Data Digit 2 = [0].

Enter the Programmer's Mode:
[9] [8] [7] [6] [#] [0]

Enter the Program Address: [0] [1] [9] [0]
Enter Data Digit 1: [2]
Enter Data Digit 2: [0]
Enter the pound key: [#]

Program the next Address, Program a different Address, or Exit the Programmer's Mode.

Select Option	DD
Alternate between both Phone Numbers	**0**
Report to Phone Number 1	1
Report to Phone Number 2	2
Report to Phone Number 1 and 2	3

Data Digit **1** **2**

Note: Data Digit 1 does not include open and close reports or zone reports (see sections 12.16 and 12.17).

0 Data Digit 2 must be 0

Copyright © 1995-96 Detection Systems, Inc.

12.19 Timer Programming: Program Addresses (0191-0196)

Example:
To program the Entry Delay Time 1 for 60 seconds.

Data Digit 1 = [1], Data Digit 2 = [2].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [1] [9] [1]
Enter Data Digit 1: [1]
Enter Data Digit 2: [2]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

Entry and Exit Delay Timers are in 5 second intervals (the maximum delay time is 255 seconds).

For example:
5 sec. = 01
15 sec. = 03
20 sec. = 04
30 sec. = 06
45 sec. = 09
60 sec. = 12
255 sec. = 51



Exit Delay Time Address 0193	
0 to 51 (0 to 255 sec.*)	Default = 12 (60 sec.)

*5 second intervals



Entry Delay Time 1 Address 0191	
0 to 51 (0 to 255 sec.*)	Default = 09 (45 sec.)

*5 second intervals

May be forced to a different value when in Commercial Fire Mode. See section 14.13.3.



Fire Bell Cutoff Address 0195	
0 to 99 minutes*	Default = 04 minutes

*1 minute intervals



Entry Delay Time 2 Address 0192	
0 to 51 (0 to 255 sec.*)	Default = 09 (45 sec.)

*5 second intervals



Burglary Bell Cutoff Address 0196	
0 to 99 minutes*	Default = 04 minutes

*1 minute intervals

12.20 A/C Fail Report Delay Programming: Program Address (0197)

Example:
To program the A/C Fail Report Delay Time to be 30 minutes.

Data Digit 1 = [1], Data Digit 2 = [*] [4].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [1] [9] [7]
Enter Data Digit 1: [1]
Enter Data Digit 2: [*] [4]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.



A/C Fail Report Delay Address 0197	
00 through FF	Default = 00

The A/C Fail Delay Times are programmed as Hexadecimal values.
For example:
00 = Send only with next report
1 *4 = 30 minute delay
3 *2 = 60 minute delay
78 = 120 minute delay
*5 0 = 240 minute delay
*5 *5 = Random delay (at least 15 minutes, but less than 120 minutes)

(*0 - *5 are Hex values. They will display as A through F at the keypads.)

See System Overview (section 6.1.1) for further details.

Copyright © 1995-96 Detection Systems, Inc.

21.21 General Code "Arm Only" Programming: Program Address (0198-0201)

This allows for a user with a General Authority level to Arm and Bypass zones he is not able to Disarm.

Example:
To program a General Authority level to be able to Arm and Bypass zones he is not able to Disarm in Partition 1.

Data Digit 1 = [1], Data Digit 2 = [0].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [1] [9] [8] (Data Digit 1)
Enter Data Digit 1: [1]
Enter Data Digit 2: [0]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

See System Overview (section 6.1.3) for further details.

Select Option	DD
General Code can Arm, Disarm, and Bypass	**0**
General Code can Arm and Bypass	1
General Code can Arm and Disarm	2
General Code can Arm	3

Program Address 0198

Data Digit 1 Data Digit 2

Partition 1 Partition 2

Program Address 0200

Data Digit 1 Data Digit 2

Partition 5 Partition 6

Program Address 0199

Data Digit 1 Data Digit 2

Partition 3 Partition 4

Program Address 0201

Data Digit 1 Data Digit 2

Partition 7 Partition 8

12.22 Arming Warning Programming: Program Addresses (0202-0205)

Example:
To program the keypads in Partition 1 to be audible during exit delay and the keypads in Partition 2 not to be audible during exit delay.

Data Digit 1 = [4], Data Digit 2 = [0].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [2] [0] [2]
Enter Data Digit 1: [4]
Enter Data Digit 2: [0]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

Arming Warning programming defines whether the keypad will be audible during the exit delay period. If programmed, the keypad sounder will activate once every 5 seconds during the exit delay. At 10 seconds and 5 seconds remaining, the keypad sounder will activate 3 times.

PA 0202

Data Digit **1** **2**

Partition 1	DD
No Keypad Sounder during Exit Delay	**0**
Keypad Sounder during Exit Delay	4

Partition 2	DD
No Keypad Sounder during Exit Delay	**0**
Keypad Sounder during Exit Delay	4

PA 0204

Data Digit **1** **2**

Partition 5	DD
No Keypad Sounder during Exit Delay	**0**
Keypad Sounder during Exit Delay	4

Partition 6	DD
No Keypad Sounder during Exit Delay	**0**
Keypad Sounder during Exit Delay	4

PA 0203

Data Digit **1** **2**

Partition 3	DD
No Keypad Sounder during Exit Delay	**0**
Keypad Sounder during Exit Delay	4

Partition 4	DD
No Keypad Sounder during Exit Delay	**0**
Keypad Sounder during Exit Delay	4

PA 0205

Data Digit **1** **2**

Partition 7	DD
No Keypad Sounder during Exit Delay	**0**
Keypad Sounder during Exit Delay	4

Partition 8	DD
No Keypad Sounder during Exit Delay	**0**
Keypad Sounder during Exit Delay	4

Copyright © 1995-96 Detection Systems, Inc.

12.23 DS7412 RS232 Interface Control Programming: Program Address (0206)

Example:
To program to enable the DS7412 and send Open/Close Reports to the printer.

Data Digit 1 = [1], Data Digit 2 = [2].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [2] [0] [6]
Enter Data Digit 1: [1]
Enter Data Digit 2: [2]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

Note: If using the WDSRP Direct Connection option for programming, Address 0206 must be set for 1 0. Address 0207 must be set for 2 5.

DS7412 RS232 Interface Control Programming allows you to enable or disable the DS7412 and to select which history events are sent to the printer as they occur. Selecting "No Events" will cause the history to be printed only on command.
To print the History Buffer starting from the most recent event, enter the Master Code followed by [#] [0] [8]. To stop printing, enter Master Code [#] [0] [8] again.

Data Digit **1** **2**

Select Option	DD
DS7412 Disabled	**0**
DS7412 Enabled	1

Select Options	Enter the Data Digit as a: 0	1	2	3	4	5	6	**7**
No Events	●							
Alarms, Troubles, and Restorals		●		●		●		●
Opens and Closes			●	●			●	●
All Other Events					●	●	●	●

12.24 DS7412 RS232 Interface Configuration Programming: Program Address (0207)

Example:
To program a 1200 Baud printer for No Parity, Software Flow Control, 2 Stop Bits and 8 Data Bits.

Data Digit 1 = [1], Data Digit 2 = [2].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]

Enter the Program Address: [0] [2] [0] [7]
Enter Data Digit 1: [1]
Enter Data Digit 2: [2]
Enter the pound key: [#]

Program the next Address, Program a different Address, or Exit the Programmer's Mode.

DS7412 RS232 Interface Configuration Programming allows you to configure the DS7412 for your printer. Most printers will operate using the default values for the DS7412. Some printers may operate more efficiently using optional program values.

Consult the operating guide provided with your printer to be sure that its configuration matches the one programmed here.

Note: If using the WDSRP Direct Connection option for programming, Address 0206 must be set for 1 0. Address 0207 must be set for 2 5.

Data Digit **1** **2**

Select Option	DD
300 Baud	**0**
1200 Baud	1
2400 Baud	2
4800 Baud	3
9600 Baud	4
14400 Baud	5

Select Options	Enter the Data Digit as a: **0**	1	2	3	4	5	6	7
No Parity	●	●	●	●				
ODD Parity					●	●		
EVEN Parity							●	●
Software Flow Control	●		●		●		●	
Hardware Flow Control		●		●		●		●
1 Stop Bit	●	●			●	●	●	●
2 Stop Bits			●	●				
8 Data Bits	●	●	●	●	●	●	●	●

Copyright © 1995-96 Detection Systems, Inc.

12.25 Report Programming: Program Addresses (0256-0304 and 0320-0340)

- To send the User number along with open, close, or partial close reports: place an 'F' (*5) in the extended digit.
- To disable a report (meaning: nothing will be sent): place a '0' in the reporting digit.
- When using SIA or Contact ID format, place a '1' in the reporting digit of each report you wish to enable. It is not necessary to program the extended digit.
- For suggested values for 4/2 and BFSK format, see section 16.1-16.3. For SIA and Contact ID, the values sent are listed in section 15.2. For other formats, consult your central station.
- **HEX values:** Some Data Digit values are higher than 9. These values are programmed by pressing the [*] key followed by another number. These values will display as HEX characters when entered. The HEX character values are as follows:

***0 = A *1 = B *2 = C *3 = D *4 = E *5 = F**

See Glossary (section 6.12) for further details.

Report	Address	Default	Reporting Digit 1	Extended Digit 2
Keypad Fire Alarm	0256	00		
Keypad Fire Restoral	0257	00		
Zone Funct. 1 Alarm	0258	10		
Zone Funct. 2 Alarm	0259	20		
Zone Funct. 3 Alarm	0260	30		
Zone Funct. 4 Alarm	0261	40		
Zone Funct. 5 Alarm	0262	50		
Zone Funct. 6 Alarm	0263	60		
Zone Funct. 7 Alarm	0264	70		
Zone Funct. 8 Alarm	0265	80		
Zone Funct. 9 Alarm	0266	00		
Zone Funct 10 Alarm	0267	00		
Zone Funct. 11 Alarm	0268	00		
Zone Funct. 12 Alarm	0269	00		
Zone Funct. 13 Alarm	0270	00		
Zone Funct. 14 Alarm	0271	00		
Zone Funct. 15 Alarm	0272	00		
Keypad Emergency	0273	00		
Keypad Panic	0274	00		
Zone Funct. 1 Restoral	0275	00		
Zone Funct. 2 Restoral	0276	00		
Zone Funct. 3 Restoral	0277	00		
Zone Funct. 4 Restoral	0278	00		
Zone Funct. 5 Restoral	0279	00		

Report	Address	Default	Reporting Digit 1	Extended Digit 2
Zone Funct. 6 Restoral	0280	00		
Zone Funct. 7 Restoral	0281	00		
Zone Funct. 8 Restoral	0282	00		
Zone Funct. 9 Restoral	0283	00		
Zone Funct. 10 Restoral	0284	00		
Zone Funct. 11 Restoral	0285	00		
Zone Funct. 12 Restoral	0286	00		
Zone Funct. 13 Restoral	0287	00		
Zone Funct. 14 Restoral	0288	00		
Zone Funct. 15 Restoral	0289	00		
Zone Funct. 1 Trouble	0290	00		
Zone Funct. 2 Trouble	0291	00		
Zone Funct. 3 Trouble	0292	00		
Zone Funct. 4 Trouble	0293	00		
Zone Funct. 5 Trouble	0294	00		
Zone Funct. 6 Trouble	0295	00		
Zone Funct. 7 Trouble	0296	00		
Zone Funct. 8 Trouble	0297	00		
Zone Funct. 9 Trouble	0298	00		
Zone Funct. 10 Trouble	0299	00		
Zone Funct. 11 Trouble	0300	00		
Zone Funct. 12 Trouble	0301	00		
Zone Funct. 13 Trouble	0302	00		
Zone Funct. 14 Trouble	0303	00		

Copyright © 1995-96 Detection Systems, Inc.

Report Programming (Continued)

Report	Address	Default	Reporting Digit 1	Extended Digit 2
Zone Funct. 15 Trouble	0304	00		
Open	0320	00		
Close	0321	00		
Duress	0322	00		
Partial Close	0322	00		
First Open After Alarm	0324	00		
Low Battery	0325	00		
Battery Restoral	0326	00		
AC Failure	0327	00		
AC Restoral	0328	00		
Comm. Test/System Normal	0329	00		

Report	Address	Default	Reporting Digit 1	Extended Digit 2
Remote Program Successful	0330	00		
Remote Prog. Unsuccessful	0331	00		
Local Program Successful	0332	00		
Local Program Unsuccessful	0333	00		
System Trouble	0334	00		
System Trouble Restoral	0335	00		
Comm. Test/System off Norm.	0336	00		
Exit Error	0337	00		
Recent Closing	0338	00		
System Test	0339	00		
System Test Restoral	0340	00		

12.26 Phone/ARDIS Routing Control: Program Addresses (0494-0495)

If address 0528 is programmed to “Try ARDIS network first”, the following addresses can be used to control report routing. If address 0528 is set to “Send alarms via both ARDIS and digital”, this will force alarms to go to the phone even if the Phone/ARDIS report routing for alarms does not specify phone usage.

Phone/ARDIS report routing (0494).
First digit: Open and Close Reports.

Data Digit 1 2

Select Options	Enter the DD as a: 1	2	3	7	*1	*5
Use Phone	●		●	●	●	●
Use ARDIS		●	●	●	●	●
Use Either			●		●	
Use Both				●		●
Try Phone First					●	●

Second digit: Zone Alarm, Zone Restoral, and Zone Trouble Reports.

Select Options	Enter the DD as a: 1	2	3	7	*1	*5
Use Phone	●		●	●	●	●
Use ARDIS		●	●	●	●	●
Use Either			●		●	
Use Both				●		●
Try Phone First					●	●

Phone/ARDIS report routing and Phone First count (0495)

First Digit: System Reports.

Data Digit 1 2

Select Options	Enter the DD as a: 1	2	3	7	*1	*5
Use Phone	●		●	●	●	●
Use ARDIS		●	●	●	●	●
Use Either			●		●	
Use Both				●		●
Try Phone First					●	●

Select Option	DD	Select Option	DD	Select Option	DD	Select Option	DD
0 Attempts	0	4 Attempts	4	8 Attempts	8	12 Attempts	*2
1 Attempt	1	5 Attempts	5	9 Attempts	9	13 Attempts	*3
2 Attempts	2	6 Attempts	6	10 Attempts	*0	14 Attempts	*4
3 Attempts	3	7 Attempts	7	11 Attempts	*1	15 Attempts	*5

Second digit: Phone First count. Number of attempts before trying ARDIS:

This value is used to control the number of attempts made on the phone line before switching to the ARDIS network. This value is only referenced if the “Use Phone”, “Use ARDIS”, and “Try Phone First” options are all selected. If the value is less than or equal to 2, or more than 5, two attempts will be made on the phone before trying ARDIS if the Phone First option is selected.

Copyright © 1995-96 Detection Systems, Inc.

12.27 Account Code Programming: Program Addresses (0496-0526)

Example:
To program Partition 1 Phone #1 Account Code to be 2332.

Data Digit 1 = [2], Data Digit 2 = [3], Data Digit 3 = [3], Data Digit 4 = [2].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [4] [9] [6]
Enter Data Digit 1: [2]
Enter Data Digit 2: [3]
Enter Data Digit 1: [3]
Enter Data Digit 2: [2]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

Account Code programming defines the number transmitted to the central station that identifies this panel. It also identifies which partition is reporting from this panel.


Data Digits
1
2
3
4
Partition 1
Phone #1 Account Code = Address 0496
Phone #2 Account Code = Address 0498
Partition 2
Phone #1 Account Code = Address 0500
Phone #2 Account Code = Address 0502
Partition 3
Phone #1 Account Code = Address 0504
Phone #2 Account Code = Address 0506
Partition 4
Phone #1 Account Code = Address 0508
Phone #2 Account Code = Address 0510
Partition 5
Phone #1 Account Code = Address 0512
Phone #2 Account Code = Address 0514
Partition 6
Phone #1 Account Code = Address 0516
Phone #2 Account Code = Address 0518
Partition 7
Phone #1 Account Code = Address 0520
Phone #2 Account Code = Address 0522
Partition 8
Phone #1 Account Code = Address 0524
Phone #2 Account Code = Address 0526

The Default for all Account Codes = 0000

Notes:

1. Account Codes are programmed from left to right. If programming a 3 digit Account Code, the fourth digit of the address must be "0." For example: If the Account Code is 121, program 1210 in the programming address.

2. If you wish to send a zero "0," enter it as *0 (this does not apply to the added zero in a three digit Account Code). For example: If the Account Code is 101, program 1*010 in the programming address. If the Account Code is 3050, program 3*05*0 in the programming address.

 Copyright © 1995-96 Detection Systems, Inc.

12.28 Phone Number General Control Programming: Program Address (0528)

Example:
To program the parameters to enable the Remote Programmer Call-back feature, to dial Pulse on all Phone Numbers, to send Alarm Reports via either ARDIS or Digital, and to use 110 Baud comm. for WDSRP.

Data Digit 1 = [1], Data Digit 2 = [0].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [5] [2] [8]
Enter Data Digit 1: [1]
Enter Data Digit 2: [0]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

See Glossary (section 7.14) for further details.

Data Digit **1** **2** ☐ ☐

Select Options	Enter the Data Digit as a: 0	1	2	3	4	5	6	7	8	9	*0	*1
Enable remote programmer call-back		●		●		●		●		●		●
Dial pulse on all phone numbers	●	●					●	●				
Dial tone on all phone numbers**					●	●					●	●
Dial tone, switch to pulse if required			●	●					●	●		
Δ Δ Try ARDIS network first							●	●	●	●	●	●

*0 - *1 are Hex values. They will display as A - B at the keypads.
ΔΔ = If this option is selected, see address 0494-0495.
** = Required on PBX systems

Select Options	Enter the Data Digit as a: 0	1	2	3	4	5	6	7	8	9	*0	*1	*2	*3	*4	*5
Dialer delay of 15 sec. on non-24H burglar alarms only**		●		●		●		●		●		●		●		●
Dialer delay of 15 sec. on 24H burglar & fire alarms only**			●	●			●	●			●	●			●	●
Send alarms via **either** ARDIS **or** digital Δ	●	●	●	●					●	●	●	●				
Δ Δ Send alarms via **both** ARDIS **and** digital Δ***					●	●	●	●					●	●	●	●
Use 110 Baud comm. for WDSRP	●	●	●	●	●	●	●	●								
Use 300 Baud comm. for WDSRP									●	●	●	●	●	●	●	●

*0 - *5 are Hex values. They will display as A - F at the keypads.

Δ = Only applicable when using the ARDIS option.
Δ Δ = If this option is selected, see address 0494-0495.
** = These selections can only be used with systems that have only one partition.
*** = This selection must be chosen for U. L. Certificated installations when using the ARDIS module.

12.29 Phone Number Format Programming: Program Addresses (0529-0530)

Select Option	DD
Phone Number Disabled	**0**
3/1 (no Extended Reporting)	1
3/1E (Extended Reporting)	2
3/1 with Parity	3
3/1E with Parity	4
4/1	5
4/2	6
BFSK	7
SIA 110 Baud	8
Contact ID	9
SIA 300 Baud	*0
Pager	*5

Data Digit **1** **2** ☐ ☐

Select Options	Enter the DD as a: 0	1	2	3	4	5
1900 Hz. Data/1400 Hz. Acknowledge	●		●		●	
1800 Hz. Data/2300 Hz. Acknowledge		●		●		●
BFSK, SIA, Contact ID		●				
10 Pulses per Second (PPS)	●	●				
20 Pulses per Second (PPS)			●	●		
40 Pulses per Second (PPS)					●	●

*0 and *5 are Hex values. They will display as A and F at the keypads.

Note:
Phone Number 1 Format = Address 0529
Phone Number 2 Format = Address 0530

When using the ARDIS communications module:
Program address 0529 as: data digit 1 = 9, data digit 2 = 1.
Program address 0530 as: data digit 1 = 9, data digit 2 = 1.

Copyright © 1995-96 Detection Systems, Inc.

12.29.1 Compatable Receivers

The following table lists those Digital Alarm Communicator Receivers and Formats that are compatible with the DS7400Xi.

Note: Contact your central station regarding which format to use and if a special line card is required.

● = The Format type the DS7400Xi supports and the Digital Alarm Communicator Receiver accepts.

Receiver	Format								
	3/1	3/1 E (Extended)	3/1 w/Parity	3/1 E w/Parity	4/1	4/2	BFSK	Contact ID	SIA
ADEMCO: Model 685	●	●	●	●	●	●	●	●	
F.B.I.: Model CP-220	●	●	●	●	●	●	●	●	
I.T.I.: Model CS-4000	●	●			●	●	●		
Osborne-Hoffman: Model II	●	●	●	●	●	●	●	●	●
Radionics: Model 6000	●	●	●	●			●		
Radionics: Model 6500	●	●	●	●	●	●	●		
Silent Knight: Model 9000	●	●	●	●	●	●	●		●
Varitech: Model V-300	●	●	●	●	●	●	●		

12.30 Phone Answering Programming: Program Address (0531)

Example:
To program the Control Panel to answer the Phone after 2 rings when Armed and after 4 rings when Disarmed.

Data Digit 1 = [2], Data Digit 2 = [4].

Enter the Programmer's Mode:
[9] [8] [7] [6] [#] [0]

Enter the Program Address:
[0] [5] [3] [1]

Enter Data Digit 1: [2]
Enter Data Digit 2: [4]
Enter the pound key: [#]

Program the next Address, Program a different Address, or Exit the Programmer's Mode.

See Glossary (section 7.15) for further details.

Data Digit
1 2

Select Option When Armed:	
Don't Answer Phone	0
Answer Phone on 1 ring**	1
Answer Phone on 2 rings	2
Answer Phone on 3 rings**	3
Answer Phone on 4 rings	4
Answer Phone on 5 rings**	5
Answer Phone on 6 rings	6
Answer Phone on 7 rings**	7
Answer Phone on 8 rings	8
Answer Phone on 9 rings**	9
Answer Phone on 10 rings	*0
Answer Phone on 11 rings**	*1
Answer Phone on 12 rings	*2
Answer Phone on 13 rings**	*3
Answer Phone on 14 rings	*4
Answer Phone on 15 rings**	*5

*0 - *5 are Hex values.
They will display as A - F at the keypads.

** = Bypass answering machine.

Select Option When Disarmed:	
Don't Answer Phone	0
Answer Phone on 1 ring**	1
Answer Phone on 2 rings	2
Answer Phone on 3 rings**	3
Answer Phone on 4 rings	4
Answer Phone on 5 rings**	5
Answer Phone on 6 rings	6
Answer Phone on 7 rings**	7
Answer Phone on 8 rings	8
Answer Phone on 9 rings**	9
Answer Phone on 10 rings	*0
Answer Phone on 11 rings**	*1
Answer Phone on 12 rings	*2
Answer Phone on 13 rings**	*3
Answer Phone on 14 rings	*4
Answer Phone on 15 rings**	*5

*0 - *5 are Hex values.
They will display as A - F at the keypads.

** = Bypass answering machine.

Copyright © 1995-96 Detection Systems, Inc.

12.31 Programmers and Master Code Programming: Programming Addresses (0532-0534)

Example:
To program the Programmer's Code to be 3 4 4 3.

Data Digit 1 = [3], Data Digit 2 = [4],
Data Digit 3 = [4], Data Digit 4 = [3].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [0] [5] [3] [2]
Enter Data Digit 1: [3]
Enter Data Digit 2: [4]
Enter Data Digit 3: [4]
Enter Data Digit 4: [3]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

Programmer's Code programming defines what the Programmer's Code will be. This code is used to enter the programming mode from the keypads.



Programmer's Code
Enter as 4 digits.
It can not be the same as any PIN number.

The Default for the Programmer's Code = 9876

Master Code programming defines what the Master Code will be. This code is the highest authority level for a PIN.

If the Master Code is lost, this address may be used to program a new one. Otherwise, the Master Code Programming Mode should be used to create PINs that have a Master Code authority level.

Master Code for User Number 001 has its authority fixed at level 0. It will always have access to all partitions.



Master Code PIN Number
(Default for this User 001 is 1234)

Note:
User Numbers 002 through 090 must be programmed from the Master Code Programming Mode.

12.32 Octal Relay Module Output Programming: Program Addresses (1456-1471)

Example:
To program the Octal Relay Module's Output # 9 to follow Output Function 1.

Data Digit 1 = [*] [3], Data Digit 2 = [1],

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [1] [4] [6] [4]
Enter Data Digit 1: [*] [3]
Enter Data Digit 2: [1]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

Octal Relay #	DS7488-1 Addresses
1	1456
2	1457
3	1458
4	1459
5	1460
6	1461
7	1462
8	1463

Octal Relay #	DS7488-2 Addresses
9	1464
10	1465
11	1466
12	1467
13	1468
14	1469
15	1470
16	1471

The Octal Relay Module is the DS7488. See section 1.14 and 6.1.6 for further details.

Select Option	DD
Latch ON after Zone Alarm**	0
ON during Entry Pre-Alert	1
ON for 10 sec. after pressing [System Reset]	2
ON when System is Armed	3
Ground Start	4
System Status (Ready to Arm)	5
Zone Alarm	**6**
Zone Alarm delayed by 20 seconds	7
Keypad Sounder Output	8
Access Output (10 sec. pulse)	9
Panic/Duress Output***	*1
Follow System Wide Events	*2
Follow Output Functions	*3

Data Digit
1 **2**

See next page for programming options *2 and *3

** = This includes invisible zones. See glossary for further details.
*** = See section 7.4 for description of this option.

These two charts are for programming the Octal Relay Module to follow events by partition.

Octal Relay partition assignments are programmed in addresses 3725-2732. See Section 12.32.1

	Data Digit			
Follows	0	1	2	**3**
Disabled	●			
Burglar Alarm		●		●
Fire Alarm			●	●

Continued on next page

 Copyright © 1995-96 Detection Systems, Inc.

12.32 Octal Relay Module Output Programming: Program Addresses (1456-1471) (Continued)

Select Option	DD
Disabled	0
AC Power Fail	1
Low Battery	2
Communicator Failure	3
System Fault (Any)	4
Keypad Supervision Fault	5
Multiplex Bus Fault	6
Aux Power Fault	8
Fire Zone Trouble	9
Supervisory	*0
Zone Trouble	*1
Duress	*2
Battery Test	*3



*0 - *3 are Hex values.
They will display as A - D at the keypads.



Select Option	DD
Disabled	0
Follow Output Function 1	1
Follow Output Function 2	2
Follow Output Function 3	3
Follow Output Function 4	4
Follow Output Function 5	5
Follow Output Function 6	6
Follow Output Function 7	7
Follow Output Function 8	8
Follow Output Function 9	9
Follow Output Function 10	*0
Follow Output Function 11	*1
Follow Output Function 12	*2
Follow Output Function 13	*3
Follow Output Function 14	*4
Follow Output Function 15	*5

*0 - *5 are Hex values.
They will display as A - F at the keypads.

The Octal Relay Module is the DS7488.
See section 1.13 for further details.

To have the DS7488's relays follow the Output Functions, program Data Digit 1 of this address as a *3, then program data digit 2 as shown.

See System Overview (section 6.1.6) for further details.

To program the Output Functions, see section 12.33. Up to 15 Output Functions may be programmed.

12.32.1 Octal Relay Module Output Partition Assignment: Program Addresses (3725-3732)



Select Option	DD
Belongs to Partition 1	0
Belongs to Partition 2	1
Belongs to Partition 3	2
Belongs to Partition 4	3
Belongs to Partition 5	4
Belongs to Partition 6	5
Belongs to Partition 7	6
Belongs to Partition 8	7
Follows all Partitions	8

Copyright © 1995-96 Detection Systems, Inc.

12.33 Output Function Programming: Program Addresses (1472-1516)

Example:
To program the Output Function 1 to follow a Zone Burg Alarm.

Data Digit 1 = [6], Data Digit 2 = [1],

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [1] [4] [7] [2]
Enter Data Digit 1: [6]
Enter Data Digit 2: [1]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

Output programming allows you to have the Outputs follow status events by partition or system-wide, or follow zone outputs in an Input/Output Cross Matrix. See the Programming Addresses Worksheet (P/N 29802) for a description of each address. See System Overview (section 6.1.7) for further details.



*0 - *5 are Hex values. They will display as A - F at the keypads.

Select Option	DD
Latch ON after Zone Alarm	0
ON during Entry Pre-Alert	1
ON when system is armed	3
Zone alarm	6
Zone Alarm delayed by 20 sec.	7
Keypad Sounder output	8
Access output (10 sec. pulse)	9
Panic/Duress output**	*1
Follow System Status Event	*2
Follow a single zone	*3
Follow two zones-When EITHER zone changes state	*4
Follow two zones-When BOTH zones change state	*5

	Data Digit			
Follows	0	1	2	3
Disabled	●			
Burglar Alarm		●		●
Fire Alarm			●	●

Data Digit 1 Options 1-*1 are used to program an Output Function to follow status events for individual partitions.

Data Digit 1 Option *2 is used to program an Output Function to follow status events system-wide.

Data Digit 1 Options *3-*5 are used to program an Output Function to follow a zone or two zones in an Input/Output Cross Matrix.



Select Option	DD	DD	Select Option
AC Power Failure	1	7	Radio Receiver Fault
Low Battery	2	8	Aux Power Fault
Communication Failure	3	9	Fire Trouble
System Fault (any)	4	*0	Supervisory
Keypad Supervision Fault	5	*1	Zone Trouble
Multiplex Bus Fault	6	*2	Duress PIN

*0 - *2 are Hex values. They will display as A - C at the keypads.



	Enter Data Digit as a:												
Activate:	0	1	2	3	4	5	6	7	8	9	*0	*1	*2
Disabled	●												
When zone is shorted		●	●	●	●	●	●	●	●	●	●	●	●
When Zone is opened			●		●		●		●		●		●
When panel is Armed		●	●			●	●	●	●			●	●
When panel is not Armed				●	●	●	●			●	●	●	●
Latch when activated**								●	●	●	●	●	●

Enter the Zone Number of First Zone to Follow (01 - 99)

Enter the Zone Number of Second Zone to Follow (01 - 99)

** = This is only for DS7465 Outputs. DS7488 Outputs will not latch when this is selected.

Copyright © 1995-96 Detection Systems, Inc.

12.33.1 Output Function Partition Assignment: Program Addresses (3733-3740)

Program Address 3733

Data Digit 1	Data Digit 2
Function 1	Function 2

Program Address 3734

Data Digit 1	Data Digit 2
Function 3	Function 4

Program Address 3735

Data Digit 1	Data Digit 2
Function 5	Function 6

Program Address 3736

Data Digit 1	Data Digit 2
Function 7	Function 8

Program Address 3737

Data Digit 1	Data Digit 2
Function 9	Function 10

Program Address 3738

Data Digit 1	Data Digit 2
Function 11	Function 12

Program Address 3739

Data Digit 1	Data Digit 2
Function 13	Function 14

Program Address 3740

Data Digit 1	Data Digit 2
Function 15	Must Be 0

Select Option	DD
Belongs to Partition 1	0
Belongs to Partition 2	1
Belongs to Partition 3	2
Belongs to Partition 4	3
Belongs to Partition 5	4
Belongs to Partition 6	5
Belongs to Partition 7	6
Belongs to Partition 8	7
Follows all Partitions	8

12.34 Dual Phone Line/Bell Supervision Module Output Programming: Program Address (1520)

Example:
To program the Dual Phone Line/Bell Supervision Module to supervise Phone Line 1 and Phone Line 2.

Data Digit 1 = [2], Data Digit 2 = [0].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [1] [5] [2] [0]
Enter Data Digit 1: [2]
Enter Data Digit 2: [0]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

The Dual Phone Line/Bell Supervision Module is the DS7420i.
See section 1.13 for further details.
When in Central Station or Local Commercial Fire Mode, this address will be forced to specific values (see section 12.15.1 and 12.15.2).

Data Digit

1	2
	0

Options	Enter the Data Digit as a: 0	1	2	3	4	5	6	7	8	9
Disabled	●									
Bell Monitor				●	●	●			●	●
Phone Line 1 Monitor		●	●		●	●	●	●	●	●
Phone Line 2 Monitor			●			●		●		●
Alarm Output on line fault							●	●	●	●

Data Digit 2 must be a 0.

Copyright © 1995-96 Detection Systems, Inc.

12.35 Call-Out Timer Programming: Program Addresses (1521-1524)

Example:
To program the Remote Programmer Call-Out hour and minute as 2:30 pm.

Hour: Data Digit 1 = [1], Data Digit 2 = [4].
Minute: Data Digit 1 = [3], Data Digit 2 = [0].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [1] [5] [2] [3]
Enter Data Digit 1: [1]
Enter Data Digit 2: [4]
Enter the pound key: [#] (will go to Address 1524)
Enter Data Digit 1: [3]
Enter Data Digit 2: [0]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.

This section allows you to define the Hour and Minute for the Communicator Test Report and Remote Programmer Call-Out.

The default time for the Communicator Test Report to be sent and for the control to call the Remote Programmer is Midnight.



12.36 Test Report and Remote Programmer Call-Out Programming: Program Address (1525)

This section allows you to define the Day and Frequency for the Communicator Test Report and the Remote Programmer Call-Out.

If this address is not programmed, the Communicator Test Report will not be sent and the control will not call the Remote Programmer.

Example:
To send Test Reports on Sundays, and to call the Remote Programmer on Saturdays.

Data Digit 1 = [1], Data Digit 2 = [7].

Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0]
Enter the Program Address: [1] [5] [2] [5]
Enter Data Digit 1: [1]
Enter Data Digit 2: [7]
Enter the pound key: [#]
Program the next Address, Program a different Address, or Exit the Programmer's Mode.



Select Option	DD
Do not send a Test Report	0
Send a Test Report on Sunday	1
Send a Test Report on Monday	2
Send a Test Report on Tuesday	3
Send a Test Report on Wednesday	4
Send a Test Report on Thursday	5
Send a Test Report on Friday	6
Send a Test Report on Saturday	7
Send a Test Report every day	8
Send a Test Report every 8 days	9
Send a Test Report every 28 days	*0
Send a Test Report every hour	*1
Send a Test Report every 12 hours	*2

*0 - *2 are Hex values.
They will display as A - C at the keypads.

Select Option	DD
Do not call the Remote Programmer	0
Call the Remote Programmer on Sunday	1
Call the Remote Programmer on Monday	2
Call the Remote Programmer on Tuesday	3
Call the Remote Programmer on Wednesday	4
Call the Remote Programmer on Thursday	5
Call the Remote Programmer on Friday	6
Call the Remote Programmer on Saturday	7
Call the Remote Programmer every day	8
Call the Remote Programmer every 8 days	9
Call the Remote Programmer every 28 days	*0

Copyright © 1995-96 Detection Systems, Inc.

12.37 Alpha Description Programming: Program Addresses (1526-3701)

Alpha Description Programming allows up to 16 characters to be programmed for the description of each partition or zone (e.g. “J. Hill’s Office”). If a description is less than 16 characters, leave the remaining address(es) blank. Once programmed, the descriptions will be displayed on the alpha keypads.

The following chart lists the Program Addresses used to program Alpha-Numeric characters for each partition or zone:

Partition 1 Program Address **1526 - 1541**	**Partition 5** Program Address **1590 - 1605**	**Zone 1** Program Address **1654 - 1669**	**Zone 5** Program Address **1718 - 1733**
Partition 2 Program Address **1542 - 1557**	**Partition 6** Program Address **1606 - 1621**	**Zone 2** Program Address **1670 - 1685**	**Zone 6** Program Address **1734 - 1749**
Partition 3 Program Address **1558 - 1573**	**Partition 7** Program Address **1622 - 1637**	**Zone 3** Program Address **1686 - 1701**	**Zone 7** Program Address **1750 - 1765**
Partition 4 Program Address **1574 - 1589**	**Partition 8** Program Address **1638 - 1653**	**Zone 4** Program Address **1702 - 1717**	**Zone 8** Program Address **1766 - 1781**
	Zones 9 through 128 Program Addresses **1782 through 3701** (16 addresses per zone)		

See Section 12.37.1 for an Alpha Description Programming worksheet for Partitions 1 through 8 and Zones 1 through 8.
See the Programming Addresses Worksheet (P/N 29802) for a complete Alpha Programming Worksheet (covering addresses 1526 through 3701).

Words are created one character at a time. Each character uses two data digits.
The data digit values for these characters are shown below:

Value	Character	Value	Character	Value	Character	Value	Character
02	blank space	83	8	05	P	86	h
12	!	93	9	15	Q	96	i
22	"	*03	:	25	R	*06	j
32	#	*13	;	35	S	*16	k
42	$	*23	<	45	T	*26	l
52	%	*33	=	55	U	*36	m
62	&	*43	>	65	V	*46	n
72	'	*53	?	75	W	*56	o
82	(	04	@	85	X	07	p
92	)	14	A	95	Y	17	q
*02	*	24	B	*05	Z	27	r
*12	+	34	C	*15	[	37	s
*22	,	44	D	*25	¥	47	t
*32	-	54	E	*35	]	57	u
*42	.	64	F	*45	^	67	v
*52	/	74	G	*55	_	77	w
03	0	84	H	06	'	87	x
13	1	94	I	16	a	97	y
23	2	*04	J	26	b	*07	z
33	3	*14	K	36	c	*17	{
43	4	*24	L	46	d	*27	|
53	5	*34	M	56	e	*37	}
63	6	*44	N	66	f	*47	~
73	7	*54	O	76	g		

Example

	Character 1	Character 2	Character 3	Character 4	Character 5	Character 6	Character 7	Character 8
Text	C	H	E	M	I	C	A	L
Value	3 4	8 4	5 4	*3 4	9 4	3 4	1 4	*2 4
	1526-1 1526-2	1527-1 1527-2	1528-1 1528-2	1529-1 1529-2	1530-1 1530-2	1531-1 1531-2	1532-1 1532-2	1533-1 1533-2

Copyright © 1995-96 Detection Systems, Inc.

12.37.1 Alpha Description Programming: A Worksheet



 Copyright © 1995-96 Detection Systems, Inc.

12.37.1 Alpha Description Programming: A Worksheet (Continued)



 Copyright © 1995-96 Detection Systems, Inc.

12.37.1 Alpha Description Programming: A Worksheet (Continued)



 Copyright © 1995-96 Detection Systems, Inc.

12.37.1 Alpha Description Programming: A Worksheet (Continued)

Zone 5

	Character 1	Character 2	Character 3	Character 4	Character 5	Character 6	Character 7	Character 8
Text								
Value	1718-1 1718-2	1719-1 1719-2	1720-1 1720-2	1721-1 1721-2	1722-1 1722-2	1723-1 1723-2	1724-1 1724-2	1725-1 1725-2

	Character 9	Character 10	Character 11	Character 12	Character 13	Character 14	Character 15	Character 16
Text								
Value	1726-1 1726-2	1727-1 1727-2	1728-1 1728-2	1729-1 1729-2	1730-1 1730-2	1731-1 1731-2	1732-1 1732-2	1733-1 1733-2

Zone 6

	Character 1	Character 2	Character 3	Character 4	Character 5	Character 6	Character 7	Character 8
Text								
Value	1734-1 1734-2	1735-1 1735-2	1736-1 1736-2	1737-1 1737-2	1738-1 1738-2	1739-1 1739-2	1740-1 1740-2	1741-1 1741-2

	Character 9	Character 10	Character 11	Character 12	Character 13	Character 14	Character 15	Character 16
Text								
Value	1742-1 1742-2	1743-1 1743-2	1744-1 1744-2	1745-1 1745-2	1746-1 1746-2	1747-1 1747-2	1748-1 1748-2	1749-1 1749-2

Zone 7

	Character 1	Character 2	Character 3	Character 4	Character 5	Character 6	Character 7	Character 8
Text								
Value	1750-1 1750-2	1751-1 1751-2	1752-1 1752-2	1753-1 1753-2	1754-1 1754-2	1755-1 1755-2	1756-1 1756-2	1757-1 1757-2

	Character 9	Character 10	Character 11	Character 12	Character 13	Character 14	Character 15	Character 16
Text								
Value	1758-1 1758-2	1759-1 1759-2	1760-1 1760-2	1761-1 1761-2	1762-1 1762-2	1763-1 1763-2	1764-1 1764-2	1765-1 1765-2

Zone 8

	Character 1	Character 2	Character 3	Character 4	Character 5	Character 6	Character 7	Character 8
Text								
Value	1766-1 1766-2	1767-1 1767-2	1768-1 1768-2	1769-1 1769-2	1770-1 1770-2	1771-1 1771-2	1772-1 1772-2	1773-1 1773-2

	Character 9	Character 10	Character 11	Character 12	Character 13	Character 14	Character 15	Character 16
Text								
Value	1774-1 1774-2	1775-1 1775-2	1776-1 1776-2	1777-1 1777-2	1778-1 1778-2	1779-1 1779-2	1780-1 1780-2	1781-1 1781-2

Copyright © 1995-96 Detection Systems, Inc.

12.38 Phone Number Programming: Program Addresses (4028, 4038, 4048)

Example: To program Phone Number 1 as 555-1212.
Data Digit 1 = [5], Data Digit 2 = [5], Data Digit 3 = [5], Data Digit 4 = [1], Data Digit 5 = [2], Data Digit 6 = [1], Data Digit 7 = [2]
Enter the Programmer's Mode: [9] [8] [7] [6] [#] [0] Enter the Program Address: [4] [0] [2] [8] Enter Data Digit 1 = [5], Data Digit 2 = [5], Data Digit 3 = [5], Data Digit 4 = [1], Data Digit 5 = [2], Data Digit 6 = [1], Data Digit 7 = [2] Enter the pound key: [#] Program the next Address, Program a different Address, or Exit the Programmer's Mode.

14.34.1 Phone Number 1 Programming: Program Address (4028)



14.34.2 Phone Number 2 Programming: Program Address (4038)



14.34.3 Phone Number 3 (Remote Programmer) Programming: Program Address (4048)



Notes:

To dial the "*" character, enter *1 (The "*" character is sent as "1" "1" when pulse dialing).

To dial the "#" character, enter *2 (The "#" character is only valid when tone dialing).

To input a three second delay, enter *3.

To wait for the dial tone, enter *4 in the first digit.

To disable a Phone Number, enter *5 in the first digit.

(*1 - *5 are Hex values. They will display as B - E at the keypads.)

Recommendation: The phone line that the control panel is connected to should not have a Call Waiting feature. If it must have call waiting, program the code to disable call waiting and add a three second delay before the phone number. This will prevent incoming calls from interrupting a communication. For example: call waiting can be disabled in many areas by dialing *70 before the phone number for tone dial and 1170 for pulse dial.

Copyright © 1995-96 Detection Systems, Inc.

13.0 Installation Guide for U.L. Listed Systems

13.1 DS7400Xi U. L. Listings:

- Household Fire Alarm, U. L. Standard UL985
- Commercial Fire Alarm (Type Service: Local, Central Station, Remote Station; Type Initiating: Automatic, Manual, Sprinkler Supervisory, and Waterflow), U. L. Standard UL864
- Household Burglary Alarm, U. L. Standard UL1023
- Police Station Connection Grades AA and A, U. L. Standard UL365
- Central Station Burglary Alarm Grades AA, A, B, and C; U. L. Standard UL1610

The control panel should be installed in accordance with U. L. Standard UL681, Installation and Classification of Mercantile and Bank Burglar Alarm Systems, or U. L. Standard UL1641, Installation and Classification of Residential Burglar Alarm Systems. It should also be installed in accordance with NFPA 72 for Household and Commercial Fire installations.

13.1.1 U.L System Configurations

The following table shows the DS7400Xi system configuration for the various types of fire and burglar alarm service for which the product is U. L. Listed.

Product	U. L. Application								
	CSF-D	CSF-D/RF	LF	CSB-A	CSB-B/C	LB-A	PSCB-D-A	PSCB-RF-A	HF/B
DS7400Xi	R	R	R	R	R	R	R	R	R
Standard Enclosure	1	1	1	n/a	n/a	n/a	n/a	n/a	1
Attack Enclosure	1	1	1	R	R	R	R	R	1
AE-TR16 Enclosure	R	R	R	n/a	n/a	n/a	n/a	n/a	n/a
DS7416	n/a	R	n/a	R	n/a	n/a	n/a	R	n/a
DS7420i	R	4	R	4	n/a	n/a	n/a	4	n/a
DS7430	0	0	0	0	0	0	0	0	0
DS7432	0	0	0	0	0	0	0	0	0
DS7433	0	0	0	0	0	0	0	0	0
DS7447	2	2	2	3	3	3	3	3	3
DS7460	0	0	0	0	0	0	0	0	0
DS7481	n/a	4	n/a	4	n/a	n/a	n/a	4	n/a
DS7488	0	0	0	0	0	0	0	0	0
AB12 Bell w/Housing	n/a	n/a	n/a	R	R	R	R	R	n/a

Key to Application Codes

CSF-D = Central Station Fire w/ DACT (Digital Alarm Communications Transmitter/dialer)
CSF-D/RF = Central Station Fire w/ DACT and Radio (ARDIS System)
LF = Local Fire
CSB-A = Central Station Burglary, grades AA and A
CSB-B/C = Central Station Burglary, grades B and C
LB-A = Local Burglary, grade A
PSCB-D-A = Police Station Connected Burglary w/DACT, grade A
PSCB-RF-A = Police Station Connected Burglary w/Radio (AAGARD System - DS7416), grades AA and A
HF/B = Household (residential) Fire and Burglary

Configuration Codes

R = Required
0 = Optional
n/a = Not Applicable
1 = Standard or attack enclosure may be used.
2 = Either enclosure may be used. Device must be mounted to the enclosure cover, or within 20 ft. w/wiring in conduit.
3 = Either enclosure may be used.
4 = Either the DS7420i or the DS7481 must be used to monitor the phone line input to the control unit.

13.2 INSTALLATION CONSIDERATIONS

- Failure to install and program the control in accordance with the requirements in this section voids the listing mark of Underwriters Laboratories, Inc.
- The standby battery capacity is 35 AH @ 12 VDC.
- The total nominal standby current must not exceed 1.5 A nor 2.5 A when in alarm.
- The control must be mounted indoors and within the protected area.
- Enclosure tamper switches (if used) must be connected to a 24-hour zone.
- Grounding must be in accordance with article 250 of the NEC (NFPA 70).
- At least one U. L. Listed keypad with zone display must be connected.

Copyright © 1995-96 Detection Systems, Inc.

- Zones must be connected to U. L. Listed, compatible devices.
- 50 Hz. AC input cannot be used in U. L. Listed Requirements.
- The ground wire provided with the enclosure must be connected between the “Earth GND” connection on the control and the enclosure tab.
- The keypad panic alarm output must follow the corresponding zone function’s programming (e.g. fire = pulsing [or steady if not a combination], burglary = steady). In all cases, the special emergency keys must be silent.
- The ground start feature shall not be programmed.

13.3 PROGRAMMING THE DS7400Xi

When used in U. L. Listed Requirements, the control must conform to certain programming requirements. The following is a list of the required program entries and required accessories for specific U. L. Listed Requirements.

13.3.1 Household Fire Alarm using Digital Alarm Communicator Transmitter with local bell

The control must be installed in accordance with NFPA 72.

Required Accessories:

- At least one Detection Systems, Inc. Model DS250 Series smoke detector with an MB Series base, or another Listed compatible smoke detector.
- One Wheelock 46T-G10-12 bell or 34T-12 horn (will provide 85db for UL985 and NFPA 72 requirements; other Listed compatible devices with a voltage range of 10.2 to 14.0 V may be used) is required for this application and must be installed inside the protected area.
- The standard control enclosure can be used.
- At least one DS7447 or DS7445 Keypad must be used.
- Four-wire detectors must be used with Listed power supervision devices. A compatible Listed 4-wire detector is the Detection Systems, Inc. DS250 in an MB4W base. A compatible Listed EOL relay is the Detection Systems, Inc. EOL200.
- All zones must be used with the EOL resistor (P/N 25899), provided.

1. Report Programming:

- Fire Zone Report must be programmed.
- Low Battery Report (Program Address 0325) must be programmed.
- AC Failure Report (Program Address 0327) must be programmed.

2. Timer Programming:

- Bell Cutoff Times (Program Addresses 0195 and 0196) must be programmed for not less than 4 minutes.

3. Zone Function Programming:

- For household fire installations only, the output signal may be pulsed or steady. For a combination system, see the selection below on alarm output programming.

4. Alarm Output Programming:

- Program Address 0146 must be programmed as: Data Digit 1=6, Data Digit 2=3.

5. General Control Programming:

- Program Address 0185 must be programmed as: Data Digit 1=0, Data Digit 2=0.

13.3.2 Grade A Household Burglary Alarm using Digital Alarm Communicator Transmitter with local bell

The control must be installed in accordance with U. L. Standard UL1641.

Required Accessories:

- At least one Wheelock 46T-G10-12 bell or 34T-12 horn (other Listed compatible devices with a voltage range of 10.2 to 14.0 V may be used) is required for this application.
- The standard DS7400 enclosure can be used.

1. Report Programming:

- Burglar Zone Reports must be programmed for those zones used.
- Low Battery Report (Program Address 0325) must be programmed.
- AC Failure Report (Program Address 0327) must be programmed.

2. Timer Programming:

- Bell Cutoff Times (Program Addresses 0195 and 0196) must be programmed for not less than 4 minutes.
- Entry Delay Timer (Program Addresses 0191 and 0192) must be programmed for not longer than 60 seconds.
- Exit Delay Timer (Program Address 0193) must be programmed for not longer than 45 seconds.

3. General Control Programming:

- Program Address 0000, Data Digit 2 must be programmed for NO Swinger Shunts (enter 0, 1, or 2).
- Program Address 0185 must be programmed as: Data Digit 1=0, Data Digit 2=0.

 Copyright © 1995-96 Detection Systems, Inc.

4. Alarm Output Programming:
- Program Address 0146 must be programmed as: Data Digit 1=6, Data Digit 2=3.
- Program Address 0149 must be programmed as: Data Digit 1=8.

NOTE: In a system that includes both fire alarm and burglar alarm devices, the system must produce distinct sounds for fire and burglar alarm conditions either by using different indicating appliances or by using distinct cadences for the same appliance.

13.4 General System Requirements

Applies to the following grades only:

Local Burglary Alarm -	Grade A using Digital Alarm Communicator Transmitter (DACT)
Police Station Connection -	Grades AA and A using DACT and ARDIS interface module. Grade A using DACT and local Bell.
Central Station Burglary Alarm -	Grades AA and A using DACT and ARDIS interface module. Grade B using DACT and local bell. Grade C using using Digital Alarm Communicator Transmitter only.

The controls must be installed in accordance with U. L. Standards UL681 and UL609 for all grades of service.

1. Report Programming:
- Burglar Zone Reports must be programmed for those zones used.
- Low Battery Report (Program Address 0325) must be programmed.
- AC Failure Report (Program Address 0327) must be programmed.
- Open Report (Program Address 0320) must be programmed.
- Close Report (Program Address 0321) must be programmed.
- 24-Hour Check-In Reports (Program Addresses 0329 and 0336) must be programmed.

2. General Control Programming:
- Must be programmed for no swinger shunts and closing ringback. (Program Address 0000 data digit 2, enter 0, 1, or 2).
- Program Address 0185 must be programmed as: Data Digit 1=0, Data Digit 2=0.

3. Zone Function Programming:
- The Burglar alarm signal (whether pulsed or steady) must be different from the Fire alarm signal.

4. Alarm Output Programming:
- Program Address 0146 must be programmed as: Data Digit 1=6, Data Digit 2=3.
- Program Address 0149 must be programmed as: Data Digit 1=8.

13.4.1 Local Burglary Alarm

A. Grade A Installations using Digital Alarm Communicator Transmitter with local bell

Follow General System Requirements as listed in 13.4.

Required Accessories:
- The control must be the Detection System's model DS7400XiCC with a cover actuated tamper switch installed.
- An Ademco Model AB-12 bell/housing* (see section 13.6).

1. Timer Programming:
- Bell Cutoff Times (Program Addresses 0195 and 0196) must be programmed for not less than 15 minutes.
- Entry, Exit Delay Times (Program Addresses 0191-0193) must be programmed for not longer than 60 seconds.

13.4.2 Police Station Connection

Follow General System Requirements as listed in 13.4.

Required Accessories:
- The control must be the Detection Systems' model DS7400XiCC with a cover actuated tamper switch installed.
- An ARDIS (or DataTAC) interface module.
- The ARDIS module and antenna should be mounted within the protected area.
- The Detection Systems' model DS7481 Phone Line Monitor.

1. Timer Programming:
- Entry, Exit Delay Times (Program Addresses 0191-0193) must be programmed for not longer than 60 seconds.

 Copyright © 1995-96 Detection Systems, Inc.

B. Grade A Installations using Digital Alarm Communicator Transmitter with local bell

Follow General System Requirements as listed in 13.4.

Required Accessories:
- The control must be the Detection System's model DS7400XiCC with a cover actuated tamper switch installed.
- The Ademco Model AB-12 bell/housing* (see section 13.6).

1. Timer Programming:
- Bell Cutoff Times (Program Addresses 0195 and 0196) must be programmed for not less than 15 minutes.
- Entry, Exit Delay Times (Program Addresses 0191-0193) must be programmed for not longer than 60 seconds.

13.4.3 Central Station Burglary Alarm

A. Grades AA and A Installations using an ARDIS Interface Module

Follow General System Requirements as listed in 13.4.

Required Accessories:
- The control must be the Detection Systems' model DS7400XiCC with a cover actuated tamper switch installed.
- An ARDIS (or DataTAC) interface module.
- The ARDIS module and antenna should be mounted within the protected area.
- The Detection Systems' model DS7481 Phone Line Monitor.

1. Timer Programming:
- Entry, Exit Delay Times (Program Addresses 0191-0193) must be programmed for not longer than 60 seconds.

B. Grade B Installations using Digital Alarm Communicator Transmitter with local bell

Follow General System Requirements as listed in 13.4.

Required Accessories:
- The control must be the Detection Systems' model DS7400XiCC with a cover actuated tamper switch installed.
- The Ademco Model AB-12 bell/housing* (see section 13.6).

1. Timer Programming:
- Bell Cutoff Times (Program Addresses 0195 and 0196) must be programmed for not less than 15 minutes.
- Entry, Exit Delay Times (Program Addresses 0191-0193) must be programmed for not longer than 60 seconds.

C. Grade C Installations using Digital Alarm Communicator Transmitter only

Follow General System Requirements as listed in 13.4.

Required Accessories:
- The control must be the Detection System's model DS7400XiCC with a cover actuated tamper switch installed.

1. Timer Programming:
- Entry, Exit Delay Times (Program Addresses 0191-0193) must be programmed for not longer than 60 seconds.

13.5 Commercial Fire Alarm

A. Central Station (DACT) and Local
The control must be installed in accordance with NFPA 72.

Required Accessories:
- DS7420i Dual Phone Line/Bell Supervision Module.
- For Local Commercial Fire Alarm: A Listed notification appliance such as a Wheelock 46T-G10-12 bell or 34T-12 horn.
- If not using the phone line supervision, it must be disabled.
- AE-TR16 Transformer Housing.
- At least one DS7447 must be used and assigned as keypad 1. If only one is used, it may be connected to the keypad bus if the keypad is mounted to the front of the box or within the same room as the control equipment and the wire is run in conduit (or equivalently protected against mechanical injury) within 20 ft. (6.1 m) of the control equipment. If multiple keypads are used, one keypad only must be used on the options bus and assigned as keypad 11-14 and meet the same requirements as in single keypad use.
- 50 Hz. operation and ground start are automatically forced to the disabled state when central station fire mode is selected.

 Copyright © 1995-96 Detection Systems, Inc.

1. Report Programming:
- Burglar Zone Reports must be programmed for those zones used.
- Fire Zone Reports must be programmed for those zones used.
- Low Battery Report (Program Address 0325) must be programmed.
- AC Failure Report (Program Address 0327) must be programmed.
- Open Report (Program Address 0320) must be programmed.
- Close Report (Program Address 0321) must be programmed.
- 24-Hour Check-In Reports (Program Addresses 0329 and 0336) must be programmed.

2. Timer Programming:
- Bell Cutoff Times (Program Addresses 0195 and 0196) must be programmed for not less than 5 minutes.
- Entry, Exit Delay Times (Program Addresses 0191-0193) must be programmed for not longer than 60 seconds.

3. General Control Programming:
- Must be programmed for no swinger shunts (Program Address 0000 data digit 2, enter 0, 1, or 2).
- Program Address 0185 must be programmed as: Data Digit 1=0, Data Digit 2=0.

4. Commercial Fire Mode Programming:
- Local (Program Address 0186, data digit 1, enter as a 1 through 6).
- Central Station (Program Address 0186, data digit 1, enter as a 7 through *2).
- The keypad panic functions are not intended to be a substitute for Listed manual pull boxes.

13.6 Wiring and Programming information for installations using the Ademco AB-12 Bell/Housing





1) Disconnect the wire jumper from terminal 4 to the inner housing of the Bell Box (prevents a ground fault condition).
2) Connect wiring between the control and Bell Box as shown above. To use the AB-12 Bell/Housing, cut the jumper wire "JP1" on the control. The EOL used in the AB-12 Bell/Housing must be 27K ohms.
3) Program Zone 8 as a 24-hour zone by programming it to follow zone function 7. (Program address 0025 = 07).
4) Do not change the default programming of zone function 7. (Program address 0007 should be 22).

 Copyright © 1995-96 Detection Systems, Inc.

14.0 Report Programming

14.1 4/2 Format

Reports with Restorals

	Report			Restoral			Trouble		
	Address	Value		Address	Value		Address	Value	
Zone Function 1	0258	A	1	0275	2	1	0290	6	1
Zone Function 2	0259	A	2	0276	2	2	0291	6	2
Zone Function 3	0260	A	3	0277	2	3	0292	6	3
Zone Function 4	0261	A	4	0278	2	4	0293	6	4
Zone Function 5	0262	A	5	0279	2	5	0294	6	5
Zone Function 6	0263	A	6	0280	2	6	0295	6	6
Zone Function 7	0264	A	7	0281	2	7	0296	6	7
Zone Function 8	0265	A	8	0282	2	8	0297	6	8
Zone Function 9	0266	A	9	0283	0	0	0298	6	9
Zone Function 10	0267	1	A	0284	2	A	0299	6	A
Zone Function 11	0268	1	1	0285	2	A	0300	6	B
Zone Function 12	0269	1	2	0286	2	A	0301	6	C
Zone Function 13	0270	1	3	0287	2	A	0302	6	D
Zone Function 14	0271	1	4	0288	2	A	0303	6	E
Zone Function 15	0272	1	5	0289	2	A	0304	6	F
Low Battery	0325	7	9	0326	6	9			
AC Fail	0327	7	A	0328	6	A			
System Trouble	0334	0	0	0335	3	9			
Keypad Fire	0256	1	8	0257	2	8			
Keypad Emergency	0273	1	6						
Keypad Panic	0274	A	A						

Reports without Restorals

	Report		
	Address	Value	
Open	0320	9	F
Close	0321	4	F
Partial Close	0322	4	F
First Open after Alarm	0324	3	8
Comm. Test/System Normal	0329	3	A

	Report Successful			Report Unsuccessful		
	Address	Value		Address	Value	
Remote Program	0330	0	0	0331	0	0
Local Program	0332	0	0	0333	0	0

	Report		
	Address	Value	
Duress	0322	1	5

Copyright © 1995-96 Detection Systems, Inc.

14.2 BFSK Format

Reports with Restorals

	Report			Restoral			Trouble		
	Address	Value		Address	Value		Address	Value	
Zone Function 1	0258	1	0	0275	E	1	0290	F	1
Zone Function 2	0259	2	0	0276	E	2	0291	F	2
Zone Function 3	0260	3	0	0277	E	3	0292	F	3
Zone Function 4	0261	4	0	0278	E	4	0293	F	4
Zone Function 5	0262	5	0	0279	E	5	0294	F	5
Zone Function 6	0263	6	0	0280	E	6	0295	F	6
Zone Function 7	0264	7	0	0281	E	7	0296	F	7
Zone Function 8	0265	8	0	0282	E	8	0297	F	8
Zone Function 9	0266	8	0	0283	E	8	0298	F	9
Zone Function 10	0267	8	0	0284	E	8	0299	F	8
Zone Function 11	0268	8	0	0285	E	8	0300	F	8
Zone Function 12	0269	8	0	0286	E	8	0301	F	8
Zone Function 13	0270	8	0	0287	E	8	0302	F	8
Zone Function 14	0271	8	0	0288	E	8	0303	F	8
Zone Function 15	0272	8	0	0289	E	8	0304	F	8
Low Battery	0325	F	9	0326	E	9			
AC Fail	0327	F	A	0328	E	A			
System Trouble	0334	F	D	0335	E	D			
Keypad Fire	0256	1	0	0257	E	1			
Keypad Emergency	0273	0	0						
Keypad Panic	0274	9	0						

Reports without Restorals

	Report		
	Address	Value	
Open	0320	B	F
Close	0321	C	F
Partial Close	0322	C	F
First Open after Alarm	0324	D	F
Comm. Test/System Normal	0329	E	E

	Report Successful		
	Address	Value	
Remote Program	0330	E	F
Local Program	0332	E	F

Report Unsuccessful		
Address	Value	
0331	F	F
0333	F	F

	Report		
	Address	Value	
Duress	0322	A	0

Copyright © 1995-96 Detection Systems, Inc.

14.3 Pager Format

The Pager format allows the control panel to dial a digital pager and leave a numeric message which includes an account ID and report type. The telephone number is dialed when a report is available. At the completion of the telephone dialing, a fixed time delay equal to 10 seconds occurs. This delay allows time to connect with the pager service, while skipping over any voice announcement. When the delay has ended, the numeric message is sent. This message includes the account number followed by up to 5 reports. If a delay time greater than 10 seconds is required, increments of 3 seconds can be added by programming the "*3" character (3 second delay) at the end of the phone number in address 4028 or 4038.

For example, if you call pager number 123-4567 and it takes 20 seconds after you finished dialing before you are allowed to enter the message, the following digits should be programmed in address 4028: 1 2 3 4 5 6 7 *3 *3 *3 *3. This will give you an overall delay of 22 seconds.

NOTE: For Pager format, it is not advisable to use the HEX character values (*0 = A, *1 = B, *2 = C, *3 = D, *4 = E, *5 = F) in the report programming addresses 0256 through 0340. These characters could cause unpredictable results when sent to a pager system that only expects numeric characters between 0-9. This is the reason that this format will not allow an associated user number with an open and close report.

CAUTION: Pager Format allows the use of the digit "0" as the reporting (first) digit. Using a "0" as the reporting digit will disable the reporting in all other formats.

The following are recommended programming values for addresses 0256 through 0340 when using the Pager format.

NOTE: The Pager format is an open-loop format which has no acknowledge tone. There is no indication at the control panel that the signal has been sent. Therefore, the Pager format is not recommended as the primary communication method.

Reports with Restorals

	Report			Restoral			Trouble		
	Address	Value		Address	Value		Address	Value	
Zone Function 1	0258	0	1	0275	2	1	0290	4	1
Zone Function 2	0259	0	2	0276	2	2	0291	4	2
Zone Function 3	0260	0	3	0277	2	3	0292	4	3
Zone Function 4	0261	0	4	0278	2	4	0293	4	4
Zone Function 5	0262	0	5	0279	2	5	0294	4	5
Zone Function 6	0263	0	6	0280	2	6	0295	4	6
Zone Function 7	0264	0	7	0281	2	7	0296	4	7
Zone Function 8	0265	0	8	0282	2	8	0297	4	8
Zone Function 9	0266	0	9	0283	2	9	0298	4	9
Zone Function 10	0267	1	0	0284	3	0	0299	5	0
Zone Function 11	0268	1	1	0285	3	1	0300	5	1
Zone Function 12	0269	1	2	0286	3	2	0301	5	2
Zone Function 13	0270	1	3	0287	3	3	0302	5	3
Zone Function 14	0271	1	4	0288	3	4	0303	5	4
Zone Function 15	0272	1	5	0289	3	5	0304	5	5

Continued on next page

 Copyright © 1995-96 Detection Systems, Inc.

Reports with Restorals

	Report			Restoral		
	Address	**Value**		**Address**	**Value**	
Low Battery	0325	6	0	0326	7	0
AC Fail	0327	6	1	0328	7	1
System Trouble	0334	6	2	0335	7	2
Keypad Fire	0256	9	0	0257	9	1
System Test	0339	6	5	0340	7	5

Reports without Restorals

	Address	Value	
Open	0320	8	0
Close	0321	8	1
Partial Close	0322	8	2
First Open after Alarm	0324	8	3
Exit Error	0337	8	6
Recent Closing	0338	8	7
Keypad Emergency	0273	9	2
Keypad Panic	0274	9	3
Duress	0322	9	4

	Report Successful			**Report Unsuccessful**		
	Address	**Value**		**Address**	**Value**	
Remote Program	0330	E	F	0331	F	F
Local Program	0332	E	F	0333	F	F

Copyright © 1995-96 Detection Systems, Inc.

15.0 Report Programming - Values Sent

15.1 SIA Format

Reports	SIA event code		SIA data field
Burglary alarm for a zone	B	A	Zone Number
Fire alarm for a zone	F	A	Zone Number
Waterflow alarm for a zone	S	A	Zone Number
Supervisory for a zone	S	S	Zone Number
Keypad fire (A)	F	A	000
Keypad fire restoral (A)	F	R	000
Keypad emergency (1, 3, or B)	Q	A	None
Keypad panic (*, #, or C)	P	A	None
Burglary restoral for a zone	B	R	Zone Number
Fire restoral for a zone	F	R	Zone Number
Waterflow restoral for a zone	S	R	Zone Number
Supervisory restoral for a zone	S	J	Zone Number
Burglary trouble for a zone	B	T	Zone Number
Fire trouble for a zone	F	T	Zone Number
Waterflow trouble for a zone	F	T	Zone Number
Supervisory trouble for a zone	F	T	Zone Number
Low battery on a radio zone	X	T	Zone Number
Low battery restoral on a radio zone	X	R	Zone Number
Open report	O	P	User Number
Close report	C	L	User Number
Duress report	H	A	000
Partial close report	C	G	User Number
First open after alarm (cancel) report	O	R	None
Low battery	Y	T	None
Low battery restoral	Y	R	None
AC failure	A	T	None
AC failure restoral	A	R	None
Octal relay fault report	E	T	None
Octal relay restoral	E	R	None
Exit error report	E	E	None
Recent closing report	C	R	None
System test start report	T	S	None
System test end report	T	E	None

Continued on next page

 Copyright © 1995-96 Detection Systems, Inc.

15.1 SIA Format (Continued)

Reports	SIA event code		SIA data field
System normal test report	R	P	None
Communicator test report	R	X	None
Remote programming successful report	R	S	None
Remote programming failure report	R	U	None
Local programming successful report	Y	G	None
Local programming failure report	Y	F	None
Communication failure report	Y	C	None
Communication restoral	Y	K	None
EEPROM checksum failure or keypad supervision failure report	E	T	None
EEPROM checksum restoral or keypad supervision restoral	E	R	None
Multiplex bus fault	E	T	None
Multiplex bus restoral	E	R	None
Radio receiver tamper	T	A	None
Radio receiver tamper restoral	T	R	None
Aux. power fault report	Y	P	None
Aux. power restoral	Y	Q	None
Ground fault report	U	T	None
Ground fault restoral	U	J	None
System off normal test report	R	P	None
Phone line 1 fault report	L	T	None
Phone line 1 restoral	L	R	None
Phone line 2 fault report	L	T	None
Phone line 2 restoral	L	R	None
AAGARD fault report	Y	S	See 9.18 Error Displays
AAGARD fault restoral	Y	K	See 9.18 Error Displays
Bell fault report	E	T	None
Bell restoral	E	R	None
RAM fault report	E	T	None
RAM restoral	E	R	None
ROM fault report	E	T	None
ROM restoral	E	R	None
Serial interface fault report	V	T	None
Serial interface restoral	V	R	None
Aux. relay fault report	E	T	None
Aux. relay restoral	E	R	None

Copyright © 1995-96 Detection Systems, Inc.

15.2 Contact I.D Format

Reports	CID event code	CID data field
Burglary alarm for a zone	130	Zone Number
Fire alarm for a zone	110	Zone Number
Waterflow alarm for a zone	113	Zone Number
Supervisory for a zone	200	Zone Number
Keypad fire (A)	110	000
Keypad fire restoral (A)	110 Restoral	000
Keypad emergency (1, 3, or B)	122	None
Keypad panic (*, #, or C)	123	None
Burglary restoral for a zone	130 Restoral	Zone Number
Fire restoral for a zone	110 Restoral	Zone Number
Waterflow restoral for a zone	113 Restoral	Zone Number
Supervisory restoral for a zone	200 Restoral	Zone Number
Burglary trouble for a zone	370	Zone Number
Fire trouble for a zone	373	Zone Number
Waterflow trouble for a zone	373	Zone Number
Supervisory trouble for a zone	373	Zone Number
Low battery on a radio zone	384	Zone Number
Low battery restoral on a radio zone	384 Restoral	Zone Number
Open report	401	User Number
Close report	401 Restoral	User Number
Duress report	121	000
Partial close report	408 Restoral	User Number
First open after alarm (cancel) report	406	None
Low battery	302	None
Low battery restoral	302 Restoral	None
AC failure	301	None
AC failure restoral	301 Restoral	None
RAM fault report	303	None
RAM restoral	303 Restoral	None
ROM fault report	304	None
ROM restoral	304 Restoral	None
Serial interface fault report	336	None
Serial interface restoral	336 Restoral	None

Continued on next page

 Copyright © 1995-96 Detection Systems, Inc.

15.2 Contact ID Format (Continued)

Reports	CID event code	CID data field
System normal test report	602	None
Communicator test report	601	None
Remote programming successful report	412	None
Remote programming failure report	413	None
Local programming successful report	306	None
Local programming failure report	306 Restoral	None
Communication failure report	354	None
Communication restoral	354 Restoral	None
EEPROM checksum failure or keypad supervision failure report	330	None
EEPROM checksum restoral or keypad supervision restoral	330 Restoral	None
Multiplex bus fault	333	None
Multiplex bus restoral	333 Restoral	None
Radio receiver tamper	137	None
Radio receiver tamper restoral	137 Restoral	None
Aux. power fault report	300	None
Aux. power restoral	300 Restoral	None
Ground fault report	310	None
Ground fault restoral	310 Restoral	None
System off normal test report	602	None
Phone line 1 fault report	351	None
Phone line 1 restoral	351 Restoral	None
Phone line 2 fault report	352	None
Phone line 2 restoral	352 Restoral	None
AAGARD fault report	353	See 9.18 Error Displays
AAGARD fault restoral	353 Restoral	See 9.18 Error Displays
Bell fault report	321	None
Bell restoral	321 Restoral	None
Aux. relay fault report	320	None
Aux. relay restoral	320 Restoral	None
Octal relay fault report	330	None
Octal relay restoral	330 Restoral	None
Exit error report	134	None
Recent closing report	405	None
System test start report	607	None
System test end report	607 Restoral	None

Copyright © 1995-96 Detection Systems, Inc.

16.0 Multiplex Zone Addressing Guide

- Before installing a multiplex device, its address and other information must be programmed into the control panel. Perform the following:
- Program the control panel.
  - Refer to section 14.3, Zone Programming.
    This section allows you to define the Multiplex Zone's address (zone number), its type (single or multiple zone input device, or a DS7465), which zone or output function it will follow (1-15) and its partition (1-8).
    For example: Program zone 9 to be a single zone input device (DS7476) that follows zone function 1 and is in partition 1.

    Procedure: Enter the programmer's mode.
    Enter address 0026.
    Enter the data digits as [0] and [1] followed by the [#] button.
    Enter address 1252.
    Enter the data digits as [0] and [0] followed by the [#] button.
    Exit the programmer's mode.

  - Program the BusLoc® feature.

    At this point, you must decide whether or not to use the BusLoc® feature.

    BusLoc® is a proprietary method of tying the multiplex zones to the control panel to prevent the system from being taken over. Using BusLoc® will program an invisible identification code into the multiplex zones.

Note: If using the DS7432 8-Input Remote Module or the DS7433 8-Input Direct Module, the BusLoc® feature can not used.

  - If you choose to use the BusLoc® feature, program a 5 digit code at programming address 9999.
    It is very important to save this code under lock and key. If you need to replace the control panel, you will have to program it with the same BusLoc® code as the previous panel or the multiplex devices will not match codes with the new control panel.

    For example: Program the BusLoc® code to be 54321.

    Procedure: Enter the programmer's mode.
    Enter address 9999.
    Enter the data digits as [5], [4], [3], [2], and [1] followed by the [#] button.
    Exit the programmer's mode.

- Once the pre-programming is done, you are ready to program the multiplex devices. Perform the following:

- Disconnect all multiplex devices from the DS7430.

- Program the multiplex devices through the control panel. Perform the following:

  - Enter the programmer's mode.

  - Enter the multiplex programming mode.
    Do this by entering [9] [9] [9] [5] followed by the [#] button.

  - The control will then take a few seconds to check the multiplex connection to confirm nothing is connected to it. The display will show the following:

Checking
Multiplex Bus

  - The display will then call-up the first zone you have pre-programmed to be a multiplex zone. To access a different zone, press the [Reset/*] key, then enter the three digit value of the zone you want. The display will show the following:

Sens/Contact 009
Press # to Prog

Before you do anything else, re-connect the multiplex device (that coincides with the displayed zone) to the multiplex bus of the DS7430.

For DS7465s and Multiple Input devices, pressing the [#] button now will program these devices to the control panel. Remember, these devices take up two addresses. When address 009 (for example) is a DS7465, pressing the [#] button now will program both addresses 009 and 010.

For Single Input devices, press the [#] button to continue programming. The display asks whether you are programming a sensor or a contact; it will show the following:

Sensor? Press 4
Contact? Press 6

If you are programming a sensor, press the [4] button to program these devices to the control panel. If you are programming a contact, press the [6] button to program these devices to the control panel.

  - If the device is successfully programmed, the keypad will sound a single beep and increment to the next zone (if there is one) pre-programmed as a multiplex zone.

Important: Disconnect the device you just programmed and connect the next device (that belongs to the displayed zone) to the multiplex bus of the DS7430 and press the [#] button. Continue programming.

Caution: 24-hour zones will alarm when you exit the programmer's mode. Alarm reports for these zones will be sent if they have been programmed. If you do not want these reports sent, disconnect power from the system now by unplugging the transformer and removing the red battery lead. Do not reconnect power until all zones have been installed and connected to the multiplex bus.

  - If no other zones have been pre-programmed, the display will show the following:

Mux Zone
Enter Zone

  - You may now exit the Zone Programmer's mode by pressing the [*/Reset] button for 2 seconds. This brings you back to the Programmer's Mode. To exit the Programmer's Mode, press the [*/Reset] button for 2 seconds.

  - If the zone is unsuccessfully programmed, the keypad will sound a three-beep error tone.

 Copyright © 1995-96 Detection Systems, Inc.

17.0 Troubleshooting Guide

17.1 Keypad Problems

Symptom	Probable Cause	Possible Solution
Entry Error: **Please Re-enter** will display on keypad. A three beep error tone will sound continuously.	a) Two or more keypads share the same address. b) The DS7430 or DS7433 is installed in the wrong pins.	a) Install keypad jumper properly in back of keypads. b) Be sure the DS7430 or DS7433 is installed properly.
Keypad displays **Not Programmed, See Instal Guide**, sounder is on and the keypad does not operate.	a) The keypad not addressed properly. b) The keypad is not programmed properly. c) Keypads 11-15 are not properly configured.	a) Install the keypad jumper properly in the back of the keypad. b) Check keypad programming addresses 0173-0180. c) Check keypad addresses 11-15. System will only see keypads on the options bus.
Keypad displays **Ready to arm, partition 1** when using only one partition. Keypad displays **System Fault**, sounder is on, and the keypad does not operate.	The keypad is programmed as a Master keypad. a) Keypad wiring error. b) Keypad(s) assigned to wrong or non-existent partition. c) The microprocessor isn't running.	Master keypads can only be used on multi-partition systems. Program the keypad as a standard keypad. a) Check wiring. b) Assign the keypad(s) to correct partition. If none of the keypads are correctly assigned, re-enable keypad 1 by shorting the program contacts in the lower right corner of the main panel board. This will force program mode and assign keypad 1 as alpha, non-master to partition 1. c) Disconnect battery and any aux. power load. If the microprocessor has shut down, aux. power will read approx. 11.5 VDC. If the EEProm chip has been field-replaced, power down AC and battery, and check for bent or mis-inserted pins; Otherwise, replace the panel.
Keypad alpha display is locked up, but the keys still function.	The keypad is enabled, but as an LED keypad.	Enter the program mode at the keypad and input the correct sequence to re-enable it as an alpha keypad. Care must be taken, since there will be no visual feedback to verify programming until the keypad is properly enabled.
Can't read back history with # 89 input.	a) Entering from Master keypad. b) Not using a PIN with test authority.	a) First enter Single Partition Mode. b) Use a PIN with test authority.
In history, the Read-back for the A, B, and C keys shows: A = Fire B = Emergency C = Panic But, the Central Station transmissions display B as Silent Panic and C as Audible Panic.	Formats display information regarding the B and C keys differently. In Contact ID: A = Fire B = Silent Panic C = Audible Panic In SIA: A = Fire B = Emergency C = Panic	Discrepancy exists in the definition of these keys in the two formats. Whatever the keys are programmed for in the panel, that is what will be sent.
Can not perform a zone test (#81).	a) Entering from a Master keypad. b) Not using a PIN with test authority.	a) Zone test is not available from a Master keypad. b) Use a PIN with test authority.

Copyright © 1995-96 Detection Systems, Inc.

Keypad Problems (Continued)

Symptom	Probable Cause	Possible Solution
Chime Mode (#7) does not work when a zone is faulted.	a) Not activating for interior zones. b) The keypad is not assigned to the same partition as the zone being activated.	a) Chime mode only activates for perimeter zones - Chime mode must be programmed. Also, if the perimeter zone has trouble enabled (trouble on open), the chime won't work if that zone is opening. b) Chime mode will only activate the sounder on keypads that are assigned to the same partition as the zone.
Some functions won't work on a Master keypad.	Some functions require you to enter single partition mode when using a Master keypad.	The following commands require that you are in Single Partition Mode when entering from a Master keypad: • History read-back • Chime mode • Checking zone status • Checking zone trouble status (after #87 - Master keypad will show only partition name) • Bypassing zones

17.2 Reporting Problems

Symptom	Probable Cause	Possible Solution
Won't send open or close reports.	Not programmed correctly.	Check addresses: 0320, 0321, 0323, and 0187.
Reports for partitions 2-8 are being sent with partition 1's reporting ID.	The account codes for 2-8 are not programmed or are not programmed correctly.	Check addresses: 0496-0526.
Not getting AC power fail reports.	a) AC power fail messages are sent only with other reports, such as low battery. b) Check A/C report offset (0197). If 00, A/C report will work like above, if another number, A/C report will be delayed.	a) Try forcing another report to send when AC is not present. b) Wait until the delay times out or set to a lower number if desired.
Panel never transmits history to WD-SRP.	a) Not programmed to send history. b) Time and date not set.	a) Check programming. b) Verify that the time in the panel is set.
The communicator test report is not being sent.	a) Report not programmed properly. b) There was a control problem at the time the report should have been sent. If this is the case, the communicator test report will not be sent. Instead, the control will send the "System Off Normal" report.	a) Check programming addresses 1521, 1522, 1525, and 0329. b) Program "System Off Normal" report in address 0336.

17.3 Zone Problems

Symptom	Probable Cause	Possible Solution
Fire Alarm displays on keypad but no zone numbers are displayed.	In Commercial Fire Mode, fire alarms must be silenced before the zone number will display.	Enter a valid disarm PIN and press #, then enter a valid disarm PIN and press # again to display the zones.
Every other zone displays **Not Ready.**	Zone Programming is incorrect.	Program as a multiple zone input for DS7432 or DS7460, a single zone input for contacts and sensors, or program as a DS7465.

Copyright © 1995-96 Detection Systems, Inc.

Zone Problems (Continued)

Symptom	Probable Cause	Possible Solution
Zones 9 and above show **Not Ready, Zone Trouble.**	a) The multiplex expansion module is not installed properly.	a) Make sure the multiplex expansion module is seated properly in the upper pins on the DS7400Xi circuit board.
	b) Multiplex wiring is missing or not installed properly.	b) Check wiring and perform a system reset.
	c) 8-Input remote module DIP switches are not set properly.	c) Correctly set the DIP switches for the 8-Input remote modules.
	d) 8-Input remote module covers are removed.	d) Replace covers or install the tamper bypass jumper.
	e) The BusLoc® code is set incorrectly or has not been programmed into modules.	e) BusLoc® can not be used with 8-Input remote modules. If using 8-Input modules, remove the BusLoc® code. **OR** If using two-input remote modules or the DS7465, be sure to use BusLoc® when programming. If not using BusLoc®, be sure to remove the BusLoc® code from address 9999.
	f) Zone Programming is incorrect.	f) Program as a multiple zone input for DS7432 or DS7460, a single zone input for contacts and sensors, or program as a DS7465.
	g) Multiplex module not programmed.	g) Program the module.
Invisible or silent zone activates alarm output.	The output is programmed as “latch on alarm” (0).	Program the output to follow zone alarms (6).
Keypad displays **Fire Trouble**, but does not indicate any zones.	A ground fault condition exists.	See system trouble: Ground fault.
Keypad displays **Not Ready,** but no zone number is displayed.	An invisible zone is not ready.	Press [PIN] + [OFF] to display the zone number of the invisible zone that is not ready.

17.4 General System Problems

Symptom	Probable Cause	Possible Solution
How to set the programming values to the factory default.	Enter a value of 01 in address 4058.	**Caution:** Only enter a value of 01 in address 4058 when you are sure you want to default the programming. Doing so will immediately erase all programming.
Power LED is flashing, keypad displays **Control Trouble Press #87.**	A control trouble exists.	Press #87 to determine the trouble condition.
#87 display = **Oct. Relay Fault** #89 display = **System Fault 20**	a) The octal relay module (DS7488) is defective or the wiring to the module is defective.	a) Check the wiring to the module.
	b) There is no DS7488 or a DS7488 has been removed from the system.	b) Enter, then exit programming mode. This will rescan the options bus and clear the problem.
#87 display = **Multiplex Bus Fault**	The Multiplex Bus is defective or shorted.	Check wiring for shorts.
Can’t reset to factory default.	Keypad programming access is set to PARTIAL from Remote programmer.	Change setting to FULL from the Remote programmer.

Copyright © 1995-96 Detection Systems, Inc.

General System Problems (Continued)

Symptom	Probable Cause	Possible Solution
#87 display = **RAM Fault** #89 display = **System Fault 01** or #87 display = **ROM Fault** #89 display = **System Fault 02** or #87 display = **EEProm Fault** #89 display = **System Fault 03**		a) An EEProm fault can be caused by disconnecting power from the control while it is in program mode. In this case, enter then exit program mode to clear. b) Try to clear the error at the keypad by entering a PIN then Reset. c) Remove AC and battery power, then re-apply. Remember that event history will be lost and time/date will have to be re-set. d) If error persists, return the panel to factory default programming by setting program address 4058 to "01". If the error clears, re-program the panel. e) If error still persists, replace the panel.
#87 display = **Communicator Err** #89 display = **Report Failure X**	The control has failed to communicate.	Check history #89 to determine the source: Report Failure 1 = Phone number 1 Report Failure 2 = Phone number 2 Report Failure 3 = Phone number 3 (remote programmer) Report Failure 4 = ARDIS Network
#87 display = **2Ph/Bell Fault** #89 display = **System Fault 10**	a) The dual phone line/bell supervision module (DS7420i) is defective or the wiring to the module is defective. b) There is no DS7420i or a DS7420i has been removed from the system.	a) Check the wiring to the module. b) Enter, then exit programming mode. This will re-scan the options bus and clear the problem.
#87 display = **Line 1 Fault** #89 display = **System Fault 11**	There is a phone line fault on line 1.	Check phone line 1 for proper operation.
#87 display = **Line 2 Fault** #89 display = **System Fault 12**	There is a phone line fault on line 2.	Check phone line 2 for proper operation. If you wish to monitor only one phone line, reprogram address 1520.
#87 display = **Bell Fault** #89 display = **System Fault 13**	The bell circuit on the DS7420i is open or shorted.	Check the bell circuit wiring. Be sure that the end-of-line resistor is in place. If you don't wish to use the bell circuit, place an end-of-line resistor across the bell terminals.
#87 display = **Aux. Output Fault** #89 display = **System Fault 14**	The auxiliary circuit on the DS7420i is open or shorted.	Check the auxiliary circuit wiring. Be sure that the end-of-line resistor is in place. If you don't wish to use the auxiliary circuit, place an end-of-line resistor across the auxiliary terminals. If you wish to use the auxiliary circuit but do not wish to supervise it, cut the auxiliary supervision jumper on the DS7420i.
#87 display = **Aux Power Fault**	The auxiliary power output has been shorted.	Remove wiring from auxiliary power and check for shorts.
#87 display = **Keypad Fault**	a) The keypad wiring is defective. b) A keypad is missing. c) A keypad has been programmed, but is not intended in this system.	a) Check keypad operation and wiring. b) Install a keypad. c) Remove from programming (0173-0180).

Copyright © 1995-96 Detection Systems, Inc.

General System Problems (Continued)

Symptom	Probable Cause	Possible Solution
#87 display = **Ground Fault** #89 display = **System Fault 04**	There is a short to ground somewhere in the system.	Disconnect field wiring from each terminal while watching the keypad display. When the keypad power LED stops flashing, you have found the wire that is causing the ground fault. **Note:** The LED will not stop flashing if there is another system fault present. If there is no keypad nearby, or another control problem exists, you can use a volt-meter to find the ground fault: 1) Connect the negative lead of a volt-meter to the panel ground terminal. 2) Connect the positive terminal to the Aux Power – terminal. You should read -4.5 to -7.5 Volts DC. A reading considerably higher or lower indicates a ground fault. Disconnect field wiring from each terminal while watching the meter. When the voltage reading returns to between -4.5 and -7.5 VDC, you have found the wire that is causing the ground fault.
#87 display = **AR IB Queue Full** #89 display = **System Fault 51**	The message queue in the RF modem is full and no messages can get out to the radio network.	Check RF coverage of the unit and check for RF noisy environment.
#87 display = **AR Host Down** #89 display = **System Fault 52**	The central station receiver has ceased to be available to the network.	Contract the central station and notify of status.
#87 display = **AR Unreg. Modem** #89 display = **System Fault 53**	The modem is not registered through all parts of the network.	Contact the network administrators or technical service.
#87 display = **AR Power Fail** #89 display = **System Fault 54**	There is a possible problem with the ARDIS Module unit.	Return for service.
#87 display = **AR Network Lost** #89 display = **System Fault 55**	The ARDIS Module has lost contact with the radio network.	Check the location and coverage of the unit.
#87 display = **AR Modem HW Err** #89 display = **System Fault 56**	There is a possible problem with the radio modem.	Replace the unit.
#87 display = **AR Modem SW Err** #89 display = **System Fault 57**	The ARDIS Module is having some trouble communicating with the radio modem.	Check for noisy environment and replace the unit if the problem continues.
#87 display = **AR Opt. Bus Err** #89 display = **System Fault 58**	The panel can no longer communicate with the ARDIS Module.	Check the wiring between the DS7400Xi and the ARDIS Module.
#87 display = **AR Corrupt MSG** #89 display = **System Fault 59**	The communication between the panel and the ARDIS Module is getting corrupted.	Check for noisy environment, and check the wiring between the DS7400Xi and the ARDIS Module.
Unable to arm the system.	a) Zone(s) faulted. b) If an AC failure exists, you must force arm.	a) Determine the cause of the problem and clear the indicated zone(s). b) Enter an arming sequence, then press the Bypass key during a 5 second beep.

Copyright © 1995-96 Detection Systems, Inc.

General System Problems (Continued)

Symptom	Probable Cause	Possible Solution
#87 display = **Battery Trouble**	a) The battery failed a battery test.	a) If there has just been a power failure, wait at least two hours for the battery to recharge then perform a System Reset to re-test the battery and clear the error.
	b) The battery is defective.	b) Replace the battery.
	c) The wiring to the battery is disconnected.	c) Check wiring.
#87 display = **Zone Trouble**	a) A zone is not responding to the control panel.	a) Check wiring to the zone. **or** If the zone is not to be used, remove from programming.
	b) The zone is programmed for "Trouble on Open" and the loop is open.	b) If using Normally Closed contacts, re-program zone for alarm on open. **or** If using Normally Open contacts and trouble on open is desired, check for opens in the loop. Remove wiring and place an EOL resistor across the zone to eliminate a problem with the control. If the trouble goes away, the problem is in the wiring or in a contact connected to the zone.
	There is a power failure and the panel is operating on battery backup. If there is a general power failure, wait for the power to return. If there is not a general power failure in the building:	
#87 display = **AC Power Failure**	a) The transformer is unplugged.	a) Plug the transformer in.
	b) The wiring from the transformer is defective.	b) Check the wiring.
	c) The circuit to the transformer is off or defective.	c) Check the circuit and circuit breakers.
	d) The transformer is defective.	d) Replace the transformer.
	e) In some cases, the transformer may be connected to a circuit controlled by a switch or a circuit breaker that is periodically turned off.	e) Connect to a circuit that is not controlled this way.
Fire Alarm displays "000".	The Fire Alarm was caused by the "A" key.	Use the System Reset command to clear the display.
Fire Trouble, no zone number.	When in Commercial Fire Mode, a ground fault causes this display.	See #87 Ground Fault display for solution.
Fire Trouble _____ zone number.	Fire zone wiring problems.	If you try to disable the zone by reprogramming it, you need to reset the control by either entering then exiting programmer's mode, or removing then restoring power to the control panel.

Copyright © 1995-96 Detection Systems, Inc.

18.0 Program Addresses

Address	Description
0000	General Control
0001	Zone Function 1
0002	Zone Function 2
0003	Zone Function 3
0004	Zone Function 4
0005	Zone Function 5
0006	Zone Function 6
0007	Zone Function 7
0008	Zone Function 8
0009	Zone Function 9
0010	Zone Function 10
0011	Zone Function 11
0012	Zone Function 12
0013	Zone Function 13
0014	Zone Function 14
0015	Zone Function 15
0016	Zone Bypass
0017	Zone Bypass
0018	Zone Number 1
0019	Zone Number 2
0020	Zone Number 3
0021	Zone Number 4
0022	Zone Number 5
0023	Zone Number 6
0024	Zone Number 7
0025	Zone Number 8
0026	Zone Number 9
0027	Zone Number 10
0028	Zone Number 11
0029	Zone Number 12
0030	Zone Number 13
0031	Zone Number 14
0032	Zone Number 15
0033	Zone Number 16
0034	Zone Number 17
0035	Zone Number 18
0036	Zone Number 19
0037	Zone Number 20
0038	Zone Number 21
0039	Zone Number 22
0040	Zone Number 23
0041	Zone Number 24
0042	Zone Number 25
0043	Zone Number 26
0044	Zone Number 27
0045	Zone Number 28
0046	Zone Number 29
0047	Zone Number 30
0048	Zone Number 31
0049	Zone Number 32
0050	Zone Number 33
0051	Zone Number 34
0052	Zone Number 35
0053	Zone Number 36
0054	Zone Number 37
0055	Zone Number 38
0056	Zone Number 39
0057	Zone Number 40
0058	Zone Number 41
0059	Zone Number 42
0060	Zone Number 43
0061	Zone Number 44
0062	Zone Number 45
0063	Zone Number 46
0064	Zone Number 47
0065	Zone Number 48
0066	Zone Number 49
0067	Zone Number 50
0068	Zone Number 51
0069	Zone Number 52
0070	Zone Number 53
0071	Zone Number 54
0072	Zone Number 55
0073	Zone Number 56
0074	Zone Number 57
0075	Zone Number 58
0076	Zone Number 59
0077	Zone Number 60
0078	Zone Number 61
0079	Zone Number 62
0080	Zone Number 63
0081	Zone Number 64
0082	Zone Number 65
0083	Zone Number 66
0084	Zone Number 67
0085	Zone Number 68
0086	Zone Number 69
0087	Zone Number 70
0088	Zone Number 71
0089	Zone Number 72
0090	Zone Number 73
0091	Zone Number 74
0092	Zone Number 75
0093	Zone Number 76
0094	Zone Number 77
0095	Zone Number 78
0096	Zone Number 79
0097	Zone Number 80
0098	Zone Number 81
0099	Zone Number 82
0100	Zone Number 83
0101	Zone Number 84
0102	Zone Number 85
0103	Zone Number 86
0104	Zone Number 87
0105	Zone Number 88
0106	Zone Number 89
0107	Zone Number 90
0108	Zone Number 91
0109	Zone Number 92
0110	Zone Number 93
0111	Zone Number 94
0112	Zone Number 95
0113	Zone Number 96
0114	Zone Number 97
0115	Zone Number 98
0116	Zone Number 99
0117	Zone Number 100
0118	Zone Number 101
0119	Zone Number 102
0120	Zone Number 103
0121	Zone Number 104
0122	Zone Number 105
0123	Zone Number 106
0124	Zone Number 107
0125	Zone Number 108
0126	Zone Number 109
0127	Zone Number 110
0128	Zone Number 111
0129	Zone Number 112
0130	Zone Number 113
0131	Zone Number 114
0132	Zone Number 115
0133	Zone Number 116
0134	Zone Number 117
0135	Zone Number 118
0136	Zone Number 119
0137	Zone Number 120
0138	Zone Number 121
0139	Zone Number 122
0140	Zone Number 123
0141	Zone Number 124
0142	Zone Number 125
0143	Zone Number 126
0144	Zone Number 127
0145	Zone Number 128
0146	Alarm Output
0147	Programmable Output 1
0148	Programmable Output 2
0149	Output Partition Assignment
0150	Output Partition Assignment
0165	Partition Control
0169	Quick Arm Control
0173	Keypad Assignment
0174	Keypad Assignment
0175	Keypad Assignment
0176	Keypad Assignment
0177	Keypad Assignment
0178	Keypad Assignment
0179	Keypad Assignment
0180	Keypad Assignment
0181	Emergency Key
0182	Panic Key
0183	Custom Arming
0184	Custom Arming
0185	Force Arming & Ground Fault
0186	Commercial Fire Mode
0187	Open/Close Report Control
0189	Open/Close/Zone Rprt. Cntrl.
0190	Report Control
0191	Entry Delay Time 1
0192	Entry Delay Time 2
0193	Exit Delay Time
0195	Fire Bell Cutoff
0196	Burglary Bell Cutoff
0197	A/C Fail Report Delay
0198	General Code: Arm Only
0199	General Code: Arm Only
0200	General Code: Arm Only
0201	General Code: Arm Only
0202	Arming Warning
0203	Arming Warning
0204	Arming Warning

Copyright © 1995-96 Detection Systems, Inc.

Address	Description
0205	Arming Warning
0206	DS7412 Interface Control
0207	DS7412 Interface Config.
0208	Keypad Partition Assign.
0209	Keypad Partition Assign.
0210	Keypad Partition Assign.
0211	Keypad Partition Assign.
0212	Keypad Partition Assign.
0213	Keypad Partition Assign.
0214	Keypad Partition Assign.
0215	Keypad Partition Assign.
0256	Keypad Fire Alarm Report
0257	Keypad Fire Restoral Report
0258	Zone Func. 1 Alarm Report
0259	Zone Func. 2 Alarm Report
0260	Zone Func. 3 Alarm Report
0261	Zone Func. 4 Alarm Report
0262	Zone Func. 5 Alarm Report
0263	Zone Func. 6 Alarm Report
0264	Zone Func. 7 Alarm Report
0265	Zone Func. 8 Alarm Report
0266	Zone Func. 9 Alarm Report
0267	Zone Func. 10 Alarm Report
0268	Zone Func. 11 Alarm Report
0269	Zone Func. 12 Alarm Report
0270	Zone Func. 13 Alarm Report
0271	Zone Func. 14 Alarm Report
0272	Zone Func. 15 Alarm Report
0273	Keypad Emergency Report
0274	Keypad Panic Report
0275	Zone Func. 1 Restoral Rpt.
0276	Zone Func. 2 Restoral Rpt.
0277	Zone Func. 3 Restoral Rpt.
0278	Zone Func. 4 Restoral Rpt.
0279	Zone Func. 5 Restoral Rpt.
0280	Zone Func. 6 Restoral Rpt.
0281	Zone Func. 7 Restoral Rpt.
0282	Zone Func. 8 Restoral Rpt.
0283	Zone Func. 9 Restoral Rpt.
0284	Zone Func. 10 Restoral Rpt.
0285	Zone Func. 11 Restoral Rpt.
0286	Zone Func. 12 Restoral Rpt.
0287	Zone Func. 13 Restoral Rpt.
0288	Zone Func. 14 Restoral Rpt.
0289	Zone Func. 15 Restoral Rpt.
0290	Zone Func. 1 Trouble Rpt.
0291	Zone Func. 2 Trouble Rpt.
0292	Zone Func. 3 Trouble Rpt.
0293	Zone Func. 4 Trouble Rpt.
0294	Zone Func. 5 Trouble Rpt.
0295	Zone Func. 6 Trouble Rpt.
0296	Zone Func. 7 Trouble Rpt.
0297	Zone Func. 8 Trouble Rpt.
0298	Zone Func. 9 Trouble Rpt.
0299	Zone Func. 10 Trouble Rpt.
0300	Zone Func. 11 Trouble Rpt.
0301	Zone Func. 12 Trouble Rpt.
0302	Zone Func. 13 Trouble Rpt.
0303	Zone Func. 14 Trouble Rpt.
0304	Zone Func. 15 Trouble Rpt.
0320	Open Report
0321	Close Report
0322	Duress Report
0323	Partial Close Report
0324	First Open After Alarm Rpt.
0325	Low Battery Report
0326	Battery Restoral Report
0327	AC Fail Report
0328	AC Restoral Report
0329	Communicator Test/System Normal Report
0330	Remote Prog. Successful Report
0331	Remote Prog. Unsuccessful Report
0332	Local Prog. Successful Rprt.
0333	Local Prog. Unsuccessful Report
0334	System Trouble Report
0335	Sys. Trouble Restoral Rprt.
0336	Communicator Test/System Off Normal Report
0337	Exit Error Report
0338	Recent Closing Report
0339	System Test Report
0340	System Test Restoral Report
0494	Phone/ARDIS Routing Cntrl.
0495	Phone/ARDIS Routing Cntrl.
0496	Account Code
0498	Account Code
0500	Account Code
0502	Account Code
0504	Account Code
0506	Account Code
0508	Account Code
0510	Account Code
0512	Account Code
0514	Account Code
0516	Account Code
0518	Account Code
0520	Account Code
0522	Account Code
0524	Account Code
0526	Account Code
0528	Phone Number Gen. Cntrl.
0529	Phone Number 1 Format
0530	Phone Number 2 Format
0531	Phone Answering
0532	Programmer's Code
0534	Master Code
1248	Zone 1 & 2 Part. Assign.
1249	Zone 3 & 4 Part. Assign.
1250	Zone 5 & 6 Part. Assign.
1251	Zone 7 & 8 Part. Assign.
1252	Zone 9 & 10 Part. Assign.
1253	Zone 11 & 12 Part. Assign.
1254	Zone 13 & 14 Part. Assign.
1255	Zone 15 & 16 Part. Assign.
1256	Zone 17 & 18 Part. Assign.
1257	Zone 19 & 20 Part. Assign.
1258	Zone 21 & 22 Part. Assign.
1259	Zone 23 & 24 Part. Assign.
1260	Zone 25 & 26 Part. Assign.
1261	Zone 27 & 28 Part. Assign.
1262	Zone 29 & 30 Part. Assign.
1263	Zone 31 & 32 Part. Assign.
1264	Zone 33 & 34 Part. Assign.
1265	Zone 35 & 36 Part. Assign.
1266	Zone 37 & 38 Part. Assign.
1267	Zone 39 & 40 Part. Assign.
1268	Zone 41 & 42 Part. Assign.
1269	Zone 43 & 44 Part. Assign.
1270	Zone 45 & 46 Part. Assign.
1271	Zone 47 & 48 Part. Assign.
1272	Zone 49 & 50 Part. Assign.
1273	Zone 51 & 52 Part. Assign.
1274	Zone 53 & 54 Part. Assign.
1275	Zone 55 & 56 Part. Assign.
1276	Zone 57 & 58 Part. Assign.
1277	Zone 59 & 60 Part. Assign.
1278	Zone 61 & 62 Part. Assign.
1279	Zone 63 & 64 Part. Assign.
1280	Zone 65 & 66 Part. Assign.
1281	Zone 67 & 68 Part. Assign.
1282	Zone 69 & 70 Part. Assign.
1283	Zone 71 & 72 Part. Assign.
1284	Zone 73 & 74 Part. Assign.
1285	Zone 75 & 76 Part. Assign.
1286	Zone 77 & 78 Part. Assign.
1287	Zone 79 & 80 Part. Assign.
1288	Zone 81 & 82 Part. Assign.
1289	Zone 83 & 84 Part. Assign.
1290	Zone 85 & 86 Part. Assign.
1291	Zone 87 & 88 Part. Assign.
1292	Zone 89 & 90 Part. Assign.
1293	Zone 91 & 92 Part. Assign.
1294	Zone 93 & 94 Part. Assign.
1295	Zone 95 & 96 Part. Assign.
1296	Zone 97 & 98 Part. Assign.
1297	Zone 99 & 100 Part. Assign.
1298	Zone 101 & 102 Part. Assign.
1299	Zone 103 & 104 Part. Assign.
1300	Zone 105 & 106 Part. Assign.
1301	Zone 107 & 108 Part. Assign.
1302	Zone 109 & 110 Part. Assign.
1303	Zone 111 & 112 Part. Assign.
1304	Zone 113 & 114 Part. Assign.
1305	Zone 115 & 116 Part. Assign.
1306	Zone 117 & 118 Part. Assign.
1307	Zone 119 & 120 Part. Assign.
1308	Zone 121 & 122 Part. Assign.
1309	Zone 123 & 124 Part. Assign.
1310	Zone 125 & 126 Part. Assign.
1311	Zone 127 & 128 Part. Assign.
1456	Octal Module #1, Relay #1
1457	Octal Module #1, Relay #2
1458	Octal Module #1, Relay #3
1459	Octal Module #1, Relay #4
1460	Octal Module #1, Relay #5
1461	Octal Module #1, Relay #6
1462	Octal Module #1, Relay #7
1463	Octal Module #1, Relay #8
1464	Octal Module #2, Relay #9
1465	Octal Module #2, Relay #10

Copyright © 1995-96 Detection Systems, Inc.

Address	Description
1466	Octal Module #2, Relay #11
1467	Octal Module #2, Relay #12
1468	Octal Module #2, Relay #13
1469	Octal Module #2, Relay #14
1470	Octal Module #2, Relay #15
1471	Octal Module #2, Relay #16
1472	Output Function 1
1475	Output Function 2
1478	Output Function 3
1481	Output Function 4
1484	Output Function 5
1487	Output Function 6
1490	Output Function 7
1493	Output Function 8
1496	Output Function 9
1499	Output Function 10
1502	Output Function 11
1505	Output Function 12
1508	Output Function 13
1511	Output Function 14
1514	Output Function 15
1520	Dual Phone Line / Bell Supervision Module Output
1521	Comm. Test Report Timer
1523	Remote Programmer Timer
1525	Test Report & Remote Programmer Call-Out
1526	Alpha for Partition 1
1542	Alpha for Partition 2
1558	Alpha for Partition 3
1574	Alpha for Partition 4
1590	Alpha for Partition 5
1606	Alpha for Partition 6
1622	Alpha for Partition 7
1638	Alpha for Partition 8
1654	Alpha for Zone Number 1
1670	Alpha for Zone Number 2
1686	Alpha for Zone Number 3
1702	Alpha for Zone Number 4
1718	Alpha for Zone Number 5
1734	Alpha for Zone Number 6
1750	Alpha for Zone Number 7
1766	Alpha for Zone Number 8
1782	Alpha for Zone Number 9
1798	Alpha for Zone Number 10
1814	Alpha for Zone Number 11
1830	Alpha for Zone Number 12
1846	Alpha for Zone Number 13
1862	Alpha for Zone Number 14
1878	Alpha for Zone Number 15
1894	Alpha for Zone Number 16
1910	Alpha for Zone Number 17
1926	Alpha for Zone Number 18
1942	Alpha for Zone Number 19
1958	Alpha for Zone Number 20
1974	Alpha for Zone Number 21
1990	Alpha for Zone Number 22
2006	Alpha for Zone Number 23
2022	Alpha for Zone Number 24
2038	Alpha for Zone Number 25
2054	Alpha for Zone Number 26
2070	Alpha for Zone Number 27
2086	Alpha for Zone Number 28
2102	Alpha for Zone Number 29
2118	Alpha for Zone Number 30
2134	Alpha for Zone Number 31
2150	Alpha for Zone Number 32
2166	Alpha for Zone Number 33
2182	Alpha for Zone Number 34
2198	Alpha for Zone Number 35
2214	Alpha for Zone Number 36
2230	Alpha for Zone Number 37
2246	Alpha for Zone Number 38
2262	Alpha for Zone Number 39
2278	Alpha for Zone Number 40
2294	Alpha for Zone Number 41
2310	Alpha for Zone Number 42
2326	Alpha for Zone Number 43
2342	Alpha for Zone Number 44
2358	Alpha for Zone Number 45
2374	Alpha for Zone Number 46
2390	Alpha for Zone Number 47
2406	Alpha for Zone Number 48
2422	Alpha for Zone Number 49
2438	Alpha for Zone Number 50
2454	Alpha for Zone Number 51
2470	Alpha for Zone Number 52
2486	Alpha for Zone Number 53
2502	Alpha for Zone Number 54
2518	Alpha for Zone Number 55
2534	Alpha for Zone Number 56
2550	Alpha for Zone Number 57
2566	Alpha for Zone Number 58
2582	Alpha for Zone Number 59
2598	Alpha for Zone Number 60
2614	Alpha for Zone Number 61
2630	Alpha for Zone Number 62
2646	Alpha for Zone Number 63
2662	Alpha for Zone Number 64
2678	Alpha for Zone Number 65
2694	Alpha for Zone Number 66
2710	Alpha for Zone Number 67
2726	Alpha for Zone Number 68
2742	Alpha for Zone Number 69
2758	Alpha for Zone Number 70
2774	Alpha for Zone Number 71
2790	Alpha for Zone Number 72
2806	Alpha for Zone Number 73
2822	Alpha for Zone Number 74
2838	Alpha for Zone Number 75
2854	Alpha for Zone Number 76
2870	Alpha for Zone Number 77
2886	Alpha for Zone Number 78
2902	Alpha for Zone Number 79
2918	Alpha for Zone Number 80
2934	Alpha for Zone Number 81
2950	Alpha for Zone Number 82
2966	Alpha for Zone Number 83
2982	Alpha for Zone Number 84
2998	Alpha for Zone Number 85
3014	Alpha for Zone Number 86
3030	Alpha for Zone Number 87
3046	Alpha for Zone Number 88
3062	Alpha for Zone Number 89
3078	Alpha for Zone Number 90
3094	Alpha for Zone Number 91
3110	Alpha for Zone Number 92
3126	Alpha for Zone Number 93
3142	Alpha for Zone Number 94
3158	Alpha for Zone Number 95
3174	Alpha for Zone Number 96
3190	Alpha for Zone Number 97
3206	Alpha for Zone Number 98
3222	Alpha for Zone Number 99
3238	Alpha for Zone Number 100
3254	Alpha for Zone Number 101
3270	Alpha for Zone Number 102
3286	Alpha for Zone Number 103
3302	Alpha for Zone Number 104
3318	Alpha for Zone Number 105
3334	Alpha for Zone Number 106
3350	Alpha for Zone Number 107
3366	Alpha for Zone Number 108
3382	Alpha for Zone Number 109
3398	Alpha for Zone Number 110
3414	Alpha for Zone Number 111
3430	Alpha for Zone Number 112
3446	Alpha for Zone Number 113
3462	Alpha for Zone Number 114
3478	Alpha for Zone Number 115
3494	Alpha for Zone Number 116
3510	Alpha for Zone Number 117
3526	Alpha for Zone Number 118
3542	Alpha for Zone Number 119
3558	Alpha for Zone Number 120
3574	Alpha for Zone Number 121
3590	Alpha for Zone Number 122
3606	Alpha for Zone Number 123
3622	Alpha for Zone Number 124
3638	Alpha for Zone Number 125
3654	Alpha for Zone Number 126
3670	Alpha for Zone Number 127
3686	Alpha for Zone Number 128
3725	Octal Relay Partition Assign.
3726	Octal Relay Partition Assign.
3727	Octal Relay Partition Assign.
3728	Octal Relay Partition Assign.
3729	Octal Relay Partition Assign.
3730	Octal Relay Partition Assign.
3731	Octal Relay Partition Assign.
3732	Octal Relay Partition Assign.
3733	Output Func. Part. Assign.
3734	Output Func. Part. Assign.
3735	Output Func. Part. Assign.
3736	Output Func. Part. Assign.
3737	Output Func. Part. Assign.
3738	Output Func. Part. Assign.
3739	Output Func. Part. Assign.
3740	Output Func. Part. Assign.
4028	Phone Number 1
4038	Phone Number 2
4048	Phone Number 3

Copyright © 1995-96 Detection Systems, Inc.

Index

Symbols

24-Hour Zone 15
4/2 Format 69

A

A/C Fail Report 45
AC Fail Report 19
AC Restoral Report 19
Access Output 16
Access PIN 21
Account Code Programming 50
Ademco AB-12 Bell 68
Alarm on Open 15
Alarm on Short 15
Alarms, Fire 25
Alarms, Invisible 15
Alarms, Silent 15
Alpha Programming 58
Answering Machine Bypass 19
ARDIS 49
Arm Only 46
Arm Only PIN 21
Arming, Custom 1, 14
Arming, Force 1
Arming, Maximum Security 14
Arming, Normal 1, 14
Arming, Perimeter 1, 14
Arming, Perimeter Instant 14
Arming Warning 46
Authority Leve 21
Automatic Arming 24

B

Battery Restoral Report 19
Battery Test 1
Battery/Sounder Test 27
BFSK Format 70
Bypass, Zone 1
Bypassing Allowed 15

C

California March Time 18
Call-Out Timer 57
Change a PIN 21
Changing Date 22
Changing Time 23
Chime Mode 1
Close Reports 18
Closing Ring-Back 14
Commercial Fire Mode 18, 43
  California March Time 18
  Multiple Keypad Use 18
  Pulsing Fire Zone 18
  Single Keypad Use 18
  Temporal 18
  Water Flow Zone Delay 18
Common Area 17
Communicator Test 1, 28
Communicator Test/System Normal Report 19
Communicator Test/System Off Normal Report 19
Contact I.D Format 75
Custom Arming 14, 17, 41

D

Day Monitor 15
Default, Factory 32
Defaults 32
Delayed Arming 23
Delayed, Zone Alarm 16
DS7412 47
DS7420i 56
Duress 25
Duress PIN 21

E

Emergency Key 17, 41
Emergency Procedures 25
Enable Remote Programmer Callback 19
Entering a Program Address 31
Entering the Programmer's Mode 31
Entry Pre-Alert 16
Entry/Exit Delay 15
Error Display 1
Error Display Reset 1
Error Displays 29
Exiting Programmer's Mode 32

F

Factory Default 32
Fire Key 17
Fire Reset 1
Fire Reset/Fire Trouble 25
Fire Safety 26
Fire Zone 15
Fire Zone with Verification 16
Flow, Water Zone 16
Force Arming 1, 42

G

General PIN 21
Ground Fault 17
Ground Fault Detect 42
Ground Start 16

H

HEX values 32
History Readback 28

I

Input Cross Matrix 55
Interior Entry/Exit Follower 15
Interior Home/Away 15
Interior Instant 15
Invisible Alarms 15

K

Keypad Alarms 26
Keypad Assignment 17, 40
Keypad Fire Alarm 18
Keypad Fire Restoral 18
Keypad Partition 40
Keypad Problems 78
Keypad Sounder Output 16
Keyswitch Input 15

L

Latch on Any Zone Alarm 16
Load Number 20
Local Program Successful Report 19
Local Program Unsuccessful Report 19
Low Battery Report 19

M

Master Code 53
Master Keypad 30
Master Keypad Arming 30
Master Keypad Disarm 31

 Copyright © 1995-96 Detection Systems, Inc.

Master Keypad Programming 17
Master PIN 21
Maximum Security Arming 14
Multiple Keypad Use 18
Multiple Zone Input 16
Multiplex Zone 77

N

Normal Arming 14

O

Octal Relay 53
ON during Entry Pre-Alert 16
ON for 10 seconds 16
ON when System is Armed 16
Open/Close Report 44
Output, Access 16
Output Cross Matrix 55
Output Function programming 55
Output, Keypad Sounder 16
Output, Panic/Duress 17
Output Partition 38
Output Partition Assignment 56
Output Programming 16
Output programming 38, 55

P

Pager Format 71
Panic Key 41
Panic/Duress Output 17
Partition Assignment 36
Partition Control 39
Partition Control Programming 17
Perimeter Arming 14
Perimeter Instant Arming 14
Phone Answering 52
Phone Number Programming 63
PIN 21
PIN Expiration Date 22
Program Addresses 84
Programmer's Code 53
Programming, Master Keypad 17
Programming, Output 16
Programming, Partition Control 17
Programming, Zone 16
Pulsing Fire Zone 18

Q

Quick Arm Control 39

R

Reading a Program Address 31
Receivers 52
Remote Program Dial-out 28
Remote Program Successful Report 19
Remote Program Unsuccessful Report 19
Report Programming 18, 48
Reporting Problems 79
Reports
- AC Fail 19
- AC Restoral 19
- Battery Restoral 19
- Close 18
- Communicator Test/System Normal 19
- Communicator Test/System Off Normal 19
- Keypad Fire Alarm 18
- Keypad Fire Restoral 18
- Local Program Successful 19
- Local Program Unsuccessful 19
- Low Battery 19
- Remote Program Successful 19
- Remote Program Unsuccessful 19
- System Test 19
- System Test Restoral 19
- System Trouble 19
- System Trouble Restoral 19

Restore when Sounders Silence 15
Restore when System Disarms 15
Restore when Zone Restores 15
RS232 Interface 47

S

SIA Format 73
Silent Alarms 15
Single Keypad Use 18
Single Partition Mode 31
Single Zone Input 16
Siren on Communication Fail 15
Special Emergency Key 17
Swinger Shunts 15
System Problems 80
System Status (ready to arm) 16
System Test Report 19
System Test Restoral Report 19
System Trouble Report 19
System Trouble Restoral Report 19

T

Temporal 18
Temporary PIN 21
Test, Communicator 28
Test Report 57
Test, Zone 27
Timer Programming 45, 57
Trouble, Fire 25
Trouble on Open 15
Trouble on Short 15
Troubleshooting Guide 78

U

U. L. Listings 64
Unlimited PIN 21
User Numbe 21

W

Water Flow Zone 16
Water Flow Zone Delay 18
WDSRP 47

Z

Zone Alarm 16
Zone Alarm Delayed 16
Zone Alarm, Latch on Any 16
Zone Bypass 1, 37
Zone, Fire 15
Zone Problems 79
Zone Programming 16
Zone, Pulsing Fire 18
Zone Test 1, 27

 Copyright © 1995-96 Detection Systems, Inc.

PRODUCT UPDATE

Detection Systems, Inc.
130 Perinton Parkway
Fairport, N.Y. 14450

Service (800) 374-7454
Sales (800) 289-0096
(716) 223-4060

CONCERNS: U.L.C. Commercial Fire Applications

AFFECTS: DS7400Xi Control Panel

DATED: February 16, 1996

DS7400Xi Reference Guide Addendum

For DS7400Xi Underwriters Laboratories of Canada (U.L.C.) Commercial Fire Applications, the following two modifications are required:

1. Do not use the enclosed transformer, instead use a CSA approved Class 2 transformer that is approved for fire monitoring station applications, such as the Basler S19591-0028.

2. Connect the earth ground terminal of the DS7400Xi control panel and the door and to the threaded ground stud on the base of the enclosure, as shown below. Also connect the earth ground of the transformer to the threaded ground stud on the base of the enclosure.



AE1 or AE2 Enclosure



AE3 or AE4 Enclosure

Copyright © 1996 Detection Systems, Inc.